



ALT-9000
Radio Altimeter Test Set
Remote Commands Manual



ALT-9000
Radio Altimeter Test Set
Remote Commands Manual
22159915 / Rev 002
Part of CD: 22149666



VIAVI Solutions
1-844-GO-VIAVI
www.viavisolutions.com



Table of Contents

| | | |
|------------------|-------------------------------------|------------|
| Chapter 1 | Introduction | 1-1 |
| | Introduction | 1-3 |
| | General Information | 1-3 |
| | SCPI Structure | 1-3 |
| | Command Guidelines | 1-5 |
| | Command Short and Long Form | 1-5 |
| | Command Punctuation | 1-5 |
| | Program Headers | 1-7 |
| | Program Data Elements | 1-9 |
| | Character Program Data (CPD) | 1-9 |
| | Numeric Program Data | 1-9 |
| | String Program Data | 1-10 |
| | Program Response Elements | 1-11 |
| | Character Response Data (CRD) | 1-11 |
| | Numeric Response Data | 1-11 |
| | String Response Data | 1-12 |
| | Command Types | 1-13 |
| | Set/Query Commands | 1-13 |
| | Action Only Commands | 1-13 |
| | Query Only Commands | 1-14 |
| | Beginning a Session | 1-15 |
| | Linux | 1-15 |
| | Windows | 1-15 |
| Chapter 2 | Common Remote Commands | 2-1 |
| | General | 2-2 |
| | *CLS | 2-2 |
| | *ESE | 2-2 |

| | | |
|------------------|---|------------|
| | *ESE? | 2-2 |
| | *ESR? | 2-2 |
| | *IDN? | 2-3 |
| | *OPC | 2-3 |
| | *OPC? | 2-4 |
| | *RST | 2-4 |
| | *SRE | 2-4 |
| | *SRE? | 2-5 |
| | *STB? | 2-5 |
| | *WAI | 2-5 |
| Chapter 3 | Configuration Remote Commands | 3-1 |
| | Configuration Remote Command List | 3-2 |
| | Configuration Remote Command Descriptions | 3-3 |
| | CONFigure:BACKlight <var> | 3-3 |
| | CONFigure:BACKlight? | 3-3 |
| | CONFigure:DATE <var> | 3-3 |
| | CONFigure:DATE? | 3-4 |
| | CONFigure:DISK:AVAILable? | 3-4 |
| | CONFigure:DISK:TOTal? | 3-4 |
| | CONFigure:MEMory:AVAILable? | 3-4 |
| | CONFigure:MEMory:TOTal? | 3-5 |
| | CONFigure:OTIME? | 3-5 |
| | CONFigure:SDCard:FORMat | 3-5 |
| | CONFigure:TCALibration | 3-5 |
| | CONFigure:TEMPeratures? | 3-6 |
| | CONFigure:TIME <var> | 3-6 |
| | CONFigure:TIME? | 3-6 |
| | CONFigure:VERSions? | 3-7 |
| Chapter 4 | Options Remote Commands | 4-1 |
| | Options Remote Command List | 4-2 |
| | Options Remote Commands | 4-2 |
| | OPTions:LIST? | 4-2 |
| | OPTions:UID? | 4-2 |
| Chapter 5 | Simulation Remote Commands | 5-1 |
| | Command List | 5-2 |
| | Simulation Remote Command Descriptions | 5-3 |
| | RALTimeter:ASIMulation:CHANnel1:ActualALTitude? | 5-4 |
| | RALTimeter:ASIMulation:MANual:CHANnel1:ALTitude <var> | 5-4 |
| | RALTimeter:ASIMulation:MANual:CHANnel1:ALTitude? | 5-4 |
| | RALTimeter:ASIMulation:MANual:CHANnel1:RATE <var> | 5-5 |

| | | |
|------------------|--|------------|
| | RALTimer:ASIMulation:MANual:CHANnel1:RATE? | 5-5 |
| | RALTimer:ASIMulation:MANual:CHANnel1:START <var> | 5-5 |
| | RALTimer:ASIMulation:MANual:CHANnel1:START? | 5-6 |
| | RALTimer:ASIMulation:MANual:CHANnel1:STOP <var> | 5-6 |
| | RALTimer:ASIMulation:MANual:CHANnel1:STOP? | 5-6 |
| | RALTimer:ASIMulation:MODE <var> | 5-6 |
| | RALTimer:ASIMulation:MODE? | 5-7 |
| | RALTimer:ASIMulation:PROFile:CHANnel1:DATA <var> | 5-7 |
| | RALTimer:ASIMulation:PROFile:CHANnel1:DATA? | 5-7 |
| | RALTimer:ASIMulation:PROFile:CHANnel1:MODified? | 5-8 |
| | RALTimer:ASIMulation:PROFile:CHANnel1:NAME? | 5-8 |
| | RALTimer:ASIMulation:PROFile:CHANnel1:RECall <var> | 5-8 |
| | RALTimer:ASIMulation:PROFile:CHANnel1:STORE <var> | 5-8 |
| | RALTimer:ASIMulation:PROFile:COUNt? | 5-9 |
| | RALTimer:ASIMulation:PROFile:DELeTe <var> | 5-9 |
| | RALTimer:ASIMulation:PROFile:DURation? | 5-9 |
| | RALTimer:ASIMulation:PROFile:LIST? | 5-9 |
| Chapter 6 | Calibration Remote Commands | 6-1 |
| | Calibration Remote Command List | 6-3 |
| | Calibration Command Descriptions | 6-6 |
| | RALTimer:CALibration:ABORT | 6-6 |
| | RALTimer:CALibration:RCW:ADC? | 6-6 |
| | RALTimer:CALibration:RCW:NEXT? | 6-6 |
| | RALTimer:CALibration:RCW:PROMpt:FREQuency? | 6-6 |
| | RALTimer:CALibration:RCW:PROMpt:POWer? | 6-7 |
| | RALTimer:CALibration:RCW:SAVE | 6-7 |
| | RALTimer:CALibration:RCW:START | 6-7 |
| | RALTimer:CALibration:RCW:STEP:CURRent? | 6-7 |
| | RALTimer:CALibration:RCW:STEP:TOTal? | 6-8 |
| | RALTimer:CALibration:RPULse:ADC? | 6-8 |
| | RALTimer:CALibration:RPULse:NEXT? | 6-8 |
| | RALTimer:CALibration:RPULse:PROMpt? | 6-8 |
| | RALTimer:CALibration:RPULse:SAVE | 6-9 |
| | RALTimer:CALibration:RPULse:START | 6-9 |
| | RALTimer:CALibration:RPULse:STEP:CURRent? | 6-9 |
| | RALTimer:CALibration:RPULse:STEP:TOTal? | 6-9 |
| | RALTimer:CALibration:TCXO:SAVE | 6-10 |
| | RALTimer:CALibration:TCXO:START | 6-10 |
| | RALTimer:CALibration:TCXO:VALue <var> | 6-10 |
| | RALTimer:CALibration:TCXO:VALue? | 6-10 |
| | RALTimer:CALibration:RFDMCAL:STEP:NEXT? | 6-11 |

RALTimer:CALibration:RFDMCAL:STEP:CUR? 6-11

RALTimer:CALibration:RFDMCAL:START 6-11

RALTimer:CALibration:RFDMCAL:SAVE 6-11

RALTimer:CALibration:RFDMCAL:SET:COILDELAY <real64> 6-12

RALTimer:CALibration:RFDMCAL:SET:COILLOSS <real64> 6-12

RALTimer:CALibration:USER:ACTive? 6-12

RALTimer:CALibration:USER:START 6-12

RALTimer:CALibration:VATTenuator:ACTive? 6-13

RALTimer:CALibration:VATTenuator:COMPLete? 6-13

RALTimer:CALibration:VATTenuator:START 6-13

RALTimer:CDATa:RCW:DATE? 6-13

RALTimer:CDATa:RCW:VALid? 6-14

RALTimer:CDATa:RPULse:DATE? 6-14

RALTimer:CDATa:RPULse:VALid? 6-14

RALTimer:CDATa:TCXO:DATE? 6-14

RALTimer:CDATa:TCXO:VALid? 6-15

RALTimer:CDATa:TRANsmit:DATE? 6-15

RALTimer:CDATa:TRANsmit:VALid? 6-15

RALTimer:CDATa:USER:DATA? 6-15

RALTimer:CDATa:USER:DATE? 6-16

RALTimer:CDATa:USER:VALid? 6-16

RALTimer:CDATa:VATTenuator:DATE? 6-16

RALTimer:CDATa:VATTenuator:VALid? 6-16

Chapter 7 Diagnostic Remote Commands 7-1

Diagnostic Remote Command List 7-4

Diagnostic Remote Command Descriptions 7-8

RALTimer:DIAGnostics:LOOPback:FREQuency <var> 7-8

RALTimer:DIAGnostics:LOOPback:FREQuency? 7-8

RALTimer:DIAGnostics:LOOPback:GAIN <var> 7-8

RALTimer:DIAGnostics:LOOPback:GAIN? 7-8

RALTimer:DIAGnostics:LOOPback:MEASure <var> 7-9

RALTimer:DIAGnostics:LOOPback:MEASure? 7-9

RALTimer:DIAGnostics:LOOPback:OUTPut <var> 7-9

RALTimer:DIAGnostics:LOOPback:OUTPut? 7-9

RALTimer:DIAGnostics:LOOPback:POWer? 7-10

RALTimer:DIAGnostics:LOOPback:RANalog <var> 7-10

RALTimer:DIAGnostics:LOOPback:RANalog? 7-10

RALTimer:DIAGnostics:LOOPback:RX0 <var> 7-10

RALTimer:DIAGnostics:LOOPback:RX0? 7-10

RALTimer:DIAGnostics:LOOPback:SPA? 7-11

RALTimer:DIAGnostics:LOOPback:TANalog <var> 7-11

| | |
|--|------|
| RALTimer:DIAGnostics:LOOPback:TANalog? | 7-11 |
| RALTimer:DIAGnostics:LOOPback:TX0 <var> | 7-11 |
| RALTimer:DIAGnostics:LOOPback:TX0? | 7-11 |
| RALTimer:DIAGnostics:LOOPback:TX1 <var> | 7-12 |
| RALTimer:DIAGnostics:LOOPback:TX1? | 7-12 |
| RALTimer:DIAGnostics:LOOPback:TX2 <var> | 7-12 |
| RALTimer:DIAGnostics:LOOPback:TX2? | 7-12 |
| RALTimer:DIAGnostics:PASSthrough:DDS0 <var> | 7-13 |
| RALTimer:DIAGnostics:PASSthrough:DDS0? | 7-13 |
| RALTimer:DIAGnostics:PASSthrough:DDS1 <var> | 7-13 |
| RALTimer:DIAGnostics:PASSthrough:DDS1? | 7-13 |
| RALTimer:DIAGnostics:PASSthrough:FREQuency <var> | 7-14 |
| RALTimer:DIAGnostics:PASSthrough:FREQuency? | 7-14 |
| RALTimer:DIAGnostics:PASSthrough:GAIN <var> | 7-14 |
| RALTimer:DIAGnostics:PASSthrough:GAIN? | 7-14 |
| RALTimer:DIAGnostics:PASSthrough:POWer? | 7-14 |
| RALTimer:DIAGnostics:PASSthrough:RANalog <var> | 7-15 |
| RALTimer:DIAGnostics:PASSthrough:RANalog? | 7-15 |
| RALTimer:DIAGnostics:PASSthrough:RUN <var> | 7-15 |
| RALTimer:DIAGnostics:PASSthrough:RUN? | 7-15 |
| RALTimer:DIAGnostics:PASSthrough:RX0 <var> | 7-16 |
| RALTimer:DIAGnostics:PASSthrough:RX0? | 7-16 |
| RALTimer:DIAGnostics:PASSthrough:SPA? | 7-16 |
| RALTimer:DIAGnostics:PASSthrough:TANalog <var> | 7-16 |
| RALTimer:DIAGnostics:PASSthrough:TANalog? | 7-16 |
| RALTimer:DIAGnostics:PASSthrough:TX0 <var> | 7-17 |
| RALTimer:DIAGnostics:PASSthrough:TX0? | 7-17 |
| RALTimer:DIAGnostics:PASSthrough:TX1 <var> | 7-17 |
| RALTimer:DIAGnostics:PASSthrough:TX1? | 7-17 |
| RALTimer:DIAGnostics:PASSthrough:TX2 <var> | 7-18 |
| RALTimer:DIAGnostics:PASSthrough:TX2? | 7-18 |
| RALTimer:DIAGnostics:RECeive:ATTenuation <var> | 7-18 |
| RALTimer:DIAGnostics:RECeive:ATTenuation? | 7-18 |
| RALTimer:DIAGnostics:RECeive:GAIN <var> | 7-19 |
| RALTimer:DIAGnostics:RECeive:GAIN? | 7-19 |
| RALTimer:DIAGnostics:RECeive:MEASure <var> | 7-19 |
| RALTimer:DIAGnostics:RECeive:MEASure? | 7-19 |
| RALTimer:DIAGnostics:RECeive:POWer? | 7-20 |
| RALTimer:DIAGnostics:TATTenuator:FREQuency <var> | 7-20 |
| RALTimer:DIAGnostics:TATTenuator:FREQuency? | 7-20 |
| RALTimer:DIAGnostics:TATTenuator:OUTPut | 7-20 |
| RALTimer:DIAGnostics:TATTenuator:OUTPut? | 7-21 |

RALTimer:DIAGnostics:TATTenuator:TX0 7-21

RALTimer:DIAGnostics:TATTenuator:TX0? 7-21

RALTimer:DIAGnostics:TATTenuator:TX1 7-21

RALTimer:DIAGnostics:TATTenuator:TX1? 7-21

RALTimer:DIAGnostics:TATTenuator:TX2 7-22

RALTimer:DIAGnostics:TATTenuator:TX2? 7-22

RALTimer:DIAGnostics[:TRANsmit]:FREQUency <var> 7-22

RALTimer:DIAGnostics[:TRANsmit]:FREQUency? 7-22

RALTimer:DIAGnostics[:TRANsmit]:LEVel <var> 7-23

RALTimer:DIAGnostics[:TRANsmit]:LEVel? 7-23

RALTimer:DIAGnostics[:TRANsmit]:MODE <var> 7-23

RALTimer:DIAGnostics[:TRANsmit]:MODE? 7-23

RALTimer:DIAGnostics[:TRANsmit]:OUTPut <var> 7-24

RALTimer:DIAGnostics[:TRANsmit]:OUTPut? 7-24

RALTimer:DIAGnostics[:TRANsmit]:PRF <var> 7-24

RALTimer:DIAGnostics[:TRANsmit]:PRF? 7-24

RALTimer:DIAGnostics[:TRANsmit]:PWIDth <var> 7-25

RALTimer:DIAGnostics[:TRANsmit]:PWIDth? 7-25

Chapter 8 Setup Remote Commands..... 8-1

General 8-3

Setup Remote Commands List 8-3

Setup Remote Commands Description 8-5

RALTimer:OSETup:DISPlay:FREQUency <var> 8-5

RALTimer:OSETup:DISPlay:FREQUency? 8-5

RALTimer:OSETup:DISPlay:POWEr <var> 8-5

RALTimer:OSETup:DISPlay:POWEr? 8-6

RALTimer:OSETup:DISPlay:PUNits <var> 8-6

RALTimer:OSETup:DISPlay:PUNits? 8-6

RALTimer:SETup:AID:MODE <var> 8-6

RALTimer:SETup:AID:MODE? 8-7

RALTimer:SETup:AID:VALue <var> 8-7

RALTimer:SETup:AID:VALue? 8-7

RALTimer:SETup:CHANnel1:LEVel <var> 8-7

RALTimer:SETup:CHANnel1:LEVel? 8-8

RALTimer:SETup:CHANnel1:LLOSs <var> 8-8

RALTimer:SETup:CHANnel1:LLOSs? 8-8

RALTimer:SETup:CHANnel1:LOSS:CABLe:RX <var> 8-8

RALTimer:SETup:CHANnel1:LOSS:CABLe:RX? 8-9

RALTimer:SETup:CHANnel1:LOSS:CABLe:TX <var> 8-9

RALTimer:SETup:CHANnel1:LOSS:CABLe:TX? 8-9

RALTimer:SETup:CHANnel1:LOSS:COUPler:RX <var> 8-9

RALTimer:SETup:CHANnel1:LOSS:COUPler:RX? 8-10
RALTimer:SETup:CHANnel1:LOSS:COUPler:TX <var> 8-10
RALTimer:SETup:CHANnel1:LOSS:COUPler:TX? 8-10
RALTimer:SETup:CHANnel1:LOSS:EXTErnal:RX <var> 8-10
RALTimer:SETup:CHANnel1:LOSS:EXTErnal:RX? 8-11
RALTimer:SETup:CHANnel1:LOSS:EXTErnal:TX <var> 8-11
RALTimer:SETup:CHANnel1:LOSS:EXTErnal:TX? 8-11
RALTimer:SETup:CHANnel1:OFFSet <var> 8-11
RALTimer:SETup:CHANnel1:OFFSet? 8-12
RALTimer:SETup:CONNEction <var> 8-12
RALTimer:SETup:CONNEction? 8-12
RALTimer:SETup:LEVel:MODE <var> 8-12
RALTimer:SETup:LEVel:MODE? 8-13
RALTimer:SETup:LEVel:OFFSet <var> 8-13
RALTimer:SETup:LEVel:OFFSet? 8-13
RALTimer:SETup:UNITs:ALTitude <var> 8-14
RALTimer:SETup:UNITs:ALTitude ? 8-14
RALTimer:SETup:UNITs:DISTance <var> 8-14
RALTimer:SETup:UNITs:DISTance? 8-15
RALTimer:SETup:UUT:TYPE? <var> 8-15
RALTimer:SETup:UUT:TYPE? 8-15

Chapter 9 Settings Storage Remote Commands 9-1

General 9-2
Settings Remote Commands List 9-2
Settings Remote Commands Description 9-3
RALTimer:SETTings:CHANnel1:DEFault 9-3
RALTimer:SETTings:CHANnel1:MODified? 9-3
RALTimer:SETTings:CHANnel1:NAME? 9-3
RALTimer:SETTings:CHANnel1:RECall <var> 9-3
RALTimer:SETTings:CHANnel1:STORe <var> 9-4
RALTimer:SETTings:COUNT? 9-4
RALTimer:SETTings:DELeTe <var> 9-4
RALTimer:SETTings:LIST? 9-4

Chapter 10 Status Remote Commands 10-1

General 10-2
Status Remote Commands List 10-2
Status Remote Commands Description 10-3
RALTimer:STATus:CHANnel1:UNLock:ALL? 10-3
RALTimer:STATus:CHANnel1:UNLock:OVERall? 10-3

| | | |
|-------------------|---|-------------|
| Chapter 11 | Test Remote Commands | 11-1 |
| | General | 11-2 |
| | Test Remote Commands List | 11-2 |
| | Test Remote Commands Description | 11-3 |
| | RALTimer:TEST:PAUSe | 11-3 |
| | RALTimer:TEST:PAUSed? | 11-3 |
| | RALTimer:TEST:RESume | 11-3 |
| | RALTimer:TEST:RUNNing? | 11-3 |
| | RALTimer:TEST:STARt | 11-4 |
| | RALTimer:TEST:STOP | 11-4 |
| | RALTimer:MEASure:CHANnel1:DATA? | 11-4 |
| | RALTimer:MEASure:CHANnel1:LEVel? | 11-4 |
| | RALTimer:MEASure:CHANnel1:MARGin? | 11-5 |
| | RALTimer:MEASure:CHANnel1:STALe? | 11-5 |
| Chapter 12 | System Remote Commands | 12-1 |
| | System Remote Commands List | 12-2 |
| | System Remote Commands Description | 12-2 |
| | SYSTem:ERRor[:NEXT]? | 12-2 |
| | SYSTem:ERRor:ALL? | 12-2 |
| | SYSTem:ERRor:CODE[:NEXT]? | 12-3 |
| | SYSTem:ERRor:COUNT? | 12-3 |
| | SYSTem:ERRor:GLOBal? | 12-3 |
| | SYSTem:VERSion? | 12-3 |
| Chapter 13 | Self Test Remote Commands | 13-1 |
| | Self Test Remote Commands List | 13-2 |
| | Self Test Remote Commands Description | 13-2 |
| | HHSelftest:RALTimer:DCVoltage? | 13-2 |
| | HHSelftest:RALTimer:TEMPerature? | 13-3 |
| | HHSelftest:RALTimer:LPOWER? | 13-3 |
| | HHSelftest:RALTimer:PLOCK? | 13-3 |
| | HHSelftest:RALTimer:RDATtenuator? | 13-4 |
| | HHSelftest:RALTimer:RAATtenuator? | 13-4 |
| | HHSelftest:RALTimer:GSTage? | 13-4 |
| | HHSelftest:RALTimer:T0Dattenuator? | 13-5 |
| | HHSelftest:RALTimer:T1Dattenuator? | 13-5 |
| | HHSelftest:RALTimer:T2Dattenuator? | 13-5 |
| | HHSelftest:RALTimer:TAATtenuator? | 13-6 |
| | HHSelftest:RALTimer:FREQuency? | 13-6 |
| | HHSelftest:RALTimer:rfDMAMps? | 13-6 |
| | HHSelftest:RALTimer:rfDMATens? | 13-6 |
| | HHSelftest:RALTimer:ALLStatus? | 13-7 |

| | | |
|-------------------|-----------------------------|------------|
| | HHSelftest:RUN? | 13-7 |
| Appendix A | RST Settings | A-1 |
| | *RST Settings | A-2 |
| Appendix B | Error Handling | B-1 |
| | Remote Control Errors | B-2 |
| | RALT:CAL:USER:STAR | B-2 |
| | RALT:CAL:VATT:STAR | B-2 |
| | RALT:TEST:STAR | B-3 |

Introduction

| | |
|---------------------------------|------|
| • Introduction | 1-3 |
| • General Information | 1-3 |
| • SCPI Structure | 1-3 |
| • Command Guidelines | 1-5 |
| • Command Short and Long Form | 1-5 |
| • Case Sensitivity | 1-5 |
| • Command Punctuation | 1-5 |
| • Arrow Brackets < > | 1-5 |
| • Choice Indicator | 1-5 |
| • Square Brackets [] | 1-6 |
| • Colon | 1-6 |
| • Semicolon | 1-6 |
| • Commas | 1-6 |
| • Program Headers | 1-7 |
| • Program Data Elements | 1-9 |
| • Character Program Data (CPD) | 1-9 |
| • Numeric Program Data | 1-9 |
| • Integer | 1-9 |
| • Decimal | 1-9 |
| • Binary | 1-9 |
| • Hexadecimal | 1-10 |
| • String Program Data | 1-10 |
| • Hex-string | 1-10 |
| • ASCII-string | 1-10 |
| • Program Response Elements | 1-11 |
| • Character Response Data (CRD) | 1-11 |
| • Numeric Response Data | 1-11 |
| • Integer | 1-11 |

- Decimal 1-11
- Binary 1-11
- Hexadecimal 1-12
- String Response Data 1-12
 - Hex-string 1-12
 - ASCII-string 1-12
- Command Types 1-13
 - Set/Query Commands 1-13
 - Set Commands 1-13
 - Query Commands 1-13
 - Action Only Commands 1-13
 - Query Only Commands 1-14
- Beginning a Session 1-15
 - Linux 1-15
 - Windows 1-15

All SCPI commands are based on a hierarchical tree structure consisting of keywords and parameters. Associated commands are grouped together under a common node in the hierarchy.

In the command tree the command on the left (A) is the root command. A tree pointer is used to decode the SCPI commands. On power up the pointer is at the root command




Figure 1-2

All SCPI commands are terminated by a line feed (0x0A). After termination the pointer is returned to the root.

Command Guidelines

The following guidelines should be followed when writing remote commands.

Command Short and Long Form

The elements of compound and query headers have a long and a short form, as defined by SCPI. Either the long or the short form may be entered as a command; other abbreviations are not permissible.

The short form is marked by upper case letters.

Long form corresponds to spelling out commands as complete words. Uppercase and lowercase syntax identify long form.

Queries always return the short form, or a numeric response in cases where the command provides a choice of numeric or character data.

Case Sensitivity

As indicated in the section titled [Command Short and Long Form](#), ALT-9000 remote commands are not case sensitive. Upper and lowercase characters are completely interchangeable.

Example:

AFCounter1:AVERage 100 is interpreted the same as AFC1:AVER 100

Command Punctuation

Arrow Brackets < >

Text within angle brackets represents an actual value that needs to be inserted in the command string. For example, <n> or <x> indicate a variable that must be inserted in the command at this point.

Example:

AFCounter<n>:AVERage 100

<n> must be defined with a valid value as follows: AFCounter1:AVERage
100

Choice Indicator

The vertical bar (|) separates a choice of parameters or commands. For example, 0 | 1 means '0 or 1.'

Square Brackets []

Square brackets [] indicate optional variables that do not need to be included in the command string, such as units of measurement.

Colon

A colon moves the current path down one level in the command tree. For example the colon in SYSTEM:MODE specifies MODE is one level below SYSTEM. When the colon is the first character of a command, it specifies that it is a root level command, e.g. :SYSTEM specifies that SYSTEM is a root level command.

Semicolon

A semicolon separates two commands in the same message without changing the command pointer.

For example, referencing the tree above:

```
:A:B:E;F;G
```

This is the same as sending the three messages:

```
:A:B:E
```

```
:A:B:F
```

```
:A:B:G
```

Commas

If a command requires more than one parameter, you must use a comma to separate adjacent parameters. Commas do not affect the command pointer. To execute a command the full path to it must be specified.

e.g. :SYSTem:FADing:STATe ON

would turn fading on for simulation. Note that there must be a space between the command and the parameters.

In addition a node can be default node and these keywords are optional when using the command, the instrument will process the command to have the same effect whether the option node is omitted or not. This is denoted in throughout this manual by square brackets [].

e.g. RALTimer:DIAGnostics:TRANsmi:LEVel?

```
RALTimer:DIAGnostics:LEVel?
```

Program Headers

Program headers are keywords that identify the command. There are two types of headers, common command and instrument control. Instruments do not distinguish between upper and lower case.

The common command syntax is:

*<PROGRAM MNEMONIC>

These are used to control and extract data from the instrument. The instrument control syntax is:

:<MNEMONIC>

:<MNEMONIC><PARAMETER>

Most SCPI commands can be queried. A query is a command header with a question mark (?) appended to it. When a query command is received, the current settings associated with the command are placed into the output buffer. Execution of the query will have no effect on the operation of the instrument

Queries have the syntax:

*<PROGRAM MNEMONIC>?For common command

:<MNEMONIC>?For instrument control

The parameter field of a command can contain several different types of data. These are explained in the subsections below.

The errors can be read by issuing the following command:

:SYSTem:ERRor?

The response consists of an error number followed by a string that describes the error. When the Error Queue is empty the instrument responds with:

0,"No error"

Querying the error clears the storage location in the error buffer.

Table 1-1

| Command | Description |
|---------|---|
| *CLS | Clears the status and event registers. |
| *ESE | Standard Event Status Enable Register. |
| *ESE? | Returns the Standard Event Status Enable Register. |
| *ESR? | Returns the contents of the Standard Events Status. |
| *IDN? | Return Identity. |
| *OPC | Set bit 0 of the Standard Event Status Register when it completes all pending operations. Since there are no overlapped commands this will always return immediately. |
| *OPC? | Output '1' when pending operations complete. |
| *OPT? | Identify any reportable device options.* |
| *RST | System Reset. |

| | |
|-------|---|
| *SRE | Service Request Enable. |
| *SRE? | Returns contents of Service Request Enable. |
| *STB? | Status Byte Register. |
| *TST? | Self Test.* |
| *WAI | Wait until all pending operations complete. Since there are no overlapped commands this will always return immediately. |

* Not supported.

Program Data Elements

ALT-9000 Remote programming commands use the following data program elements:

Character Program Data (CPD)

Character Program Data is used to define a parameter best described as a short alpha or alphanumeric string.

Example:

AUD1

DEMod

Numeric Program Data

ALT-9000 Remote programming commands use the following numeric program elements:

Integer

Variable is numeric and does not contain a defined decimal point.

Example:

10

175

Decimal

Variable is numeric and does contain a defined decimal point.

Example:

12.5

825.0625

Binary

Variable is in binary format. Binary values are preceded with #b or #B.

Example:

#B1010

#B10101111

Hexadecimal

Variable is in hexadecimal format. Hexadecimal values are preceded with #h or #H.

Example:

#H3E8

#H1D4C

String Program Data

String program data consists of a number of ASCII characters enclosed in quotes. Use either pairs of single (ASCII 39) or double (ASCII 34) quotes, but do not mix single and double in a string. A quote within a string must be enclosed within an extra pair of quotes.

Example:

'This string contains the word 'Hello' '

is interpreted as

This string contains the word 'Hello'

and

"This string contains the word "Hello" "

is interpreted as

This string contains the word "Hello"

Hex-string

Uses characters 0-9 and A-F to produce hex pairs representing values from 0 to 255. There are no white spaces within the string.

ASCII-string

Example:

"Script File Test 1" which refers to the file being loaded.

Program Response Elements

ALT-9000 Remote programming commands use the following formats for response data:

Character Response Data (CRD)

Variable is returned as a short alpha or alphanumeric string.

Example:

DEM

AUD1

Numeric Response Data

ALT-9000 Remote programming commands use the following numeric response elements:

Integer

Variable is numeric and does not contain a defined decimal point.

Example:

10

175

Decimal

Variable is numeric and does contain a defined decimal point.

Example:

12.5

825.0625

Binary

Variable is in binary format. Binary values are preceded with #B.

Example:

#B1010

#B10101111

Hexadecimal

Variable is in hexadecimal format. Hexadecimal values are preceded with #H.

Example:

#H3E8

#H1D4C

String Response Data

This takes a similar form to String Program Data except that the delimiting character is always a double quote ("ASCII34").

Hex-string

Returns characters 0-9 and A-F to produce hex pairs representing values within specified parameter range. There are no white spaces within the string.

ASCII-string

Example:

"Call in progress."

Command Types

Set/Query Commands

The majority of the commands used within the ALT-9000's remote command structure support set and query functionality.

Set Commands

Set commands define a parameter.

Example:

```
RALTimer:SETup:AID:MODE FIXed
```

The Set Command defines the type of AID to use.

Query Commands

Query commands use the same command structure as the set command, but contain a '?' at the end of the command string instead of a variable.

Example:

```
RALTimer:SETup:CHANnel1:LEVel 50
```

```
RALTimer:SETup:CHANnel1:LEVel?
```

The Set Command sets the power level to 50 dBm. The Query Command returns the current power level.

Action Only Commands

Action only commands initiate a specific function or action. These commands do not require parameters and can not be queried. Typical use of Action Only commands is to clear average or peak readings and to move markers on the instrument tiles and measurement graph tiles.

Example:

```
RALTimer:TEST:START
```

Command starts a simulation. Command does not require a parameter, nor can it be queried.

Query Only Commands

Query only commands return information only. These commands do not define parameters. Measurement query commands or status commands are the main use of query only commands. All query commands must include a '?' at the end of the command string.

Example:

RALTimeter:TEST:RUNNing?

Query command returns if simulation is running.

Some commands that are used to define a parameter can also be used as a query command by adding a '?' to the end of the command.

| | |
|-------------|--|
| NOTE | Query response always returns short form. For example, VARiable and FIXed are returned as VAR and FIX. |
|-------------|--|

Beginning a Session

To begin a session, telnet into the ALT-9000 using port 5025.

Linux

Telnet is provided on most Linux distributions. If the ALT-9000 has an IP address of 192.168.0.0, the command to begin a session would be: `telnet 192.168.0.0 5025`

Windows

A suitable program needs to be installed to allow telnet access. PUTTY is one program that works well in conjunction with Windows.

In PUTTY configuration, on the terminal page, select 'implicit CR in every LF'.

In PUTTY session page, enter the IP address, set port to 5025 and click telnet, then click open.




Figure 1-3 PUTTY setup options screen




Figure 1-4 PuTTY setup basic options screen

Common Remote Commands

- General 2-2
 - *CLS 2-2
 - *ESE 2-2
 - *ESE? 2-2
 - *ESR? 2-2
 - *IDN? 2-3
 - *OPC 2-3
 - *OPC? 2-4
 - *RST 2-4
 - *SRE 2-4
 - *SRE? 2-5
 - *STB? 2-5
 - *WAI 2-5

General

The following are IEEE mandated Remote Commands supported by the ALT-9000.

*CLS

Parameters: None
Description: Clear Status clears the Standard Event Status Register, the Error Queue, the Operation Status Event Register and the Questionable Status Event Register.
Example: *CLS
Clear the status reporting structure.

*ESE

Parameters: Mask
Valid values: Mask: integer. Valid values are 0 to 255. Values outside range are rejected and an error generated.
Description: The Standard Event Status Enable command sets the Standard Event Status Enable Register. This is an eight bit register.
Example: *ESE 1
Set the Standard Event Status Enable Register to 1 (00000001 in binary). This will allow OPC (Operation Complete) messages generated by the instrument to be reported in the Event Summary Bit. (OPC is issued by the instrument when an overlapped command completes and a *OPC command has been received).

*ESE?

Parameters: None
Response: Mask
Returned values: Mask: integer. Values are in the range 0 to 255.
Description: Read the Standard Event Status Enable Register. This is an eight bit register.
Example: *ESE?

*ESR?

Parameters: None
Response: Register contents
Returned values: Register contents: integer. Values are in the range 0 to 255.
Description: Read the value of the Standard Event Status Register. This is an eight bit register.
Example: *ESR?

*IDN?

- Parameters:** None
- Response:** Instrument Identification
- Returned values:** Instrument Identification: string
- Description:** The Identification Query command allows information about the instrument to be read.
The Instrument Identification is split into five fields:
 Manufacturer
 Model
 Serial number
 Software Issue No.
 Software build date
- Manufacturer returns name of manufacture
- Model returns the instrument model number ALT-9000.
- Serial number is in the form ssssssssss (10 digits) where s is an ASCII digit in the range 0 to 9.
- Software Issue No. is in the form n.n.n where n are numbers in the range 0 to 99. Software build date is YYYYMMDDHHMM
- Example:** *IDN?
Read information on the instrument.
- Example response:** Aeroflex, ALT-9000, 104000139, 2.5.0, 201409091525

*OPC

- Parameters:** None
- Description:** The Operation Complete command sets the Operation Complete bit in the Standard Event Status Register when execution of all overlapped commands have completed.
- This command is really only useful after an overlapped command when it will indicate when that command has been completed. Other (non-overlapped) commands can be executed whilst the overlapped command is still being executed. If there is more than one overlapped command being executed, the Operation Complete bit will only be set once all of the overlapped commands complete.
- Example:** *OPC
Since there are no overlapped commands in the instrument, the Operation Complete bit will be set in the Standard Event Status Register immediately.
- *OPC should be the final <PROGRAM MESSAGE UNIT> of the <PROGRAM MESSAGE>.

*OPC?

Parameters: None

Response: Operation complete

Returned values: Operation complete: integer. Value is 1

Description: The Operation Complete Query returns a '1' when all overlapped commands have completed.

This command is really only useful after an overlapped command when it will indicate when that command has been completed.

*OPC? should be the final <QUERY MESSAGE UNIT> of the <PROGRAM MESSAGE>.

Example: *OPC?

Since there are no overlapped commands in the instrument, the value '1' will be placed in the output queue immediately.

*RST

Parameters: None

Description: Reset the instrument. This command places the instrument in its default state. This is the same state as when the instrument is first powered on. Appendix A lists reset settings and which parameters are not reset.

Example: *RST

Reset instrument to known state.

*SRE

Parameters: Mask

Valid values: Mask: integer. Valid values are 0 to 255. Values outside range are rejected and an error generated.

Description: Set the Service Request Enable Register. This is an eight bit register.

Example: *SRE 32

Set the Service Request Enable Register to 32 (0010 0000 in binary) to enable service requests when the Standard Event Status Register Summary Bit is set.

*SRE?

Parameters: None
Response: Mask
Returned values: Mask: integer. Values are in the range 0 to 255.
Description: Read the Service Request Enable Register. This is an eight bit register.
Example: *SRE?

*STB?

Parameters: None
Response: Status byte
Returned values: Status byte: integer. Values are in the range 0 to 255.
Description: Read the Status Byte Register. This is an eight bit register. Bit 6 of the register contains the Master Summary Status. See Appendix A for details.
Example: *STB?

*WAI

Parameters: None
Description: The Wait to Continue command inhibits execution of a command until the execution of all overlapped commands has been completed.

This command is really only useful after an overlapped command when it will hold off further commands until that command has been completed. If there is more than one overlapped command being executed, the next command will be held off until all of the overlapped commands complete.
Example: *WAI
Since there are no overlapped commands in the instrument, *WAI will complete immediately.

This page intentionally left blank.

Configuration Remote Commands

- Configuration Remote Command List 3-2
- Configuration Remote Command Descriptions 3-3
 - CONFigure:BACKlight <var>..... 3-3
 - CONFigure:BACKlight? 3-3
 - CONFigure:DATE <var> 3-3
 - CONFigure:DATE? 3-4
 - CONFigure:DISK:AVAILable? 3-4
 - CONFigure:DISK:TOTal? 3-4
 - CONFigure:MEMory:AVAILable? 3-4
 - CONFigure:MEMory:TOTal? 3-5
 - CONFigure:OTIME? 3-5
 - CONFigure:SDCard:FORMat 3-5
 - CONFigure:TCALibration 3-5
 - CONFigure:TEMPeratures? 3-6
 - CONFigure:TIME <var> 3-6
 - CONFigure:TIME? 3-6
 - CONFigure:VERSions?..... 3-7

Configuration Remote Command List

:CONFigure
 :BACKlight
 :BACKlight?
 :DATE
 :DATE?
 :DISK
 :AVailable?
 :TOTal?
 :MEMory
 :AVailable?
 :TOTal?
 :OTIME?
 :SDCard
:FORMat
 :TCALibration
 :TEMPeratures?
 :TIME
 :TIME?
:VERSions?

Configuration Remote Command Descriptions

The set of CONFigure remote commands control the ALT-9000 configuration.

CONFigure:BACKlight <var>

| | |
|--------------------|---------------------------------------|
| Description | Sets Test Set's LCD backlight. |
| Parameter | Integer Percentage of backlight |
| Range | 0 - 100 |
| Example | CONF:BACK 50 Sets backlight to 50% |

CONFigure:BACKlight?

| | |
|---------------------|--------------------------------------|
| Description | Returns LCD backlight value |
| Return Value | Integer Backlight as a percentage |
| Example | CONF:BACK? 50 |

CONFigure:DATE <var>

| | |
|--------------------|---|
| Description | Sets Test Set's internal calendar. |
| Parameter | Date, string, formatted as "YYYY/MM/DD" |
| Range | NA |
| Example | CONF:DATE "2013/09/12" Sets internal calendar to September 12, 2013. |

CONFigure:DATE?

| | |
|---------------------|-------------------------------|
| Description | Returns current date setting. |
| Return Value | YYYY/MM/DD |
| Example | CONF:DATE? 2013/09/12 |

CONFigure:DISK:AVAlable?

| | |
|---------------------|---|
| Description | Amount of space available on the SD card. |
| Return Value | Integer - in bytes |
| Example | CONF:DISK:AVA? 3354368000 |

CONFigure:DISK:TOTal?

| | |
|---------------------|---|
| Description | Total amount of space available on the SD card. |
| Return Value | Integer - in bytes |
| Example | CONF:DISK:TOT? 3557776000 |

CONFigure:MEMory:AVAlable?

| | |
|---------------------|---------------------------|
| Description | Amount of RAM available. |
| Return Value | Integer - in bytes |
| Example | CONF:MEM:AVA? 14036000 |

CONFigure:MEMory:TOTal?

| | |
|---------------------|----------------------------|
| Description | Total amount of RAM. |
| Return Value | Integer - in bytes |
| Example | CONF:MEM:TOT? 124936000 |

CONFigure:OTIME?

| | |
|---------------------|--------------------------------------|
| Description | Length of time the unit has been on. |
| Return Value | Integer - in seconds |
| Example | CONF:OTIM? 1240 |

CONFigure:SDCard:FORMat

| | |
|--------------------|---|
| Description | Formats the SD card. This will erase user data. |
| Parameter | NA |
| Range | NA |
| Example | CONF:SDC:FORM |

CONFigure:TCAibration

| | |
|--------------------|--|
| Description | Touch Screen Calibration will be run on next boot. |
| Parameter | NA |
| Range | NA |
| Example | CONF:TICAL |

CONFigure:TEMPeratures?

| | |
|---------------------|--|
| Description | Returns temperatures of system hardware in Celsius. |
| Return Value | ascii string |
| Example | CONF:TEMP? "RF Temperature Off (Temp Invalid!): 0,0;Power Supply Temperature: 35.0;Battery Temp Off (Temp Invalid!): 0.0;Slot 1 MIC284 Temperature: 38.0;Slot 1 OMAP Temperature: 49.8;Digital Board Temperature: 31.8" |

CONFigure:TIME <var>

| | |
|--------------------|--|
| Description | Sets Test Set's internal clock. |
| Parameter | String time |
| Range | HH:MM:SS (24 Hour format) |
| Example | CONF:TIME "19:25:44" Sets internal clock to 7:25:44 PM. |

CONFigure:TIME?

| | |
|---------------------|---------------------------|
| Description | Returns internal time. |
| Return Value | HH:MM:SS (24 Hour format) |
| Example | CONF:TIME? 19:25:44 |

CONFigure:VERsions?

| | |
|---------------------|---|
| Description | Returns hardware version information. |
| Return Value | ascii string |
| Example | CONF:VERS? "RF Card ID:139047 (8015);RF Card Revision: 4;RF Firmware Version: 1.02.00;Digital Board Card ID: 92879;Digital Board Card Revision: 1;Digital Board Firmware Version: 1.05.03;Slot 1 Actel PCI FPGA version: 1.0.03 12-14-2010;Slot 1 Control Board Revision: 1;Slot 1 Actel JTAG CPLD version: 1.0.04 11-19-2010;Power Supply Version: 1.00.08" |

This page intentionally left blank.

Options Remote Commands

- Options Remote Command List 4-2
- Options Remote Commands 4-2
 - OPTions:LIST? 4-2
 - OPTions:UID? 4-2

Options Remote Command List

- :OPTions
- :LIST?
- :UID?

Options Remote Commands

The following are Options Remote Commands for the ALT-9000.

OPTions:LIST?

| | |
|---------------------|--|
| Description | Returns a list of options enabled on the Test Set. |
| Return Value | String data, comma delimited |
| Example | OPT:LIST? ALT9000,ALL,1,-1, |

OPTions:UID?

| | |
|---------------------|---|
| Description | Returns the Test Set's unique ID. |
| Return Value | Alphanumeric (hexadecimal), 12 characters |
| Example | OPT:UID? d4b417000000 |

Simulation Remote Commands

| | |
|---|-----|
| • Command List | 5-2 |
| • Simulation Remote Command Descriptions | 5-3 |
| • RALTimer:ASIMulation:CHANnel1:ActualALTitude? | 5-4 |
| • RALTimer:ASIMulation:MANual:CHANnel1:ALTitude <var> | 5-4 |
| • RALTimer:ASIMulation:MANual:CHANnel1:ALTitude? | 5-4 |
| • RALTimer:ASIMulation:MANual:CHANnel1:RATE <var> | 5-5 |
| • RALTimer:ASIMulation:MANual:CHANnel1:RATE? | 5-5 |
| • RALTimer:ASIMulation:MANual:CHANnel1:START <var> | 5-5 |
| • RALTimer:ASIMulation:MANual:CHANnel1:START? | 5-6 |
| • RALTimer:ASIMulation:MANual:CHANnel1:STOP <var> | 5-6 |
| • RALTimer:ASIMulation:MANual:CHANnel1:STOP? | 5-6 |
| • RALTimer:ASIMulation:MODE <var> | 5-6 |
| • RALTimer:ASIMulation:MODE? | 5-7 |
| • RALTimer:ASIMulation:PROFile:CHANnel1:DATA <var> | 5-7 |
| • RALTimer:ASIMulation:PROFile:CHANnel1:DATA? | 5-7 |
| • RALTimer:ASIMulation:PROFile:CHANnel1:MODified? | 5-8 |
| • RALTimer:ASIMulation:PROFile:CHANnel1:NAME? | 5-8 |
| • RALTimer:ASIMulation:PROFile:CHANnel1:RECall <var> | 5-8 |
| • RALTimer:ASIMulation:PROFile:CHANnel1:STORe <var> | 5-8 |
| • RALTimer:ASIMulation:PROFile:COUNT? | 5-9 |
| • RALTimer:ASIMulation:PROFile:DELeTe <var> | 5-9 |
| • RALTimer:ASIMulation:PROFile:DURation? | 5-9 |
| • RALTimer:ASIMulation:PROFile:LIST? | 5-9 |

Command List

:RALTimer
:ASIMulation
:CHANnel1 :
ActualALTitude?
:MANual
:CHANnel1
:ALTitude
:ALTitude?
:RATE
:RATE?
:STARt
:STARt?
:STOP
:STOP?
:MODE
:MODE ?
:PROFile
 :CHANnel1
 :DATA
 :DATA?
 :MODified?
 :NAME?
 :RECall
 :STORE
:RALTimer
:ASIMulation
:PROFile (cont)
 :COUNt?
 :DELeTe
 :DURation?
 :LIST?

Simulation Remote Command Descriptions

The set of ASIMulation remote commands control the ALT-9000 altitude simulation.

There are three ways that the altitude simulation can be set up:

A single altitude.

A single ramp from one altitude to another at a fixed rate.

A sequence of single altitude/ramped altitude legs.

The first two of these are performed in manual mode. To select manual mode send
RALT:ASIM:MAN:CHAN1:MODE MAN.

To setup a single altitude, set the rate to zero and set the start altitude to the required altitude.

Example for 250 ft:

```
RALT:ASIM:MAN:CHAN1:RATE 0  
RALT:ASIM:MAN:CHAN1:STAR 250
```

To setup a single ramp, set the rate, then set the start and stop altitudes.

Example:

```
RALT:ASIM:MAN:CHAN1:RATE 300  
RALT:ASIM:MAN:CHAN1:STAR 100  
RALT:ASIM:MAN:CHAN1:STOP 400
```

The ramp from 100 ft to 400 ft will take exactly one minute at a rate of 300 ft/min.

To run a sequence of legs it is first necessary to create a profile and select it. The first leg of the profile is shown on the screen and the manual rate, start and stop query commands will return the current data (leg 1 when not running).

RALTimer:ASIMulation:CHANnel1:ActualALTitude?

| | |
|----------------------|---|
| Description | Returns the Simulated Actual Altitude while running a simulation. |
| Return Value: | Altitude in Feet, Integers 0 to 10000 without option ALT-9000OPT1 Note: Additional altitudes of 16000 & 25000 feet with option ALT-9000OPT1 |
| Example | RALT:ASIM:CHAN1:AALT? 1000 |

RALTimer:ASIMulation:MANual:CHANnel1:ALTitude <var>

| | |
|--------------------|--|
| Description | Sets the simulated altitude. Can only set while running a simulation in Manual Mode and test paused. Used for static altitude entry. |
| Parameter | Altitude in Feet. |
| Range | Integers -20 to 8000. Values outside range are rejected and an error generated. |
| Example | :RALT:ASIM:MAN:CHAN1:ALT 1000 Set altitude simulation channel 1 altitude to 1000 feet. |

RALTimer:ASIMulation:MANual:CHANnel1:ALTitude?

| | |
|---------------------|--|
| Description | Returns the currently simulated altitude while running a simulation. |
| Return Value | Altitude in Feet, Integers -20 to 8000 feet |
| Example | :RALT:ASIM:MAN:CHAN1:ALT? 1000 |

RALTimer:ASIMulation:MANual:CHANnel1:RATE <var>

| | |
|--------------------|--|
| Description | Sets the simulated altitude rate. Can only be set in Manual Mode when a simulation is not running. |
| Parameter | Altitude Rate in ft/min. |
| Range | Integers 0 to 120000. Values outside range are rejected and an error generated. Set 0 for static altitude. Note: When simulating a linear ramp, RATE parameter must be set before START or STOP altitude parameters. |
| Example | :RAL:ASIM:MAN:CHAN1:RATE 1000 Set altitude simulation channel 1 altitude rate to 1000 ft/min. |

RALTimer:ASIMulation:MANual:CHANnel1:RATE?

| | |
|---------------------|--|
| Description | Returns the simulated altitude rate. |
| Return Value | Altitude Rate in ft/min, Integer 1 to 120000 |
| Example | :RAL:ASIM:MAN:CHAN1:RATE? 1000 |

RALTimer:ASIMulation:MANual:CHANnel1:START <var>

| | |
|--------------------|---|
| Description | Sets the simulated start altitude. Used for creating a linear altitude ramp or a fixed altitude. Can only be set in Manual mode when a simulation is not running. |
| Parameter | Altitude in Feet. |
| Range | Integers -20 to 8000. Values outside range are rejected and an error generated. Note: When simulating a linear ramp, RATE parameter must be set before START or STOP altitude parameters. |
| Example | :RAL:ASIM:MAN:CHAN1:START 550 Set altitude simulation channel 1 start altitude to 550 feet. |

RALTimer:ASIMulation:MANual:CHANnel1:START?

| | |
|---------------------|--|
| Description | Returns the simulated start altitude. |
| Return Value | Altitude in Feet, Integers -20 to 8000 feet. |
| Example | :RAL:ASIM:MAN:CHAN1:START? 550 |

RALTimer:ASIMulation:MANual:CHANnel1:STOP <var>

| | |
|--------------------|---|
| Description | Sets the simulated stop altitude. Used for creating a linear altitude ramp. Can only be set in Manual Mode when a simulation is not running. |
| Parameter | Altitude in Feet. |
| Range | Integers -20 to 8000. Values outside range are rejected and an error generated. Note: When simulating a linear ramp, RATE parameter must be set before START or STOP altitude parameters.. |
| Example | :RAL:ASIM:MAN:CHAN1:STOP 2500 Set altitude simulation channel 1 stop altitude to 2500 feet. |

RALTimer:ASIMulation:MANual:CHANnel1:STOP?

| | |
|---------------------|--|
| Description | Returns the simulated stop altitude. |
| Return Value | Altitude in Feet, Integer between -20 and 5500 feet. |
| Example | :RAL:ASIM:MAN:CHAN1:STOP? 2500 |

RALTimer:ASIMulation:MODE <var>

| | |
|--------------------|---|
| Description | Sets Manual (linear altitude ramp mode) or Profile (multi-leg altitude mode). |
| Parameter | Enumeration |
| Range | MANual or PROFile |
| Example | :RAL:ASIM:MODE MAN Manual altitude mode selected. |

RALTimer:ASIMulation:PROFile:CHANnel1:MODified?

| | |
|---------------------|--|
| Description | Returns if the profile has been modified or not. |
| Return Value | 0 = profile not modified, 1 = profile modified |
| Example | :RAL:ASIM:PROF:CHAN1:MOD? 1 |

RALTimer:ASIMulation:PROFile:CHANnel1:NAME?

| | |
|---------------------|--|
| Description | Returns the current profile name.. |
| Return Value | Alpha Numeric 1 to 20 characters |
| Example | :RAL:ASIM:PROF:CHAN1:NAME? "Profile1" Note: If the profile has been modified an asterisk will be added, e.g. "Profile1*" |

RALTimer:ASIMulation:PROFile:CHANnel1:RECall <var>

| | |
|--------------------|---|
| Description | Recalls a named profile. Becomes the current profile. |
| Parameter | String |
| Range | Alpha Numeric 1 to 20 characters. |
| Example | :RAL:ASIM:PROF:CHAN1:REC "my Profile" Recall file my Profile |

RALTimer:ASIMulation:PROFile:CHANnel1:STORe <var>

| | |
|--------------------|---|
| Description | Stores the current profile under file name |
| Parameter | String |
| Range | Up to 20 Alpha Numeric Characters including Space |
| Example | :RAL:ASIM:PROF:CHAN1:STORE "B-747-400 Autoland" Save profile as B-747-400 Autoland |

RALTimer:ASIMulation:PROFile:COUNT?

| | |
|---------------------|-------------------------------------|
| Description | Returns a count of stored profiles. |
| Return Value | Integer |
| Example | :RALT:ASIM:PROF:COUN? 4 |

RALTimer:ASIMulation:PROFile:DELeTe <var>

| | |
|--------------------|--|
| Description | Deletes the named profile. |
| Parameter | String |
| Range | Alpha Numeric 1 to 20 Characters including Space |
| Example | :RALT:ASIM:PROF:DEL "B-747-400 Autoland" Delete profile B-747-400 Autoland from disk. |

RALTimer:ASIMulation:PROFile:DURation?

| | |
|---------------------|--|
| Description | Returns the current profile duration in minutes. |
| Return Value | Integer in minutes |
| Example | :RALT:ASIM:PROF:DUR? 10 |

RALTimer:ASIMulation:PROFile:LIST?

| | |
|---------------------|--|
| Description | Returns a list of stored profile file names. |
| Return Value | Comma separated string |
| Example | :RALT:ASIM:PROF:LIST? "myProfile","B-747-400Autoland" |

This page intentionally left blank.

Calibration Remote Commands

| | |
|---|------|
| • Calibration Remote Command List | 6-3 |
| • Calibration Command Descriptions | 6-6 |
| • RALTimer:CALibration:ABORT | 6-6 |
| • RALTimer:CALibration:RCW:ADC? | 6-6 |
| • RALTimer:CALibration:RCW:NEXT? | 6-6 |
| • RALTimer:CALibration:RCW:PROMpt:FREQuency? | 6-6 |
| • RALTimer:CALibration:RCW:PROMpt:POWEr? | 6-7 |
| • RALTimer:CALibration:RCW:SAVE | 6-7 |
| • RALTimer:CALibration:RCW:START | 6-7 |
| • RALTimer:CALibration:RCW:STEP:CURRent? | 6-7 |
| • RALTimer:CALibration:RCW:STEP:TOTal? | 6-8 |
| • RALTimer:CALibration:RPULse:ADC? | 6-8 |
| • RALTimer:CALibration:RPULse:NEXT? | 6-8 |
| • RALTimer:CALibration:RPULse:PROMpt? | 6-8 |
| • RALTimer:CALibration:RPULse:SAVE | 6-9 |
| • RALTimer:CALibration:RPULse:START | 6-9 |
| • RALTimer:CALibration:RPULse:STEP:CURRent? | 6-9 |
| • RALTimer:CALibration:RPULse:STEP:TOTal? | 6-9 |
| • RALTimer:CALibration:TCXO:SAVE | 6-10 |
| • RALTimer:CALibration:TCXO:START | 6-10 |
| • RALTimer:CALibration:TCXO:VALue <var> | 6-10 |
| • RALTimer:CALibration:TCXO:VALue? | 6-10 |
| • RALTimer:CALibration:RFDMCAL:STEP:NEXT? | 6-11 |
| • RALTimer:CALibration:RFDMCAL:STEP:CUR? | 6-11 |
| • RALTimer:CALibration:RFDMCAL:START | 6-11 |
| • RALTimer:CALibration:RFDMCAL:SAVE | 6-11 |
| • RALTimer:CALibration:RFDMCAL:SET:COILDELAY <real64> | 6-12 |

- RALTimer:CALibration:RDFMCAL:SET:COILLOSS <real64> 6-12
- RALTimer:CALibration:USER:ACTIve? 6-12
- RALTimer:CALibration:USER:STARt 6-12
- RALTimer:CALibration:VATTenuator:ACTIve? 6-13
- RALTimer:CALibration:VATTenuator:COMPLete? 6-13
- RALTimer:CALibration:VATTenuator:STARt 6-13
- RALTimer:CDATa:RCW:DATE? 6-13
- RALTimer:CDATa:RCW:VALId? 6-14
- RALTimer:CDATa:RPULse:DATE? 6-14
- RALTimer:CDATa:RPULse:VALId? 6-14
- RALTimer:CDATa:TCXO:DATE? 6-14
- RALTimer:CDATa:TCXO:VALId? 6-15
- RALTimer:CDATa:TRANsmit:DATE? 6-15
- RALTimer:CDATa:TRANsmit:VALId? 6-15
- RALTimer:CDATa:USER:DATA? 6-15
- RALTimer:CDATa:USER:DATE? 6-16
- RALTimer:CDATa:USER:VALId? 6-16
- RALTimer:CDATa:VATTenuator:DATE? 6-16
- RALTimer:CDATa:VATTenuator:VALId? 6-16

Calibration Remote Command List

RFDMCAL (Added)

:RALTimer

:CALibration
:ABORt
:RCW
:ADC?
:NEXT?
:PROMpt
:FREQuency?
:POWer?
:SAVE
:START
:STEP
:CURRent?
:TOTal?

:RALTimer

:CALibration (cont)
:RPULse
:ADC?
:NEXT?
:PROMpt?
:SAVE
:START
:STEP
:CURRent?
:TOTal?
:TCXO
:SAVE
:START
:VALue
:VALue?
:TRANsmit

:NEXT?
:PROMpt
:FREQUency?
:POWER?
:SGENERator?
:TATTenuator?
:RATTenuator
:SAVE
:START
:STEP
:CURRent?
:TOTal?
:TATTenuator
:RALTimeter
:CALibration (cont)
:USER
:ACTive?
:START
:VATTenuator
:ACTive?
:COMPLete?
:START
:RFDMCAL
:STEP
:NEXT?
:CURRENT?
:CUR?
:START
:SAVE
:SET:
COILDELAY <real64>
COILLOSS <real64>
:CDATa

:RCW
:DATE?
:VALid?
:RPULse
:DATE?
:VALid?
:TCXO
:DATE?
:VALid?
:TRANsmit
:DATE?
:VALid?
:USER
:DATA?
:DATE?
:VALid?
:VATTenuator
:DATE?
:VALid?

Calibration Command Descriptions

The set of CALibration Remote Commands control the ALT-9000 calibration.

RALTimer:CALibration:ABORt

| | |
|--------------------|---------------------------------|
| Description | Aborts the factory calibration. |
| Parameter | NA |
| Range | NA |
| Example | :RALT:CAL:ABOR |

RALTimer:CALibration:RCW:ADC?

| | |
|---------------------|------------------------------------|
| Description | Returns the Receiver CW ADC value. |
| Return Value | ADC value |
| Example | :RALT:CAL:RCW:ADC? 1500 |

RALTimer:CALibration:RCW:NEXT?

| | |
|---------------------|--|
| Description | Proceeds to the next Receiver CW calibration step. |
| Return Value | Returns 0 when command has completed. |
| Example | :RALT:CAL:RCW:NEXT? 0 |

RALTimer:CALibration:RCW:PROMpt:FREQuency?

| | |
|---------------------|--|
| Description | Returns current Receiver CW calibration frequency. |
| Return Value | Frequency in MHz |
| Example | :RALT:CAL:RCW:PROM:FREQ? 4100 |

RALTimer:CALibration:RCW:PROMpt:POWer?

| | |
|---------------------|--|
| Description | Returns current Receiver CW calibration frequency. |
| Return Value | Power in dBm |
| Example | :RALT:CAL:RCW:PROM:POW? 10 |

RALTimer:CALibration:RCW:SAVE

| | |
|--------------------|--|
| Description | Saves the Receiver CW calibration value. Can only be issued if all steps have been completed. |
| Parameter | NA |
| Range | NA |
| Example | :RALT:CAL:RCW:SAVE |

RALTimer:CALibration:RCW:START

| | |
|--------------------|---|
| Description | Starts the Receiver CW factory calibration. |
| Parameter | NA |
| Range | NA |
| Example | :RALT:CAL:RCW:STAR |

RALTimer:CALibration:RCW:STEP:CURRent?

| | |
|---------------------|---|
| Description | Returns the current Receiver CW calibration step. |
| Return Value | Current step number |
| Example | :RALT:CAL:RCW:STEP:CURR? 1 |

RALTimer:CALibration:RCW:STEP:TOTal?

| | |
|---------------------|---|
| Description | Returns the total number of steps in the Receiver CW calibration. |
| Return Value | Total number of steps in the calibration |
| Example | :RALT:CAL:RCW:STEP:TOT? 11 |

RALTimer:CALibration:RPULse:ADC?

| | |
|---------------------|---------------------------------------|
| Description | Returns the Receiver Pulse ADC value. |
| Return value | ADC value |
| Example | :RALT:CAL:RPUL:ADC? 1500 |

RALTimer:CALibration:RPULse:NEXT?

| | |
|---------------------|---|
| Description | Proceeds to the next Receiver Pulse calibration step. |
| Return value | Returns 0 when command has completed. |
| Example | :RALT:CAL:RPUL:NEXT? 0 |

RALTimer:CALibration:RPULse:PROMpt?

| | |
|---------------------|--|
| Description | Returns the pulse width. |
| Return value | 75, 300, or 0. 0 means siggen RF off. |
| Example | :RALT:CAL:RPUL:PROM? 75 |

RALTimer:CALibration:RPULse:SAVE

| | |
|--------------------|---|
| Description | Saves the Receiver Pulse calibration value. Can only be issued if all steps have been completed. |
| Parameter | NA |
| Range | NA |
| Example | :RALT:CAL:RPUL:SAVE |

RALTimer:CALibration:RPULse:START

| | |
|--------------------|--|
| Description | Starts the Receiver Pulse factory calibration. |
| Parameter | NA |
| Range | NA |
| Example | :RALT:CAL:RPUL:STAR |

RALTimer:CALibration:RPULse:STEP:CURRent?

| | |
|---------------------|--|
| Description | Returns the current Receiver Pulse calibration step. |
| Return value | Current step number |
| Example | :RALT:CAL:RPUL:STEP:CURR? 1 |

RALTimer:CALibration:RPULse:STEP:TOTal?

| | |
|---------------------|--|
| Description | Returns the total number of steps in the Receiver Pulse calibration. |
| Return value | Total number of steps in the calibration |
| Example | :RALT:CAL:RPUL:STEP:TOT? 11 |

RALTimer:CALibration:TCXO:SAVE

| | |
|--------------------|--|
| Description | Saves the Receiver TCXO calibration value. Can only be issued if all steps have been completed. |
| Parameter | NA |
| Range | NA |
| Example | :RAL:CAL:TCXO:SAVE |

RALTimer:CALibration:TCXO:START

| | |
|--------------------|---|
| Description | Starts the Receiver TCXO factory calibration. |
| Parameter | NA |
| Range | NA |
| Example | :RAL:CAL:TCXO:STAR |

RALTimer:CALibration:TCXO:VALue <var>

| | |
|--------------------|-----------------------|
| Description | Sets the TCXO value. |
| Parameter | Integer |
| Range | 0-1023 |
| Example | :RAL:CAL:TCXO:VAL 512 |

RALTimer:CALibration:TCXO:VALue?

| | |
|---------------------|-----------------------------|
| Description | Returns current TCXO value. |
| Return value | Integer |
| Example | :RAL:CAL:TCXO:VAL? 512 |

RALTimer:CALibration:RFDMCAL:STEP:NEXT?

| | |
|---------------------|---|
| Description | Returns the next step number in the RFDM calibration. |
| Return value | Integer. |
| Example | :RAL:CAL:RFDMCAL:STEP:NEXT? 11 |

RALTimer:CALibration:RFDMCAL:STEP:CUR?

| | |
|---------------------|--|
| Description | Returns the current step number in the RFDM calibration. |
| Return value | Integer. |
| Example | :RAL:CAL:RFDMCAL:STEP:CUR? 11 |

RALTimer:CALibration:RFDMCAL:START

| | |
|--------------------|--------------------------------------|
| Description | Starts the RFDM factory calibration. |
| Parameter | NA |
| Range | NA |
| Example | :RAL:CAL:RFDMCAL:STAR |

RALTimer:CALibration:RFDMCAL:SAVE

| | |
|--------------------|---|
| Description | Saves the RFDM calibration value. Can only be issued if all steps have been completed. |
| Parameter | NA |
| Range | NA |
| Example | :RAL:CAL:RFDMCAL:SAVE |

RALTimer:CALibration:RDFMCAL:SET:COILDELAY <real64>

| | |
|--------------------|-------------------------------------|
| Description | Sets the delay for a specific coil |
| Parameter: | Real |
| Range: | Value in ns - No limits |
| Example | :RAL:CAL:RDFMCAL:SET:COILDELAY 42.7 |

RALTimer:CALibration:RDFMCAL:SET:COILLOSS <real64>

| | |
|--------------------|---|
| Description | Sets the loss value for a specific coil |
| Parameter: | Real |
| Range: | Value in nB - No limits |
| Example | :RAL:CAL:RDFMCAL:SET:COILLOSS 3.57 |

RALTimer:CALibration:USER:ACTive?

| | |
|---------------------|--|
| Description | Returns value indicating if Delay calibration is actively running. |
| Return Value | 0 = not active, 1 = active |
| Example | :RAL:CAL:USER:ACT? 0 |

RALTimer:CALibration:USER:STARt

| | |
|------------------------|------------------------------|
| Description | Starts the Delay calibration |
| Parameter range | NA |
| Example | :RAL:CAL:USER:STAR |

RALTimer:CALibration:VATTenuator:ACTive?

| | |
|---------------------|--|
| Description | Returns a value indicating whether the loopback calibration is actively running. |
| Return Value | 0 = not active, 1 = active |
| Example | :RALT:CAL:VATT:ACT? 0 |

RALTimer:CALibration:VATTenuator:COMplete?

| | |
|---------------------|---|
| Description | Returns a value indicating how much of the loopback calibration is completed. |
| Return Value | 0 - 100 percent |
| Example | :RALT:CAL:VATT:COMP? 42 |

RALTimer:CALibration:VATTenuator:STARt

| | |
|------------------------|----------------------------------|
| Description | Starts the Loopback calibration. |
| Parameter range | NA |
| Example | :RALT:CAL:VATT:STAR |

RALTimer:CDATa:RCW:DATE?

| | |
|---------------------|---|
| Description | Returns data and time of the last RX CW calibration. |
| Return Value | Comma separated time and date |
| Example | :RALT:CDAT:RCW:DATE? 10,32,55,2014,7,30 Shows time 10:32:55, Date July 30, 2014 |

RALTimer:CDATa:RCW:VALid?

| | |
|---------------------|---|
| Description | Indicates if RX CW calibration is valid or invalid. |
| Return Value | 1 = Valid, 0 = Invalid |
| Example | :RALT:CDAT:RCW:VAL? 1 |

RALTimer:CDATa:RPULse:DATE?

| | |
|---------------------|--|
| Description | Returns date and time of the last RX Pulse calibration. |
| Return Value | Comma separated time and date |
| Example | :RALT:CDAT:RPUL:DATE? 10,32,55,2014,7,30 Shows time 10:32:55, Date July 30, 2014 |

RALTimer:CDATa:RPULse:VALid?

| | |
|---------------------|--|
| Description | Indicates if RX Pulse calibration is valid or invalid. |
| Return Value | 1 = Valid, 0 = Invalid |
| Example | :RALT:CDAT:RPUL:VAL? 1 |

RALTimer:CDATa:TCXO:DATE?

| | |
|---------------------|--|
| Description | Returns date and time of the last TCXO calibration. |
| Return Value | Comma separated time and date |
| Example | :RALT:CDAT:TCXO:DATE? 10,32,55,2014,7,30 Shows time 10:32:55, Date July 30, 2014 |

RALTimer:CDAT:TCXO:VALid?

| | |
|---------------------|--|
| Description | Indicates if TXCO calibration is valid or invalid. |
| Return Value | 1 = Valid, 0 = Invalid |
| Example | :RALT:CDAT:TCXO:VAL? 1 |

RALTimer:CDAT:TRANsmit:DATE?

| | |
|---------------------|--|
| Description | Returns date and time of the last TX calibration. |
| Return Value | Comma separated time and date |
| Example | :RALT:CDAT:TRAN:DATE? 10,32,55,2014,7,30 Shows time 10:32:55, Date July 30, 2014 |

RALTimer:CDAT:TRANsmit:VALid?

| | |
|---------------------|--|
| Description | Indicates if TX calibration is valid or invalid. |
| Return Value | 1 = Valid, 0 = Invalid |
| Example | :RALT:CDAT:TRAN:VAL? 1 |

RALTimer:CDAT:USER:DATA?

| | |
|---------------------|--|
| Description | Returns the delay calibration values. |
| Return Value | Returns 2 integers, FMCW value first, then Pulse value (in ns) |
| Example | :RALT:CDAT:USER:DATA? 77, 77 |

RALTimer:CDATa:USER:DATE?

| | |
|---------------------|---|
| Description | Returns date and time of the last delay calibration. |
| Return Value | Comma separated time and date |
| Example | :RAL:CDAT:USER:DATE? 10,32,55,2014,7,30 Shows time 10:32:55, Date July 30, 2014 |

RALTimer:CDATa:USER:VALid?

| | |
|---------------------|---|
| Description | Indicates if delay calibration is valid or invalid. |
| Return Value | 1 = Valid, 0 = Invalid |
| Example | :RAL:CDAT:USER:VAL? 1 |

RALTimer:CDATa:VATTenuator:DATE?

| | |
|---------------------|---|
| Description | Returns date and time of the last loopback calibration. |
| Return Value | Comma separated time and date |
| Example | :RAL:CDAT:VATT:DATE? 10,32,55,2014,7,30 Shows time 10:32:55, Date July 30, 2014 |

RALTimer:CDATa:VATTenuator:VALid?

| | |
|---------------------|--|
| Description | Indicates if delay loopback is valid or invalid. |
| Return Value | 1 = Valid, 0 = Invalid |
| Example | :RAL:CDAT:VATT:VAL? 1 |

Diagnostic Remote Commands

- Diagnostic Remote Command List 7-4
- Diagnostic Remote Command Descriptions 7-8
 - RALTimer:DIAGnostics:LOOPback:FREQuency <var> 7-8
 - RALTimer:DIAGnostics:LOOPback:FREQuency? 7-8
 - RALTimer:DIAGnostics:LOOPback:GAIN <var> 7-8
 - RALTimer:DIAGnostics:LOOPback:GAIN? 7-8
 - RALTimer:DIAGnostics:LOOPback:MEASure <var> 7-9
 - RALTimer:DIAGnostics:LOOPback:MEASure? 7-9
 - RALTimer:DIAGnostics:LOOPback:OUTPut <var> 7-9
 - RALTimer:DIAGnostics:LOOPback:OUTPut? 7-9
 - RALTimer:DIAGnostics:LOOPback:POWer? 7-10
 - RALTimer:DIAGnostics:LOOPback:RANalog <var> 7-10
 - RALTimer:DIAGnostics:LOOPback:RANalog? 7-10
 - RALTimer:DIAGnostics:LOOPback:RX0 <var> 7-10
 - RALTimer:DIAGnostics:LOOPback:RX0? 7-10
 - RALTimer:DIAGnostics:LOOPback:SPA? 7-11
 - RALTimer:DIAGnostics:LOOPback:TANalog <var> 7-11
 - RALTimer:DIAGnostics:LOOPback:TANalog? 7-11
 - RALTimer:DIAGnostics:LOOPback:TX0 <var> 7-11
 - RALTimer:DIAGnostics:LOOPback:TX0? 7-11
 - RALTimer:DIAGnostics:LOOPback:TX1 <var> 7-12
 - RALTimer:DIAGnostics:LOOPback:TX1? 7-12
 - RALTimer:DIAGnostics:LOOPback:TX2 <var> 7-12
 - RALTimer:DIAGnostics:LOOPback:TX2? 7-12
 - RALTimer:DIAGnostics:PASSthrough:DDS0 <var> 7-13
 - RALTimer:DIAGnostics:PASSthrough:DDS0? 7-13
 - RALTimer:DIAGnostics:PASSthrough:DDS1 <var> 7-13

- RALTimer:DIAGnostics:PASSthrough:DDS1? 7-13
- RALTimer:DIAGnostics:PASSthrough:FREQuency <var> 7-14
- RALTimer:DIAGnostics:PASSthrough:FREQuency? 7-14
- RALTimer:DIAGnostics:PASSthrough:GAIN <var> 7-14
- RALTimer:DIAGnostics:PASSthrough:GAIN? 7-14
- RALTimer:DIAGnostics:PASSthrough:POWEr? 7-14
- RALTimer:DIAGnostics:PASSthrough:RANalog <var> 7-15
- RALTimer:DIAGnostics:PASSthrough:RANalog? 7-15
- RALTimer:DIAGnostics:PASSthrough:RUN <var> 7-15
- RALTimer:DIAGnostics:PASSthrough:RUN? 7-15
- RALTimer:DIAGnostics:PASSthrough:RX0 <var> 7-16
- RALTimer:DIAGnostics:PASSthrough:RX0? 7-16
- RALTimer:DIAGnostics:PASSthrough:SPA? 7-16
- RALTimer:DIAGnostics:PASSthrough:TANalog <var> 7-16
- RALTimer:DIAGnostics:PASSthrough:TANalog? 7-16
- RALTimer:DIAGnostics:PASSthrough:TX0 <var> 7-17
- RALTimer:DIAGnostics:PASSthrough:TX0? 7-17
- RALTimer:DIAGnostics:PASSthrough:TX1 <var> 7-17
- RALTimer:DIAGnostics:PASSthrough:TX1? 7-17
- RALTimer:DIAGnostics:PASSthrough:TX2 <var> 7-18
- RALTimer:DIAGnostics:PASSthrough:TX2? 7-18
- RALTimer:DIAGnostics:RECeive:ATTenuation <var> 7-18
- RALTimer:DIAGnostics:RECeive:ATTenuation? 7-18
- RALTimer:DIAGnostics:RECeive:GAIN <var> 7-19
- RALTimer:DIAGnostics:RECeive:GAIN? 7-19
- RALTimer:DIAGnostics:RECeive:MEASure <var> 7-19
- RALTimer:DIAGnostics:RECeive:MEASure? 7-19
- RALTimer:DIAGnostics:RECeive:POWEr? 7-20
- RALTimer:DIAGnostics:TATTenuator:FREQuency <var> 7-20
- RALTimer:DIAGnostics:TATTenuator:FREQuency? 7-20
- RALTimer:DIAGnostics:TATTenuator:OUTPut 7-20
- RALTimer:DIAGnostics:TATTenuator:OUTPut? 7-21
- RALTimer:DIAGnostics:TATTenuator:TX0. 7-21
- RALTimer:DIAGnostics:TATTenuator:TX0?. 7-21
- RALTimer:DIAGnostics:TATTenuator:TX1. 7-21
- RALTimer:DIAGnostics:TATTenuator:TX1?. 7-21
- RALTimer:DIAGnostics:TATTenuator:TX2. 7-22
- RALTimer:DIAGnostics:TATTenuator:TX2?. 7-22
- RALTimer:DIAGnostics[:TRANsmit]:FREQuency <var> 7-22
- RALTimer:DIAGnostics[:TRANsmit]:FREQuency? 7-22
- RALTimer:DIAGnostics[:TRANsmit]:LEVel <var> 7-23
- RALTimer:DIAGnostics[:TRANsmit]:LEVel? 7-23

-
- RALTimer:DIAGnostics[:TRANsmit]:MODE <var>..... 7-23
 - RALTimer:DIAGnostics[:TRANsmit]:MODE?..... 7-23
 - RALTimer:DIAGnostics[:TRANsmit]:OUTPut <var>..... 7-24
 - RALTimer:DIAGnostics[:TRANsmit]:OUTPut?..... 7-24
 - RALTimer:DIAGnostics[:TRANsmit]:PRF <var> 7-24
 - RALTimer:DIAGnostics[:TRANsmit]:PRF?..... 7-24
 - RALTimer:DIAGnostics[:TRANsmit]:PWIDth <var>..... 7-25
 - RALTimer:DIAGnostics[:TRANsmit]:PWIDth?..... 7-25

Diagnostic Remote Command List

:RALTimer

:DIAGnostics

:LOOPback

:FREQuency

:FREQuency?

:GAIN

:GAIN?

:MEASure

:MEASure?

:OUTPut

:OUTPut?

:POWer?

:RANalog

:RANalog?

:RX0

:RX0?

:SPA?

:TANalog

:TANalog?

:TX0

:RALTimer

:DIAGnostics

:LOOPback (cont)

:TX0?

:TX1

:TX1?

:TX2

:TX2?

:PASSthrough

:DDS0

:DDS0?

:DDS1

:DDS1?

:FREQuency

:FREQuency?

:GAIN

:GAIN?

:POWER?

:RANalog

:RANalog?

:RUN

:RUN?

:RX0

:RX0?
:SPA?
:TANalog
:TANalog?
:TX0
:TX0?
:TX1
:TX1?
:TX2
:TX2?
:RALTimeter
:DIAGnostics
:RECeive
:ATTenuation
:ATTenuation?
:GAIN
:GAIN?
:MEASure
:MEASure?
:POWER?
:TATTenuator
:FREQuency
:FREQuency?
:OUTPut
:OUTPut?
:TX0
:TX0?
:TX1
:TX1?
:TX2
:TX2?
[:TRANsmit]
:FREQuency

:FREQuency?
:LEVeI
:LEVeI?
:MODE
:MODE?
:OUTPut
:OUTPut?
:RALTimer
:DIAGnostics
[:TRANsmit] (cont)
:PRF
:PRF?
:PWIDth
:PWIDth ?

Diagnostic Remote Command Descriptions

RALTimer:DIAGnostics:LOOPback:FREQuency <var>

Description Sets diagnostics Frequency

Parameter Frequency in MHz

Range Integer 4200 to 4400 MHz

Example RALT:DIAG:LOOP:FREQ 4315
Sets Frequency to 4315 MHz

RALTimer:DIAGnostics:LOOPback:FREQuency?

Description Returns set diagnostics Frequency in MHz

Parameter Integer 4200 to 4400 MHz

Example RALT:DIAG:LOOP:FREQ?
4300

RALTimer:DIAGnostics:LOOPback:GAIN <var>

Description Turn the receiver gain stage on or off

Parameter Enumeration - state

Range ON, OFF

Example RALT:DIAG:LOOP:GAIN ON
Sets Gain Stage to ON

RALTimer:DIAGnostics:LOOPback:GAIN?

Description Return the receiver gain stage setting

Return Value ON, OFF

Example RALT:DIAG:LOOP:GAIN?
OFF

RALTimer:DIAGnostics:LOOPback:MEASure <var>

| | |
|--------------------|--|
| Description | Starts or Stops receiver diagnostic measurements |
| Parameter | Boolean |
| Range | ON or 1 starts measurements OFF or 0 stops measurements |
| Example | RALT:DIAG:LOOP:MEAS ON Start receiver diagnostic measurements |

RALTimer:DIAGnostics:LOOPback:MEASure?

| | |
|---------------------|--|
| Description | Returns receiver diagnostics measurement state |
| Return Value | 1 or 0 |
| Example | RALT:DIAG:LOOP:MEAS? 1 |

RALTimer:DIAGnostics:LOOPback:OUTPut <var>

| | |
|--------------------|--|
| Description | Turn diagnostics RF output on or off |
| Parameter | Boolean |
| Range | ON or 1 starts signal output OFF or 0 stops signal output |
| Example | RALT:DIAG:LOOP:OUTP 0 Set diagnostics output to OFF |

RALTimer:DIAGnostics:LOOPback:OUTPut?

| | |
|---------------------|-------------------------------------|
| Description | Returns diagnostics RF output state |
| Return Value | 1 or 0 |
| Example | RALT:DIAG:LOOP:OUTP? 0 |

RALTimer:DIAGnostics:LOOPback:POWer?

Description Returns raw reading corresponding to receiver input power level in mV

Return Value Integer

Example RALT:DIAG:LOOP:POW?
1846

RALTimer:DIAGnostics:LOOPback:RANalog <var>

Description Set receive analog attenuator

Parameter Integer

Range 0 to 1023. Higher value sets higher attenuation.

Example RALT:DIAG:LOOP:RAN 800
Set receive analog attenuator

RALTimer:DIAGnostics:LOOPback:RANalog?

Description Returns set receive analog attenuation

Return Value Integer 0 to 1023

Example RALT:DIAG:LOOP:RAN?
88

RALTimer:DIAGnostics:LOOPback:RX0 <var>

Description Set 31.5dB receive digital attenuator RX0

Parameter Integer

Range 0 to 63, in half dB steps

Example RALT:DIAG:LOOP:RX0 40
Set receive digital attenuator RX0 to 20dB

RALTimer:DIAGnostics:LOOPback:RX0?

Description Returns set receive digital attenuation RX0

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:LOOP:RX0?
62

RALTimer:DIAGnostics:LOOPback:SPA?

Description Returns raw reading corresponding to SPA measured power level in mV

Return Value Integer

Example RALT:DIAG:LOOP:SPA?
986

RALTimer:DIAGnostics:LOOPback:TANalog <var>

Description Set transmit analog attenuator

Parameter Integer

Range 0 to 1023. Higher value sets higher attenuation.

Example RALT:DIAG:LOOP:TAN 800
Set transmit analog attenuator

RALTimer:DIAGnostics:LOOPback:TANalog?

Description Returns set transmit analog attenuation

Return Value Integer 0 to 1023

Example RALT:DIAG:LOOP:TAN?
88

RALTimer:DIAGnostics:LOOPback:TX0 <var>

Description Set 31.5dB transmit digital attenuator TX0

Parameter Integer

Range 0 to 63, in half dB steps

Example RALT:DIAG:LOOP:TX0 10
Set transmit digital attenuator TX0 to 5dB

RALTimer:DIAGnostics:LOOPback:TX0?

Description Returns set transmit digital attenuation TX0

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:LOOP:TX0?
6

RALTimer:DIAGnostics:LOOPback:TX1 <var>

Description Set 31.5dB transmit digital attenuator TX1

Parameter Integer

Range 0 to 63, in half dB steps

Example RALT:DIAG:LOOP:TX1 15
Set transmit digital attenuator TX1 to 7.5dB

RALTimer:DIAGnostics:LOOPback:TX1?

Description Returns set transmit digital attenuation TX1

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:LOOP:TX1?
18

RALTimer:DIAGnostics:LOOPback:TX2 <var>

Description Set 31.5dB transmit digital attenuator TX2

Parameter Integer

Range 0 to 63, in half dB steps

Example RALT:DIAG:LOOP:TX2 0
Set transmit digital attenuator TX2 to 0dB

RALTimer:DIAGnostics:LOOPback:TX2?

Description Returns set transmit digital attenuation TX2

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:LOOP:TX2?
8

RALTimer:DIAGnostics:PASSthrough:DDS0 <var>

- Description** For FMCW altimeters, changing the DDS value will change the simulated altitude. For all other altimeters, set this to zero. Generally DDS0 and DDS1 values will be set identically.
- Parameter** DDS offset in tenths of Hz (e.g. 142 is 14.2 Hz)
- Range** Integer -200 to 20000 (-20.0 Hz to 2000 Hz offset)
- Example** RALT:DIAG:PASS:DDS0 -47
Set DDS0 frequency offset to -4.7 Hz

RALTimer:DIAGnostics:PASSthrough:DDS0?

- Description** Returns set DDS0 frequency offset.
- Return Value** Integer -200 to 20000 (corresponding to -20.0 Hz to 2000 Hz)
- Example** RALT:DIAG:PASS:DDS0?
470

RALTimer:DIAGnostics:PASSthrough:DDS1 <var>

- Description** For FMCW altimeters, changing the DDS value will change the simulated altitude. For all other altimeters, set this to zero. Generally DDS0 and DDS1 values will be set identically.
- Parameter** DDS offset in tenths of Hz (e.g. 142 is 14.2 Hz)
- Range** Integer -200 to 20000 (-20.0 Hz to 2000 Hz offset)
- Example** RALT:DIAG:PASS:DDS1 -47
Set DDS1 frequency offset to -4.7 Hz

RALTimer:DIAGnostics:PASSthrough:DDS1?

- Description** Returns set DDS1 frequency offset.
- Return Value** Integer -200 to 20000 (corresponding to -20.0 Hz to 2000 Hz)
- Example** RALT:DIAG:PASS:DDS1?
471

RALTimer:DIAGnostics:PASSthrough:FREQuency <var>

| | |
|--------------------|--|
| Description | Sets diagnostics Frequency |
| Parameter | Frequency in MHz |
| Range | Integer 4200 to 4400 MHz |
| Example | RALT:DIAG:PASS:FREQ 4290 Sets Frequency to 4290 MHz |

RALTimer:DIAGnostics:PASSthrough:FREQuency?

| | |
|---------------------|--|
| Description | Returns set diagnostics Frequency in MHz |
| Return Value | Integer 4200 to 4400 MHz |
| Example | RALT:DIAG:PASS:FREQ? 4301 |

RALTimer:DIAGnostics:PASSthrough:GAIN <var>

| | |
|--------------------|---|
| Description | Turn the receiver gain stage on or off |
| Parameter | Enumeration - state |
| Range | ON, OFF |
| Example | RALT:DIAG:PASS:GAIN ON Sets Gain Stage to ON |

RALTimer:DIAGnostics:PASSthrough:GAIN?

| | |
|---------------------|--|
| Description | Return the receiver gain stage setting |
| Return Value | ON, OFF |
| Example | RALT:DIAG:PASS:GAIN? OFF |

RALTimer:DIAGnostics:PASSthrough:POWer?

| | |
|---------------------|---|
| Description | Returns raw reading corresponding to receiver input power level in mV |
| Return Value | Integer |
| Example | RALT:DIAG:PASS:POW? 971 |

RALTimer:DIAGnostics:PASSthrough:RANalog <var>

| | |
|--------------------|---|
| Description | Set receive analog attenuator |
| Parameter | Integer |
| Range | 0 to 1023. Higher value sets higher attenuation. |
| Example | RALT:DIAG:PASS:RAN 800 Set receive analog attenuator |

RALTimer:DIAGnostics:PASSthrough:RANalog?

| | |
|---------------------|--|
| Description | Returns set receive analog attenuation |
| Return Value | Integer 0 to 1023 |
| Example | RALT:DIAG:PASS:RAN? 88 |

RALTimer:DIAGnostics:PASSthrough:RUN <var>

| | |
|--------------------|--|
| Description | Start/Stop pass-through diagnostics |
| Parameter | Boolean |
| Range | ON or 1 starts signal output and measuring OFF or 0 stops signal output and measuring |
| Example | RALT:DIAG:PASS:RUN 0 Set diagnostics output/measuring to OFF |

RALTimer:DIAGnostics:PASSthrough:RUN?

| | |
|---------------------|---|
| Description | Returns diagnostics RF output/measuring state |
| Return Value | 1 or 0 |
| Example | RALT:DIAG:PASS:RUN? 0 |

RALTimer:DIAGnostics:PASSthrough:RX0 <var>

Description Set 31.5dB receive digital attenuator RX0

Parameter Integer

Range 0 to 63, in half dB steps

Example RALT:DIAG:PASS:RX0 40
Set receive digital attenuator RX0 to 20dB

RALTimer:DIAGnostics:PASSthrough:RX0?

Description Returns set receive digital attenuation RX0

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:PASS:RX0?
62

RALTimer:DIAGnostics:PASSthrough:SPA?

Description Returns raw reading corresponding to SPA measured power level in mV

Return Value Integer

Example RALT:DIAG:PASS:SPA?
1127

RALTimer:DIAGnostics:PASSthrough:TANalog <var>

Description Set transmit analog attenuator

Parameter Integer

Range 0 to 1023. Higher value sets higher attenuation.

Example RALT:DIAG:PASS:TAN 800
Set transmit analog attenuator

RALTimer:DIAGnostics:PASSthrough:TANalog?

Description Returns set transmit analog attenuation

Return Value Integer 0 to 1023

Example RALT:DIAG:PASS:TAN?
88

RALTimer:DIAGnostics:PASSthrough:TX0 <var>

Description Set 31.5dB transmit digital attenuator TX0

Parameter Integer

Range 0 to 63, in half dB steps

Example RALT:DIAG:PASS:TX0 30
Set transmit digital attenuator TX0 to 15dB

RALTimer:DIAGnostics:PASSthrough:TX0?

Description Returns set transmit digital attenuation TX0

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:PASS:TX0?
6

RALTimer:DIAGnostics:PASSthrough:TX1 <var>

Description Set 31.5dB transmit digital attenuator TX1

Parameter Integer

Range 0 to 63, in half dB steps

Example RALT:DIAG:PASS:TX1 10
Set transmit digital attenuator TX1 to 5dB

RALTimer:DIAGnostics:PASSthrough:TX1?

Description Returns set transmit digital attenuation TX1

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:PASS:TX1?
14

RALTimer:DIAGnostics:PASSthrough:TX2 <var>

- Description** Set 31.5dB transmit digital attenuator TX2
- Parameter** Integer
- Range** 0 to 63, in half dB steps
- Example** RALT:DIAG:PASS:TX2 50
Set transmit digital attenuator TX2 to 25dB

RALTimer:DIAGnostics:PASSthrough:TX2?

- Description** Returns set transmit digital attenuation TX2
- Return Value** Integer 0 to 63, in half dB steps
- Example** RALT:DIAG:PASS:TX2?
33

RALTimer:DIAGnostics:RECeive:ATTenuation <var>

- Description** Sets diagnostics receiver attenuation level
- Parameter** Attenuation dB
- Range** Integer 0 to 31. Values outside range are rejected and an error generated.
- Example** :RALT:DIAG:REC:ATT 15

RALTimer:DIAGnostics:RECeive:ATTenuation?

- Description** Returns set Attenuation in dB
- Return Value** Integer 0 to 31
- Example** RALT:DIAG:REC:ATT?
15

RALTimer:DIAGnostics:RECeive:GAIN <var>

Description Turns the receiver gain stage on or off.

Parameter Enumeration - Mode

Range ON, OFF

Example :RALT:DIAG:REC:GAIN ON
Sets Gain Stage to ON

RALTimer:DIAGnostics:RECeive:GAIN?

Description Returns diagnostic gain stage setting

Return Value ON, OFF

Example :RALT:DIAG:REC:GAIN?
ON

RALTimer:DIAGnostics:RECeive:MEASure <var>

Description Starts or Stops receiver diagnostics measurements

Parameter Boolean

Range ON or 1 starts measurements
OFF or 0 stops measurements

Example :RALT:DIAG:REC:MEAS 1
Starts receiver diagnostic measurements

RALTimer:DIAGnostics:RECeive:MEASure?

Description Returns receiver diagnostics measurement state

Return Value 1 or 0

Example :RALT:DIAG:REC:MEAS?
1

RALTimer:DIAGnostics:RECeive:POWer?

- Description** Returns raw reading corresponding to receiver input power level in mV
- Return Value** Integer
- Example** RALT:DIAG:REC:POW?
2217

RALTimer:DIAGnostics:TATTenuator:FREQuency <var>

- Description** Sets diagnostics Frequency
- Parameter** Frequency in MHz
- Range** Integer 4200 to 4400 MHz
- Example** RALT:DIAG:TATT:FREQ 4300
Sets Frequency to 4300 MHz

RALTimer:DIAGnostics:TATTenuator:FREQuency?

- Description** Returns set diagnostics Frequency in MHz
- Return Value** Integer 4200 to 4400 MHz
- Example** RALT:DIAG:TATT:FREQ?
4250

RALTimer:DIAGnostics:TATTenuator:OUTPut

- Description** Turns diagnostics RF output on or off
- Parameter** Boolean
- Range** ON or 1 starts signal output
OFF or 0 stops signal output
- Example** RALT:DIAG:TATT:OUTP 0
Set diagnostics output to OFF

RALTimer:DIAGnostics:TATTenuator:OUTPut?

Description Returns diagnostics RF output state

Return Value 1 or 0

Example RALT:DIAG:TATT:OUTP?
0

RALTimer:DIAGnostics:TATTenuator:TX0

Description Set 31.5dB transmit digital attenuator TX0

Parameter Integer

Range 0 to 63, in half dB steps

Example Example RALT:DIAG:TATT:TX0 30
Set transmit digital attenuator TX0 to 15dB

RALTimer:DIAGnostics:TATTenuator:TX0?

Description Returns set transmit digital attenuation TX0

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:TATT:TX0?
6

RALTimer:DIAGnostics:TATTenuator:TX1

Description Set 31.5dB transmit digital attenuator TX1

Parameter Integer

Range 0 to 63, in half dB steps

Example RALT:DIAG:TATT:TX1 29
Set transmit digital attenuator TX0 to 14.5dB

RALTimer:DIAGnostics:TATTenuator:TX1?

Description Returns set transmit digital attenuation TX1

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:TATT:TX1?
12

RALTimer:DIAGnostics:TATTenuator:TX2

Description Set 31.5dB transmit digital attenuator TX2

Parameter Integer

Range 0 to 63, in half dB steps

Example RALT:DIAG:TATT:TX2 31
Set transmit digital attenuator TX2 to 15.5dB

RALTimer:DIAGnostics:TATTenuator:TX2?

Description Returns set transmit digital attenuation TX2

Return Value Integer 0 to 63, in half dB steps

Example RALT:DIAG:TATT:TX2?
38

RALTimer:DIAGnostics[:TRANsmit]:FREQuency <var>

Description Sets diagnostics Frequency

Parameter Frequency in MHz

Range Integer 4200 to 4400 MHz

Example :RALT:DIAG:FREQ 4300
Set Frequency to 4300MHz

RALTimer:DIAGnostics[:TRANsmit]:FREQuency?

Description Returns set diagnostics Frequency in MHz

Return Value Integer 4200 to 4400 MHz

Example RALT:DIAG:FREQ?
4300

RALTimer:DIAGnostics[:TRANsmit]:LEVel <var>

| | |
|--------------------|---|
| Description | Sets diagnostics RF Level |
| Parameter | Power Level dBm |
| Range | Signed integer 17 to -76. Values outside range are rejected and an error generated. |
| Example | :RALT:DIAG:LEV -14 Sets RF Level to -14dBm |

RALTimer:DIAGnostics[:TRANsmit]:LEVel?

| | |
|---------------------|--|
| Description | Returns set diagnostics RF Level in + or - dBm |
| Return Value | Signed integer 17 to - 76 dBm |
| Example | RALT:DIAG:LEV? -55 |

RALTimer:DIAGnostics[:TRANsmit]:MODE <var>

| | |
|--------------------|--|
| Description | Sets diagnostic mode |
| Parameter | Enumeration - mode |
| Range | CW, FMCW, PULSe |
| Example | :RALT:DIAG:MODE FMCW Sets Mode to FMCW –fixed triangular modulated waveform |

RALTimer:DIAGnostics[:TRANsmit]:MODE?

| | |
|---------------------|-------------------------|
| Description | Returns diagnostic mode |
| Return Value | CW, FMCW, PULSE |
| Example | RALT:DIAG:MODE? CW |

RALTimer:DIAGnostics[:TRANsmit]:OUTPut <var>

Description Sets diagnostics RF output to ON or OFF

Parameter Boolean
Output ON/OFF

Range ON or 1 turns output on
OFF or 0 turns output off

Example :RALT:DIAG:OUTP 1
Sets diagnostic output to ON

RALTimer:DIAGnostics[:TRANsmit]:OUTPut?

Description Returns diagnostics RF output state

Return Value 1 or 0

Example RALT:DIAG:OUTP?
1

RALTimer:DIAGnostics[:TRANsmit]:PRF <var>

Description Sets diagnostics PRF in Hz

Parameter PRF Hz

Range Integer 2000 to 30000. Values outside range are rejected and an error generated.

Example :RALT:DIAG:PRF 10000
Sets PRF to 10000 Hz

RALTimer:DIAGnostics[:TRANsmit]:PRF?

Description Returns set diagnostics PRF in Hz

Return Value Integer 2000 to 30000

Example RALT:DIAG:PRF?
10000

RALTimer:DIAGnostics[:TRANsmit]:PWIDth <var>

Description Sets diagnostics Pulse Width in ns.

Parameter Pulse Width ns

Range Integer 20 to 400. Values outside range are rejected and an error generated. Value will be rounded to nearest valid value (4 ns steps).

Example :RALT:DIAG:PWID 20
Sets Pulse Width to 20 ns

RALTimer:DIAGnostics[:TRANsmit]:PWIDth?

Description Returns set diagnostics Pulse Width in ns

Return Value Integer 20 to 400

Example :RALT:DIAG:PWID?
20

This page intentionally left blank.

Setup Remote Commands

| | |
|--|------|
| • General | 8-3 |
| • Setup Remote Commands List | 8-3 |
| • Setup Remote Commands Description | 8-5 |
| • RALTimer:OSETup:DISPlay:FREQuency <var> | 8-5 |
| • RALTimer:OSETup:DISPlay:FREQuency? | 8-5 |
| • RALTimer:OSETup:DISPlay:POWEr <var> | 8-5 |
| • RALTimer:OSETup:DISPlay:POWEr? | 8-6 |
| • RALTimer:OSETup:DISPlay:PUNits <var> | 8-6 |
| • RALTimer:OSETup:DISPlay:PUNits? | 8-6 |
| • RALTimer:SETup:AID:MODE <var> | 8-6 |
| • RALTimer:SETup:AID:MODE? | 8-7 |
| • RALTimer:SETup:AID:VALue <var> | 8-7 |
| • RALTimer:SETup:AID:VALue? | 8-7 |
| • RALTimer:SETup:CHANnel1:LEVEl <var> | 8-7 |
| • RALTimer:SETup:CHANnel1:LEVEl? | 8-8 |
| • RALTimer:SETup:CHANnel1:LLOSSs <var> | 8-8 |
| • RALTimer:SETup:CHANnel1:LLOSSs? | 8-8 |
| • RALTimer:SETup:CHANnel1:LOSS:CABLe:RX <var> | 8-8 |
| • RALTimer:SETup:CHANnel1:LOSS:CABLe:RX? | 8-9 |
| • RALTimer:SETup:CHANnel1:LOSS:CABLe:TX <var> | 8-9 |
| • RALTimer:SETup:CHANnel1:LOSS:CABLe:TX? | 8-9 |
| • RALTimer:SETup:CHANnel1:LOSS:COUPler:RX <var> | 8-9 |
| • RALTimer:SETup:CHANnel1:LOSS:COUPler:RX? | 8-10 |
| • RALTimer:SETup:CHANnel1:LOSS:COUPler:TX <var> | 8-10 |
| • RALTimer:SETup:CHANnel1:LOSS:COUPler:TX? | 8-10 |
| • RALTimer:SETup:CHANnel1:LOSS:EXTErnal:RX <var> | 8-10 |
| • RALTimer:SETup:CHANnel1:LOSS:EXTErnal:RX? | 8-11 |

- RALTimer:SETup:CHANnel1:LOSS:EXternal:TX <var> 8-11
- RALTimer:SETup:CHANnel1:LOSS:EXternal:TX? 8-11
- RALTimer:SETup:CHANnel1:OFFSet <var> 8-11
- RALTimer:SETup:CHANnel1:OFFSet? 8-12
- RALTimer:SETup:CONNectiOn <var> 8-12
- RALTimer:SETup:CONNectiOn? 8-12
- RALTimer:SETup:LEVel:MODE <var> 8-12
- RALTimer:SETup:LEVel:MODE? 8-13
- RALTimer:SETup:LEVel:OFFSet <var> 8-13
- RALTimer:SETup:LEVel:OFFSet? 8-13
- RALTimer:SETup:UNITs:ALTituDe <var> 8-14
- RALTimer:SETup:UNITs:ALTituDe ? 8-14
- RALTimer:SETup:UNITs:DISTance <var> 8-14
- RALTimer:SETup:UNITs:DISTance? 8-15
- RALTimer:SETup:UUT:TYPE? <var> 8-15
- RALTimer:SETup:UUT:TYPE? 8-15

General

Setup Remote Commands duplicate the functionality of the setup screen and also the altitude offset from the simulation screen.

Setup Remote Commands List

:RALTimer
:OSETup
:DISPlay
:FREQuency
:FREQuency?
:POWer
:POWer?
:PUNits
:PUNits?
:SETup
:AID
:MODE
:MODE?
:VALue
:VALue?
:CHANnel1
:LEVel
:LEVel?
:LLOSs
:LLOSs?
:LOSS
:CABLE
:RX
:RX?
:TX
:TX?
:COUPler

:RX
:RX?
:TX
:TX?
:RALTimer
:SETup
:CHANnel1
:LOSS (cont)
:EXTernal
:RX
:RX?
:TX
:TX?
:OFFSet
:OFFSet?
:CONNection
:CONNection?
:LEVel
:MODE
:MODE?
:OFFSet
:OFFSet?
:UNITs
:ALTitude
:ALTitude?
:DISTance
:DISTance?
:UUT
:TYPE?

Setup Remote Commands Description

RALTimer:OSETup:DISPlay:FREQuency <var>

- Description** Set the main simulation screen to show center & deviation or start & stop frequencies. This setting is held over a power off cycle and is not affected by recalling settings.
- Parameter** Enumeration - mode
- Range** DEViation, SSTop
- Example** RALT:OSET:DISP:FREQ SST
Sets display to show start frequency and stop frequency

RALTimer:OSETup:DISPlay:FREQuency?

- Description** Determine if displaying center & deviation or start/stop frequencies
- Return Value** DEV, SST
- Example** RALT:OSET:DISP:FREQ?
SST

RALTimer:OSETup:DISPlay:POWer <var>

- Description** Set the main simulation screen to show absolute power level at UUT:RX or the simulated loop loss. This setting is held over a power off cycle and is not affected by recalling settings.
- Parameter** Enumeration - mode
- Range** ABSolute, LLOSS
- Example** RALT:OSET:DISP:POW LLOS
Sets display to show loop loss

RALTimer:OSETup:DISPlay:POWer?

- Description** Determine if displaying absolute level or loop loss
- Return Value** ABS, LLOS
- Example** RALT:OSET:DISP:POW?
ABS

RALTimer:OSETup:DISPlay:PUNits <var>

- Description** Set the profile graph units to be feet or meters. This setting is held over a power off cycle and is not affected by recalling settings.
- Parameter** Enumeration - mode
- Range** METers, METRes, FEET
- Example** RALT:OSET:DISP:PUN MET
Sets profile graph to use meters for altitude

RALTimer:OSETup:DISPlay:PUNits?

- Description** Determine if profile graph is using feet or meters
- Return Value** MET, FEET
- Example** RALT:OSET:DISP:PUN?
MET

RALTimer:SETup:AID:MODE <var>

- Description** Selects Fixed AID (ARINC AID Selections) or Variable (User entered AID)
- Parameter** Enumeration
- Range** FIXed or VARiable
- Example** :RAL:SET:AID:MODE FIX
Fixed AID selected.

RALTimer:SETup:AID:MODE?

- Description** Determines if the Fixed or Variable AID setting is selected.
- Return Value** FIX or VAR
- Example** RALT:SET:AID:MODE?
FIX

RALTimer:SETup:AID:VALue <var>

- Description** Sets AID in feet.If fixed AID is selected only 0, 20, 40, 57 or 80 is accepted.
- Parameter** Integer
- Range** Integer 0 to 99
- Example** :RALT:SET:AID:VAL 40
40 ft AID selected.

RALTimer:SETup:AID:VALue?

- Description** Returns AID Value.
- Return Value** Integer 0 to 99
- Example** RALT:SET:AID:VAL?
40

RALTimer:SETup:CHANnel1:LEVel <var>

- Description** Sets RF Level if Level Mode is Manual.
- Parameter** Level dBm
- Range** Signed Integer 17 to -76. Values outside range are rejected and an error generated.
- Example** :RALT:SET:CHAN1:LEV -14
Sets RF Level to -14 dBm

RALTimer:SETup:CHANnel1:LEVel?

- Description** Returns RF Level in + or - dBm
- Return Value** Signed Integer 17 to -76
- Example** RALT:SET:CHAN1:LEV?
-14

RALTimer:SETup:CHANnel1:LLOs <var>

- Description** Sets RF loop loss (UUT TX port to UUT RX port) if Level Mode is manual and Power Display Mode is loop loss.
- Parameter** Loop loss dB
- Range** Real 30.0 to 140.0 values outside range are rejected and an error generated.
- Example** RALT:SET:CHAN1:LLOS 71.2

RALTimer:SETup:CHANnel1:LLOs?

- Description** Returns loop loss in dB
- Return Value** Real 30.0 to 140.0
- Example** RALT:SET:CHAN1:LLOS?
87.9

RALTimer:SETup:CHANnel1:LOSS:CABLe:RX <var>

- Description** Sets Cable RX Loss in dB
- Parameter** Cable RX Loss dB
- Range** Real 0.0 to 9.9. Values outside range are rejected and an error generated.
- Example** :RALT:SET:CHAN1:LOSS:CABL:RX 5.2
Sets Cable RX Loss to 5.2dB

RALTimer:SETup:CHANnel1:LOSS:CABLe:RX?

Description Returns set Cable RX Loss in dB

Return Value Real 0.0 to 9.9

Example RALT:SET:CHAN1:LOSS:CABL:RX?
5.2

RALTimer:SETup:CHANnel1:LOSS:CABLe:TX <var>

Description Sets Cable TX Loss in dB

Parameter Cable TX Loss dB

Range Real 0.0 to 9.9. Values outside range are rejected and an error generated.

Example :RALT:SET:CHAN1:LOSS:CABL:TX 5.2
Sets Cable TX Loss to 5.2dB

RALTimer:SETup:CHANnel1:LOSS:CABLe:TX?

Description Returns set Cable TX Loss in dB

Return Value Real 0.0 to 9.9

Example RALT:SET:CHAN1:LOSS:CABL:TX?
5.2

RALTimer:SETup:CHANnel1:LOSS:COUPler:RX <var>

Description Sets Coupler RX Loss in dB

Parameter Coupler RX Loss dB

Range Real 0.0 to 19.9. Values outside range are rejected and an error generated.

Example :RALT:SET:CHAN1:LOSS:COUP:RX 5.2
Sets Coupler RX Loss to 5.2dB

RALTimer:SETup:CHANnel1:LOSS:COUPler:RX?

- Description** Returns Coupler RX Loss in dB
- Return Value** Real 0.0 to 19.9
- Example** RALT:SET:CHAN1:LOSS:COUPI:RX?
5.2

RALTimer:SETup:CHANnel1:LOSS:COUPler:TX <var>

- Description** Sets Coupler TX Cable in dB
- Parameter** Coupler TX Loss dB
- Range** Real 0.0 to 19.9. Values outside range are rejected and an error generated.
- Example** :RALT:SET:CHAN1:LOSS:COUP:TX 5.2
Sets Coupler TX Loss to 5.2dB

RALTimer:SETup:CHANnel1:LOSS:COUPler:TX?

- Description** Returns set Coupler TX Loss in dB
- Return Value** Real 0.0 to 19.9
- Example** RALT:SET:CHAN1:LOSS:COUP:TX?
5.2

RALTimer:SETup:CHANnel1:LOSS:EXTernal:RX <var>

- Description** Sets External RX Loss in dB
- Parameter** External RX Loss dB
- Range** Real 0.0 to 50.0. Values outside range are rejected and an error generated.
- Example** :RALT:SET:CHAN1:LOSS:EXT:RX 25.2
Sets External RX Loss to 25.2dB

RALtImeter:SETup:CHANnel1:LOSS:EXTernal:RX?

Description Returns External RX Loss in dB

Return Value Real 0.0 to 50.0

Example :RALT:SET:CHAN1:LOSS:EXT:RX?
25.2

RALtImeter:SETup:CHANnel1:LOSS:EXTernal:TX <var>

Description Sets External TX Cable in dB

Parameter External TX Loss dB

Range Real 0.0 to 20.0. Values outside range are rejected and an error generated.

Example :RALT:SET:CHAN1:LOSS:EXT:TX 10.1
Sets External TX Loss to 10.1dB

RALtImeter:SETup:CHANnel1:LOSS:EXTernal:TX?

Description Returns External TX Loss in dB

Return Value Real 0.0 to 20.0

Example RALT:SET:CHAN1:LOSS:EXT:TX?
10.1

RALtImeter:SETup:CHANnel1:OFFSet <var>

Description Sets Altitude Offset in ft

Parameter Offset ft

Range Real 0.0 to 100.0 in 0.5 ft increments. Values outside range are rejected and an error generated.

Example :RALT:SET:CHAN1:OFFS 50
Sets Altitude Offset 50 ft

RALTimer:SETup:CHANnel1:OFFSet?

- Description** Returns Altitude Offset in ft
- Return Value** Real 0.0 to 100.0
- Example** RALT:SET:CHAN1:OFFSet?
50

RALTimer:SETup:CONNEction <var>

- Description** Selects RF connection to Direct, Feeder or Coupler
- Parameter** Enumeration
- Range** DIRect, FEEDer, COUPler
- Example** :RALT:SET:CONN COUP
Coupler selected.

RALTimer:SETup:CONNEction?

- Description** Determine whether the Direct, Feeder or Coupler RF connection is selected.
- Return Value** DIR, FEED, COUP
- Example** :RALT:SET:CONN?
COUP

RALTimer:SETup:LEVel:MODE <var>

- Description** Sets RF Level Mode. MANUAL: User may set RF level. AUTO: RF Level set automatically referenced to TX power and simulated altitude path loss.
- Parameter** Mode
- Range** AUTO, MANUAL
- Example** :RALT:SET:LEV:MODE AUTO
Sets Mode to Auto

RALTimer:SETup:LEVel:MODE?

Description Returns RF Level Mode

Return Value AUTO, MAN

Example RALT:SET:LEV:MODE?
AUTO

RALTimer:SETup:LEVel:OFFSet <var>

Description Sets RF Level Offset in dB
Note: Only applicable in Auto RF Level Mode

Parameter Offset dB

Range Real integer -20.0 to 20.0 in 0.5 dB increments. Values outside range are rejected and an error generated.

Example :RALT:SET:LEV:OFFS 4.5
Sets RF Level Offset to 4.5 dB

RALTimer:SETup:LEVel:OFFSet?

Description Returns RF Level Offset in dB

Return Value Real integer -20.00 to 20.0

Example RALT:SET:LEV:OFFS?
4.5

RALTimer:SETup:UNITs:ALTitude <var>

Description Select feet or meters entry mode for the commands that set altitude or altitude rate.

Affected commands are:

```
RALT:ASIM:MAN:CHAN1:ALT  
RALT:ASIM:MAN:CHAN1:RATE  
RALT:ASIM:MAN:CHAN1:STAR  
RALT:ASIM:MAN:CHAN1:STOP
```

The query form of these commands are also affected.

Parameter Enumeration

Range FEET or METers or METRes

Example :RALT:SET:UNIT:ALT MET
select meters entry

RALTimer:SETup:UNITs:ALTitude ?

Description Determine if altitude entry via rci is in feet or meters.

Return Value FEET or MET

Example :RALT:SET:UNIT:ALT?
FEET

RALTimer:SETup:UNITs:DISTance <var>

Description Select feet or meters entry mode for the command RALT:SET:CHAN1:OFFS and the query form of this command.

Parameter Enumeration

Range FEET or METers or METRes

Example :RALT:SET:UNIT:DIST FEET
select feet units when setting or reading altitude offset

RALTimer:SETup:UNITs:DISTance?

Description Determines if altitude offset entry via rci is in feet or meters.

Return Value FEET or MET

Example :RAL:SET:UNIT:DIST?
MET

RALTimer:SETup:UUT:TYPE? <var>

Description Sets UUT Type

Parameter Enumeration

Range FMCW, CDF, PULS, GFMC, OTHER

Example RAL:SET:UUT:TYPE?
FMCW; OTHER

RALTimer:SETup:UUT:TYPE?

Description Returns set UUT Type

Return Value FMCW, CDF, PULS, GFMC, OTHER

Example RAL:SET:UUT:TYPE?
FMCW; OTHER

This page intentionally left blank.

Settings Storage Remote Commands

- General 9-2
- Settings Remote Commands List 9-2
- Settings Remote Commands Description 9-3
 - RALTimer:SETTINGS:CHANnel1:DEFault 9-3
 - RALTimer:SETTINGS:CHANnel1:MODified? 9-3
 - RALTimer:SETTINGS:CHANnel1:NAME? 9-3
 - RALTimer:SETTINGS:CHANnel1:RECall <var> 9-3
 - RALTimer:SETTINGS:CHANnel1:STORE <var> 9-4
 - RALTimer:SETTINGS:COUNt? 9-4
 - RALTimer:SETTINGS:DELeTe <var> 9-4
 - RALTimer:SETTINGS:LIST? 9-4

General

Settings Remote Commands duplicate the functionality on the setup screen for storing, managing and recalling settings.

Settings Remote Commands List

:RALTimer
:SETTings
:CHANnel1
:DEFault
:MODified?
:NAME?
:RECall
:STORe
:COUNT?
:DELete
:LIST?

Settings Remote Commands Description

RALTimer:SETTings:CHANnel1:DEFault

Description Sets Factory default settings

Parameter NA

Range NA

Example :RALT:SETT:CHAN1:DEF

RALTimer:SETTings:CHANnel1:MODified?

Description Indicates if the settings have been modified since the store was last loaded or saved.

Return Value 0 = settings not modified, 1 = settings modified

Example RALT:SETT:CHAN1:MOD?
1

RALTimer:SETTings:CHANnel1:NAME?

Description Returns the current settings file name.

Return Value Up to 20 Alpha Numeric characters

Example :RALT:SETT:CHAN1:NAME?
Settings1
Note: If the name has been modified an asterisk will be added,
e.g. "Settings1*"

RALTimer:SETTings:CHANnel1:RECall <var>

Description Recalls a named settings file. Becomes the current settings.

Parameter String

Range Up to 20 Alpha Numeric characters

Example :RALT:SETT:CHAN1:REC "A-380"
Recall file A-380

RALTimer:SETTINGS:CHANnel1:STORe <var>

- Description** Stores the current settings under a file name. The number of settings that may be stored is only limited by available memory.
- Parameter** String
- Range** Up to 20 Alpha Numeric Characters including Space
- Example** :RAL:SETT:CHAN1:STORE "LRA-900 TEST"
Store settings as LRA-900 TEST

RALTimer:SETTINGS:COUNT?

- Description** Returns a count of stored settings files
- Return Value** Integer
- Example** :RAL:SETT:COUN?
4

RALTimer:SETTINGS:DELEte <var>

- Description** Deletes the named settings file.
- Parameter** String
- Range** Up to 20 Alpha Numeric Characters
- Example** :RAL:SETT:DEL "B-757"
Delete file B-757

RALTimer:SETTINGS:LIST?

- Description** Returns a list of stored settings file names , each up to 20 characters in length
- Return Value** Comma separated string
- Example** :RAL:SETT:LIST?
"A-380","LRA-900TEST"

Status Remote Commands

- General 10-2
- Status Remote Commands List 10-2
- Status Remote Commands Description..... 10-3
 - RALTimer:STATus:CHANnel1:UNLock:ALL? 10-3
 - RALTimer:STATus:CHANnel1:UNLock:OVERall?..... 10-3

General

Status Remote Commands duplicate the functionality of system info screen (maintenance menu).

Status Remote Commands List

:RALTimer
:STATus
:CHANnel 1
:UNLock
:ALL?
OVERall?

Status Remote Commands Description

RALTimer:STATus:CHANnel1:UNLock:ALL?

Description Returns flags for hardware locked/unlock status
Order is: Overall unlocked flag
Tracking synth unlocked flag
External ref unlocked flag (always zero)
Receive LO unlocked flag
Transmit LO unlocked flag
Offset synth unlocked flag
SPA unlocked flag
DPLL unlocked flag

Return Value 0 = Locked, 1 = Unlocked

Example :RAL:STAT:CHAN1:UNL:ALL?
0,0,0,0,0,0,0,0
Shows everything is locked

RALTimer:STATus:CHANnel1:UNLock:OVERall?

Description Returns flag for overall locked/unlock status

Return Value 1= Unlocked 0= Locked

Example :RAL:STAT:CHAN1:UNL:OVER?
1

This page intentionally left blank.

Test Remote Commands

- General 11-2
- Test Remote Commands List 11-2
- Test Remote Commands Description 11-3
 - RALTimeter:TEST:PAUSe 11-3
 - RALTimeter:TEST:PAUSed? 11-3
 - RALTimeter:TEST:RESume 11-3
 - RALTimeter:TEST:RUNNing? 11-3
 - RALTimeter:TEST:START 11-4
 - RALTimeter:TEST:STOP 11-4
 - RALTimeter:MEASure:CHANnel1:DATA? 11-4
 - RALTimeter:MEASure:CHANnel1:LEVel? 11-4
 - RALTimeter:MEASure:CHANnel1:MARGin? 11-5
 - RALTimeter:MEASure:CHANnel1:STALe? 11-5

General

Test Remote Commands duplicate the functionality of the simulation screen Run/Stop button and Pause Altitude button.

Test Remote Commands List

:RALTimer
:TEST
:PAUSE
:PAUSEd?
:RESume
:RUNNING?
:START
:STOP
:MEASURE
:CHANNEL1
:DATA?
:LEVEL?
:MARGIN?
:STALE?

Test Remote Commands Description

RALTimer:TEST:PAUSE

Description Pauses the test
Note: Only valid while simulation is running

Parameter NA

Range NA

Example :RALT:TEST:PAUS

RALTimer:TEST:PAUSed?

Description Returns flag for test paused status

Return Value 1= Paused 0= Running

Example :RALT:TEST:PAUS?
1

RALTimer:TEST:RESume

Description Resumes the test
Note: Only valid while simulation is running and test paused

Parameter NA

Range NA

Example :RALT:TEST:RES

RALTimer:TEST:RUNNing?

Description Returns flag for test running status

Return Value 0 = not running, 1 = running

Example :RALT:TEST:RUNN?
1

RALTimer:TEST:START

Description Starts the Simulation test

Parameter NA

Range NA

Example :RALT:TEST:STAR

RALTimer:TEST:STOP

Description Stops the Simulation test

Parameter NA

Range NA

Example :RALT:TEST:STOP

RALTimer:MEASure:CHANnel1:DATA?

Description Returns frequency, power, sweep rate, fm deviation, PRF, pulse width, altitude.

Return Value Validity: 0 = invalid, 1 = valid
Frequency: 4200 to 4400 (**Note:** not hard clipped)
Power: in mW
Sweep Rate: 0 to 500 Hz (**Note:** not hard clipped)
FM Deviation: 0 to 100 MHz (**Note:** not hard clipped)
PRF: 1 to 30000 Hz
Pulse Width: 20 to 400 ns
Altitude: -20 to 8000 ft

Example :RALT:MEAS:CHAN1:DATA?
1,4300,104.7,738,62,0,0,0

RALTimer:MEASure:CHANnel1:LEVel?

Description Returns auto RF level (dBm) or auto loop loss (dB) depending on setting of RALT:OSET:DISP:POW

Return Value Real

Example RALT:MEAS:CHAN1:LEV?
-38.5

RALTimer:MEASure:CHANnel1:MARGin?

Description Returns Link Margin for LPI pulse altimeters

Return Value Integer

Example RALT:MEAS:CHAN1:MARG?
25

RALTimer:MEASure:CHANnel1:STALe?

Description Returns an indication of whether uut measurements are stale

Return Value six Booleans: frequency, power, sweep rate, fmdev, prf, pulse width

Example RALT:MEAS:CHAN1:STAL?
1,0,1,1,0,0

This page intentionally left blank.

System Remote Commands

- System Remote Commands List 12-2
- System Remote Commands Description 12-2
 - SYSTem:ERRor[:NEXT]? 12-2
 - SYSTem:ERRor:ALL? 12-2
 - SYSTem:ERRor:CODE[:NEXT]? 12-3
 - SYSTem:ERRor:COUnT? 12-3
 - SYSTem:ERRor:GLOBal? 12-3
 - SYSTem:VERSion? 12-3

System Remote Commands List

:SYSTem
:ERRor?
:ERRor
:ALL?
:CODE
[:NEXT]?
:COUNT?
:GLOBal?
[:NEXT]?
:VERSion?

System Remote Commands Description

SYSTem:ERRor[:NEXT]?

Description Returns oldest error message in the error queue and then clears the error message from the queue

Return Value Integer, string

Example :SYST:ERR?
-113,"Undefined header;*ict;2014/10/10 17:03:49"

SYSTem:ERRor:ALL?

Description Returns all error messages in the error queue and then clears all error messages from the queue.

Return Value Comma separated list of error messages (integer, string)

Example :SYST:ERR:ALL?
-113,"Undefined header;*ict;2014/10/10 17:03:49",
-113,"Undefined header;*ict;2014/10/10 17:05:30"

SYSTem:ERRor:CODE[:NEXT]?

Description Returns first error message number in the error queue and then clears the error message from the queue.

Return Value Integer

Example :SYST:ERR:CODE:NEXT?
-113

SYSTem:ERRor:COUNt?

Description Returns the number of error messages currently in the queue.

Return Value Integer

Example :SYST:ERR:COUN?
3

SYSTem:ERRor:GLOBal?

Description Returns oldest error message from the global error queue and clears the error message from the queue.

Return Value Integer, String

Example :SYST:ERR:GLOB?
-200, "Execution error;Power too low at RF In. Testing
stopped.;2016/11/07 16:10:02."

SYSTem:VERSion?

Description Returns system version number.

Return Value String

Example :SYST:VERS?
"1999"

This page intentionally left blank.

Self Test Remote Commands

- Self Test Remote Commands List 13-2
- Self Test Remote Commands Description 13-2
 - HHSelftest:RALTimer:DCVoltage? 13-2
 - HHSelftest:RALTimer:TEMPerature? 13-3
 - HHSelftest:RALTimer:LPOWER? 13-3
 - HHSelftest:RALTimer:PLOCK? 13-3
 - HHSelftest:RALTimer:RDATtenuator? 13-4
 - HHSelftest:RALTimer:RAATtenuator? 13-4
 - HHSelftest:RALTimer:GSTage? 13-4
 - HHSelftest:RALTimer:T0Dattenuator? 13-5
 - HHSelftest:RALTimer:T1Dattenuator? 13-5
 - HHSelftest:RALTimer:T2Dattenuator? 13-5
 - HHSelftest:RALTimer:TAATtenuator? 13-6
 - HHSelftest:RALTimer:FREQuency? 13-6
 - HHSelftest:RALTimer:rfDMAMps? 13-6
 - HHSelftest:RALTimer:rfDMATtens? 13-6
 - HHSelftest:RALTimer:ALLStatus? 13-7
 - HHSelftest:RUN? 13-7

Self Test Remote Commands List

:HHSelftest

:RALTimer?
:DCVoltage?
:TEMPerature?
:LPOWer?
:PLOCK?
:RDATtenuator?
:RAATtenuator?
:GSTage?
:T0Dattenuator?
:T1Dattenuator?
:T2Dattenuator?
:TAATtenuator?
:FREQuency?
:DDS?
:rfDMAMps?
:rfDMATtens?
:ALLStatus?
:RUN?

Self Test Remote Commands Description

HHSelftest:RALTimer:DCVoltage?

Description After selftest has been run this will return the DC voltage test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:DCV?
"PASS"

HHSelftest:RALTimer:TEMPerature?

Description After selftest has been run this will return the temperature test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:TEMP?
"PASS"

HHSelftest:RALTimer:LPOWER?

Description After selftest has been run this will return the loopback power test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "PASS" indicates a passing test. A return of "FAIL" indicates a test failure. If this test fails, the remaining tests cannot be run and will all return "UNABLE TO TEST".

Return Value String

Example HHS:RAL:LPOW?
"PASS"

HHSelftest:RALTimer:PLOCK?

Description After selftest has been run this will return the PLL lock test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "UNABLE TO TEST" indicates that the selftest failed the loopback power test and could not continue. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:PLOC?
"PASS"

HHSelftest:RALTimer:RDATtenuator?

Description After selftest has been run this will return the receive digital attenuator test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "UNABLE TO TEST" indicates that the selftest failed the loopback power test and could not continue. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:RDAT?
"PASS"

HHSelftest:RALTimer:RAATtenuator?

Description After selftest has been run this will return the receive analog attenuator test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "UNABLE TO TEST" indicates that the selftest failed the loopback power test and could not continue. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:RAAT?
"PASS"

HHSelftest:RALTimer:GSTage?

Description After selftest has been run this will return the gain stage test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "UNABLE TO TEST" indicates that the selftest failed the loopback power test and could not continue. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:GST?
"PASS"

HHSelftest:RALTimer:T0Dattenuator?

Description After selftest has been run this will return the transmit TX0 digital attenuator test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "UNABLE TO TEST" indicates that the selftest failed the loopback power test and could not continue. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:T0D?
"PASS"

HHSelftest:RALTimer:T1Dattenuator?

Description After selftest has been run this will return the transmit TX1 digital attenuator test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "UNABLE TO TEST" indicates that the selftest failed the loopback power test and could not continue. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:T1D?
"PASS"

HHSelftest:RALTimer:T2Dattenuator?

Description After selftest has been run this will return the transmit TX2 digital attenuator test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "UNABLE TO TEST" indicates that the selftest failed the loopback power test and could not continue. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:T2D?
"PASS"

HHSelftest:RALTimer:TAATenuator?

Description After selftest has been run this will return the transmit analog attenuator test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "UNABLE TO TEST" indicates that the selftest failed the loopback power test and could not continue. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:TAAT?
"PASS"

HHSelftest:RALTimer:FREQuency?

Description After selftest has been run this will return the frequency test status. A return of "NOT RUN" indicates that the test has not been performed. A return of "UNABLE TO TEST" indicates that the selftest failed the loopback power test and could not continue. A return of "PASS" indicates a passing test. A return similar to "FAIL 0002" indicates a test failure, the value being a hex error code.

Return Value String

Example HHS:RAL:FREQ?
"PASS"

HHSelftest:RALTimer:rfDMAMps?

Description After selftest has been run this will return the RF Delay Module Amplifier status

Return Value String

Example HHS:RAL:DMAM? "PASS"

HHSelftest:RALTimer:rfDMATtens?

Description After selftest has been run this will return the RF Delay Module Attenuator status

Return Value String

Example HHS:RAL:DMAT? "PASS"

HHSelftest:RALTimer:ALLStatus?

Description After selftest has been run this will return the status of all selftests run

Return Value String

Example HHS:RAL:ALLS? "PASS"

HHSelftest:RUN?

Description Run the self test for the ALT9000. Does not return until the selftest completes, and then returns a 1. Use the individual readback commands to determine which tests passed or failed.

Return Value Integer

Example HHS:RUN?
1

This page intentionally left blank.

*RST Settings

- *RST Settings A-2

*RST Settings

Table A-1 RST Settings

| | |
|--|----------|
| (Start) Altitude | 0 |
| Stop Altitude | 0 |
| Altitude Rate | 0 |
| Simulation Mode | Manual |
| Uut Detect | Auto |
| Uut Type | FMCW |
| CDF Subtype | Sweeping |
| Altitude Offset | 0 |
| RF Level Mode | Auto |
| Manual RF Level | -55 |
| Manual Loop Loss | 48.9 |
| Connection Type | Direct |
| Uut:tx Cable Loss | 0 |
| Uut:rx Cable Loss | 0 |
| Uut:tx Coupler Loss | 0 |
| Uut:rx Coupler Loss | 0 |
| Uut:tx Ext Attenuation | 0 |
| Uut:rx Ext Attenuation | 0 |
| Diagnostics Tx Power | -55 |
| Diagnostics Tx Freq | 4300 |
| Diagnostics Tx Mode | CW |
| Diagnostics Tx Prf | 2000 |
| Diagnostics Tx Pulse Width | 20 |
| Diagnostics Rx Atten | 31 |
| Diagnostics Rx Gain Stage | Off |
| Diagnostics Tx Attens Freq | 4300 |
| Diagnostics Tx Attens Tx 0 | 63 |
| Diagnostics Tx Attens Tx1 | 63 |
| Diagnostics Tx Attens Tx2 | 63 |
| Diagnostics Loopback Freq | 4300 |
| Diagnostics Loopback Tx Analog Atten | 1023 |
| Diagnostics Loopback Tx0 Digital Atten | 63 |
| Diagnostics Loopback Tx1 Digital Atten | 63 |
| Diagnostics Loopback Tx2 Digital Atten | 63 |

Table A-1 RST Settings

| | |
|---|------------------|
| Diagnostics Loopback Rx Analog Atten | 1023 |
| Diagnostics Loopback Rx0 Digital Atten | 63 |
| Diagnostics Loopback Gain Stage | Off |
| Diagnostics Passthrough Rx0 Digital Atten | 63 |
| Diagnostics Passthrough Rx Analog Atten | 1023 |
| Diagnostics Passthrough Gain Stage | Off |
| Diagnostics Passthrough Tx Analog Atten | 1023 |
| Diagnostics Passthrough Tx0 Digital Atten | 63 |
| Diagnostics Passthrough Tx1 Digital Atten | 63 |
| Diagnostics Passthrough Tx2 Digital Atten | 63 |
| Frequency Display Mode | Center/Deviation |
| Profile Display Units | Feet |

This page intentionally left blank.

Error Handling

- Remote Control Errors B-2
 - RALT:CAL:USER:STAR B-2
 - RALT:CAL:VATT:STAR B-2
 - RALT:TEST:STAR B-3

Remote Control Errors

Some remote control commands can cause global errors. These errors are accessed using SYST:ERR:GLOB? instead of SYST:ERR?.

The following commands generate errors that are reported via the global queue.

RALT:CAL:USER:STAR

Delay calibration failure:

No signal detected at RF In. Are the cables connected together using the supplied tnc to tnc adapter?

Delay calibration failure:

Too much loss. Remove any external attenuators. If there are no external attenuators attached then please use lower loss cables.

Delay calibration failure:

Failed to determine cable delay for pulse mode.

Delay calibration failure:

Failed to determine cable delay for FM CW mode.

RALT:CAL:VATT:STAR

Loopback calibration failure:

Unable to optimize signal level during analog attenuator offset calibration.

Loopback calibration failure:

Failed to detect pulses at receiver.

Loopback calibration failure:

Unable to measure consistent pulse width during vref5 calibration.

Loopback calibration failure:

Power too low - is the loop-back cable connected?

RALT:TEST:STAR

A level flight path has been entered with an Altitude Rate. Please change the Altitude Rate to 0 for a level flight. Testing stopped.

UUT frequency out of range. Test Stopping.

Unable to detect reasonable UUT signal. Testing stopped.

User set UUT type (FMCW/CDF) does not match detected UUT type (PULSE).

Pulses not detected. Check that the pulse radio is connected correctly.

Pulse Power too low at RF In. Testing stopped.

Power too low at RF In. Testing stopped.

Power level varying, cannot determine level. Testing stopped.

Invalid Pulse UUT Detected. Testing stopped.

UUT transmit frequency out of range. UUT measurements continue but no RF is output.

User set uut type (FMCW) does not match detected uut type (CDF FMCW). Testing will continue but results will be unpredictable.

User set uut type (CDF FMCW) does not match detected uut type (FMCW). Testing will continue but results will be unpredictable.

User set Search/Track subtype does not match detected Sweeping subtype. Testing will continue but results will be unpredictable.

User set Sweeping subtype does not match detected Search/Track subtype. Testing will continue but results will be unpredictable. Query both queues to determine if any errors have occurred.

Signal at RF In is CW. It is recommended that the test be stopped, check the uut connections and re-start the test. Query both queues to determine if any errors have occurred.

All other errors are reported via the per-parser queue, using SYST:ERR? to read them. Query both queues to determine if any errors have occurred.

This page intentionally left blank.



**ALT-9000 Radio Altimeter Test Set
Remote Commands Manual
22159915, Rev. 002
Part of CD: 22149666
March, 2026
English**

VIAVI Solutions

| | |
|---------------------------|--|
| North America: | 1.844.GO VIAVI / 1.844.468.4284 |
| Latin America | +52 55 5543 6644 |
| EMEA | +49 7121 862273 |
| APAC | +1 512 201 6534 |
| All Other Regions: | viavisolutions.com/contacts |