



**3900 Series**  
**Digital Radio Test Set**  
ARIB Remote Programming Manual



# **3900 Series**

## **Digital Radio Test Set**

### **ARIB Remote Programming Manual**

PUBLISHED BY  
VIAVI Solutions, Inc.

COPYRIGHT © VIAVI Solutions, Inc. 2020

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior permission of the publisher.

Re-Issued            Jan 2020

---

# Preface

## ABOUT THIS MANUAL

This manual identifies Remote Commands for the 3900 Series ARIB Option (390XOPT460). Refer to the 3900 Series Remote Programming Manual for additional information about 3900 Remote Commands and for remote commands for 3900 Test Instruments. The remote commands identified in this manual are only valid when the ARIB Option is installed in the Test Set. Refer to the 3900 Series Operation Manual for information pertaining to Test Set operation.

## NOMENCLATURE STATEMENT

The 3901, 3902 and 3920"x" Digital Radio Test Set is the official nomenclature for the test sets currently included in the 3900 Digital Radio Test Set Series. In this manual, 3900, unit or Test Set, refers to the 3901, 3902 and 3920"x" Digital Radio Test Sets unless otherwise indicated.

## INTENDED AUDIENCE

This manual is intended for personnel familiar with the use of remote command language and Test Set operation. Refer to the 3900 Series Operation Manual for information pertaining to Test Set operation.

## TEST SET REQUIREMENTS

Refer to the 3900 Series Operation Manual for information on the following:

- Safety Precautions
- Power Requirements
- Platform Performance Data Specifications
- Repacking / Shipping Test Set

THIS PAGE INTENTIONALLY LEFT BLANK.

---

## Contents

### **CHAPTER 1 UUT MEASUREMENT RETURN DATA**

Chapter describes parameters found in ARIB Rx Measurements data string.

### **CHAPTER 2 GENERATOR/TRANSMIT CHANNEL REMOTE COMMANDS**

Chapter describes commands that define Transmit and Generator parameters.

### **CHAPTER 3 ANALYZER/RECEIVE CHANNEL REMOTE COMMANDS**

Chapter describes commands that configure Analyzer and Receive parameters.

### **CHAPTER 4 ARIB SIGNAL METER REMOTE COMMANDS**

Chapter describes commands that configure and return ARIB STD-T98 signal measurements.

### **CHAPTER 5 AUDIO/DEMOD SIGNAL RX METER REMOTE COMMANDS**

Chapter describes commands that configure and return Audio and Demodulated signal measurements.

### **CHAPTER 6 MODULATION ACCURACY AND POWER REMOTE COMMANDS**

Chapter describes commands that configure and return Modulation Accuracy and Power measurements.

THIS PAGE INTENTIONALLY LEFT BLANK.

---

# Table of Contents

## **UUT Measurement Return Data . . . . . 1 - 1**

Introduction . . . . .	1 - 1
UUT Measurement Meter Return Data . . . . .	1 - 1

## **Generator/Transmit Channel Remote Commands . . . . . 2 - 1**

Introduction . . . . .	2 - 1
AF Generator Configuration . . . . .	2 - 1
AF Generator - Tone Encoding . . . . .	2 - 6
Mod Generator Configuration . . . . .	2 - 13
Modulation Generators - Tone Encoding . . . . .	2 - 16
External Modulation Generator . . . . .	2 - 25
RF Generator/Transmit Channel Configuration . . . . .	2 - 27
Cable Loss Measurements . . . . .	2 - 30

## **Analyzer/Receive Channel Remote Commands . . . . . 3 - 1**

Introduction . . . . .	3 - 1
Acquire Signal . . . . .	3 - 1
Audio Measurements Configuration . . . . .	3 - 2
AF Analyzer - Tone Decode . . . . .	3 - 5
Modulation Analyzer - Tone Decoding . . . . .	3 - 8
Receiver (Analyzer) Configuration . . . . .	3 - 11

## **ARIB Signal Meter Remote Commands . . . . . 4 - 1**

Introduction . . . . .	4 - 1
Reset Measurement Data . . . . .	4 - 1
Bit Error Rate (BER) . . . . .	4 - 1
Broadband Power . . . . .	4 - 4
Frequency Correction . . . . .	4 - 7
FSK Error . . . . .	4 - 10
Signal Power . . . . .	4 - 13
Symbol Clock Error . . . . .	4 - 16
Symbol Deviation . . . . .	4 - 19

## Audio/Demod Signal

### **Rx Meter Remote Commands . . . . . 5 - 1**

Introduction . . . . .	5 - 1
Audio Measurement Configuration . . . . .	5 - 1
Modulation Measurement Configuration . . . . .	5 - 5
AF Distortion Measurements . . . . .	5 - 7
AF Frequency Measurements . . . . .	5 - 10
AF Hum & Noise Measurements . . . . .	5 - 13
AF Level Measurements . . . . .	5 - 17
AF Sinad Measurements . . . . .	5 - 20
AF SNR Measurements . . . . .	5 - 23
Broadband Power . . . . .	5 - 26
FM Deviation Measurements . . . . .	5 - 29
Inband Power Measurements . . . . .	5 - 33
Modulation Distortion Measurements . . . . .	5 - 36
Modulation Frequency Measurements . . . . .	5 - 39
Modulation Hum & Noise Measurements . . . . .	5 - 42
Modulation Sinad Measurements . . . . .	5 - 45
Modulation SNR Measurements . . . . .	5 - 48
RF Error Measurements . . . . .	5 - 51

## Modulation Accuracy and Power

### **Remote Commands . . . . . 6 - 1**

Introduction . . . . .	6 - 1
Constellation Graph . . . . .	6 - 1
Distribution Graph . . . . .	6 - 3
Power Over Time . . . . .	6 - 5



---

# Chapter 1 - UUT Measurement Return Data

## 1.1 INTRODUCTION

This chapter contains general information about DPMR UUT Measurement return data. Refer to the 3900 Series Digital Radio Test Set Remote Programming Manual for detailed information about 3900 system remote commands.

**NOTE**

Upper range value of 2.71 GHz is only valid for some 3900 models/options. Refer to product specifications for valid upper range.

## 1.2 UUT MEASUREMENT METER RETURN DATA

The information returned in UUT Measurement Meters data strings varies depending on the type of measurement. The following are examples:

<statusbyte>,<failbyte>,<avgcount>,<avg>,<wc>  
<statusbyte>,<failbyte>,<precision>,<percentage>,<avg>,<max>,<min>,<units>  
<statusbyte>,<failbyte>,<avgcount>,<avg>,<max>,<min>

### 1.2.1 Status Byte (Bitmask)

**NOTE**

Statusbyte may return more than one condition as a bitmask.

Status Byte returned in the following bit position indicates measurement reading status:

- Bit 0 = Invalid
  - Bit 1 = Inaccurate
  - Bit 2 = Settling
  - Bit 3 = Squelch
- Returns 0 when measurement reading is valid.

### 1.2.2 Fail Byte (Bitmask)

**NOTE**

Failbyte may return more than one condition as a bitmask.

Returns 0 in the following bit position when limit check has passed.

Returns 1 in the following bit position when limit check has failed.

- Bit 0 = Minimum Upper Limit
- Bit 1 = Minimum Lower Limit
- Bit 2 = Maximum Upper Limit
- Bit 3 = Maximum Lower Limit
- Bit 4 = Average Upper Limit
- Bit 5 = Average Lower Limit
- Bit 6 = Worst Case Upper Limit

Bit 7 = Worst Case Lower Limit

**1.2.3 Precision (Numeric)**

Precision value indicates the number of numerals that follow the decimal point in the returned average, maximum and minimum readings.

**1.2.4 Percentage (Numeric)**

Percentage value indicates the percentage of averaging completed when remote command was issued. For example, if the over  $n$  burst field is set to 1000 bursts, and only 500 bursts have been obtained when the query command is issued, the returned percentage value is 50.

**1.2.5 Average (Numeric)**

Value indicates average measurement reading.

**1.2.6 Maximum (Numeric)**

Value indicates maximum measurement reading.

**1.2.7 Minimum (Numeric)**

Value indicates minimum measurement reading.

**1.2.8 Worst Case (wc)**

Value indicates maximum measurement reading.

**1.2.9 Peak to Peak/2 (pk-pk/2)**

Value indicates FM Peak to Peak/2 measurement reading.

**1.2.10 Positive Peak (pospeak)**

Value indicates maximum measurement reading.

**1.2.11 Negative Peak (negpeak)**

Value indicates minimum measurement reading.

**1.2.12 Units**

0 = No Units	7 = V	14 = dBW
1 = %	8 = mV	15 = Vrms
2 = Hz	9 = $\mu$ V	16 = dBr
3 = kHz	10 = dB $\mu$ V	17 = dBV
4 = MHz	11 = W	18 = mHz
5 = dB	12 = mW	19 = $\mu$ s
6 = dBm	13 = $\mu$ W	

**1.2.13 Message Responses**

A message response is not always included at the end of the data string. The following are valid Message Responses which may be received when a remote command is sent.

“signal not acquired\n”

“timed out waiting for TraceMutex\n”

“timed out waiting for data\n”

---

## Chapter 2 - Generator/Transmit Channel Remote Commands

### 2.1 INTRODUCTION

This chapter describes the Remote Commands for configuring ARIB Transmit and Receive System Parameters. Commands are listed alphabetically under Transmit and Receiver headings.

### 2.2 AF GENERATOR CONFIGURATION

#### 2.2.1 AF Generators - DCS Code

**:AF:GENErator:SOURceN:CODEword "xxx"**  
**:AF:GENErator:SOURceN:CODEword?**

**Description:** Set command defines the DCS code for specified AF Generator.  
Query command returns parameter setting.

**Parameter:** Refer to Appendix A of 3900 Series Remote Programming Manual for supported DCS codes.

**Default Value:** 023

**Set/Query Format:** NR1

**Example:** :AF:GENErator:SOURce1:CODEword "071"  
Sets AF Generator 1 DCS Code to 071.

**Query Response:** :AF:GENErator:SOURce1:CODEword?  
071

**NOTE**

AF Generator Waveform must be defined as DCS for command to be valid.  
SourceN = 1, 2 or 3 (AF Generator 1, 2 or 3)

#### 2.2.2 AF Generators - DTMF Burst Length

**:AF:GENErator:SOURce1:MARK**  
**:AF:GENErator:SOURce1:MARK?**

**Description:** Set command defines the length of time a DTMF burst is ON for the AF Generator 1.  
Query command returns parameter setting.

**Range:** 1 to 6,000,000 ms

**Units:** ms

**Default Value:** 100 ms

**Set/Query Format:** NRf | NR1

**Example:** :AF:GENErator:SOURce1:MARK 5000ms  
Sets length of AF Generator 1 DTMF burst to 5000 milliseconds.

**Query Response:** :AF:GENErator:SOURce1:MARK?  
5000

**NOTE**

DTMF waveform is only supported on AF Generator 1.  
AF Generator 1 Waveform must be defined as DTMF for command to be valid.

### 2.2.3 AF Generators - DTMF Dead Time

**:AF:GENErator:SOURce1:END**

**:AF:GENErator:SOURce1:END?**

**Description:** Set command defines the dead time between DTMF tones for AF Generator 1. Query command returns parameter setting.

**Range:** 1 to 6,000,000 ms

**Units:** ms

**Default Value:** 500 ms

**Set/Query Format:** NRf | NR1

**Example:** :AF:GENErator:SOURce1:END 1000ms  
Sets dead time between DTMF tones to 1000 milliseconds.

**Query Response:** :AF:GENErator:SOURce1:END?  
1000

**NOTE**

DTMF waveform is only supported on AF Generator 1.  
AF Generator 1 Waveform must be defined as DTMF for command to be valid.

### 2.2.4 AF Generators - DTMF Sequence

**:AF:GENErator:SOURce1:SEQuence**

**:AF:GENErator:SOURce1:SEQuence?**

**Description:** Set command defines DTMF Sequence when DTMF Waveform is selected. Query command returns parameter setting.

**Parameter:** 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | # | \*  
maximum of 16 characters encased in double quotes “ “

**Default Value:** 01234567

**Set/Query Format:** hex string

**Example:** :AF:GENErator:SOURce1:SEQuence "ABCD\*1245#5678"  
Sets AF Generator 1 DTMF Sequence to ABCD\*1245#5678.

**Query Response:** :AF:GENErator:SOURce1:SEQuence?  
ABCD\*1245#5678

**NOTE**

DTMF waveform is only supported on AF Generator 1.  
AF Generator 1 Waveform must be defined as DTMF for command to be valid.

### 2.2.5 AF Generators - DTMF Sequence Mode

**:AF:GENErator:SOURce1:SEQMode**

**:AF:GENErator:SOURce1:SEQMode?**

**Description:** Set command defines the DTMF sequence mode of operation for the AF Generator 1.

Query command returns parameter setting.

**Parameter:** 0 = Single DTMF burst  
1 = Continuous DMTF burst

**Default Value:** 0 (Single)

**Set/Query Format:** NR1

**Example:** :AF:GENErator:SOURce1:SEQMode 1  
Sets DTMF Sequence of AF Generator 1 to Continuous.

**Query Response:** :AF:GENErator:SOURce1:SEQMode?  
1

**NOTE**

DTMF waveform is only supported on AF Generator 1.  
AF Generator 1 Waveform must be defined as DTMF for command to be valid.

### 2.2.6 AF Generators - DTMF Sequence Spacing

**:AF:GENErator:SOURce1:SPACe**

**:AF:GENErator:SOURce1:SPACe?**

**Description:** Set command defines the length of time a DTMF burst is ON for the AF Generator 1.

Query command returns parameter setting.

**Range:** 1 to 6,000,000 ms

**Units:** ms

**Default Value:** 500 ms

**Set/Query Format:** NRf | NR1

**Example:** :AF:GENErator:SOURce1:SPACe 1000ms  
Sets dead time between DTMF tone sequences to 1000 milliseconds.

**Query Response:** :AF:GENErator:SOURce1:SPACe?  
1000

**NOTE**

DTMF waveform is only supported on AF Generator 1.  
Continuous Sequence Mode must be selected for command to be valid.

### 2.2.7 AF Generators - Enable

**:AF:GENErator:SOURceN:ENABle**

**:AF:GENErator:SOURceN:ENABle?**

**Description:** Set command Enables/Disables the specified AF Generator.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :AF:GENErator:SOURce2:ENABle ON  
Enables AF Generator 2.

**Query Response:** :AF:GENErator:SOURce2:ENABle?  
1

**NOTE**

SourceN = 1, 2 or 3 (AF Generator 1, 2 or 3)

### 2.2.8 AF Generators - Impedance

**:CONFIgure:IMPedance:AF:GENErator**

**:CONFIgure:IMPedance:AF:GENErator?**

**Description:** Set command defines the Impedance of the AF Generator.  
Query command returns parameter setting.

**Range:** 1 to 10,000 Ohms

**Units:** Ohms

**Default Value:** 600 Ohms

**Set/Query Format:** NRf | NR1

**Example:** :CONFIgure:IMPedance:AF:GENErator 500OHMS  
Sets AF Generator Impedance to 500 Ohms.

**Query Response:** :CONFIgure:IMPedance:AF:GENErator?  
500

### 2.2.9 AF Generators - Frequency

**:AF:GENErator:SOURceN:FREQUency**

**:AF:GENErator:SOURceN:FREQUency?**

**Description:** Set command defines the frequency for the specified AF Generator.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 40.0 kHz

**Units:** Hz | kHz

**Default Value:** AF 1: 1.0 kHz  
AF 2: 300.0 Hz  
AF 3: 3.4 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :AF:GENErator:SOURce3:FREQUency 15kHz  
Sets AF Generator 3 Frequency to 15.0 kHz.

**Query Response:** :AF:GENErator:SOURce3:FREQUency?  
15000.0

**NOTE**

SourceN = 1, 2 or 3 (AF Generator 1, 2 or 3)

**2.2.10 AF Generators - Level****:AF:GENERator:SOURceN:LEVel****:AF:GENERator:SOURceN:LEVel?**

**Description:** Set command defines the Level for the specified AF Generator.  
Query command returns parameter setting.

**Range:** 1.0 mV to 5.0 Vrms

**Units:** mV | V

**Default Value:** 100.0 mV

**Set/Query Format:** NRf | NR2 (mV)

**Example:** :AF:GENERator:SOURce1:LEVel 5V  
Sets AF Generator 1 Level (Amplitude) to 5.0 V.

**Query Response:** :AF:GENERator:SOURce1:LEVel?  
5000.0

**NOTE**

SourceN = 1, 2 or 3 (AF Generator 1, 2 or 3)

**2.2.11 AF Generators - Waveform****:AF:GENERator:SOURceN:SHAPE****:AF:GENERator:SOURceN:SHAPE?**

**Description:** Set command defines the Waveform for the specified AF Generator.  
Query command returns parameter setting.

**Parameter:** SINE | SQUARE | TRIangle | RAMP | DCS | DCSINV | DTMF

**Query Data:** SNR | SINE | SQUARE | TRIangle | RAMP | DCS | DCSINV | DTMF | TONESEQ |  
TONEREM

**Default Value:** SINE

**Set/Query Format:** CPD | CRD

**Example:** :AF:GENERator:SOURce2:SHAPE SQUARE  
Sets AF Generator 2 Waveform shape to Square.

**Query Response:** :AF:GENERator:SOURce2:SHAPE?  
SQU

**NOTE**

SourceN = 1, 2 or 3 (AF Generator 1, 2 or 3)

DTMF waveform is only valid on AF Generator 1. AF Generator 2 is unavailable when DTMF is selected on AF Generator 1.

DCS and DCSINV are not supported on AF Generator 3.

AF Generator 1 is unavailable as a modulation source when Normal MOD SNR Noise Measurements are defined (:CONFigure:MOD:ANALyzer:SNR:MODE 1) and AF:GENERator:SOURce1:SHAPE? returns SNR.

## 2.3 AF GENERATOR - TONE ENCODING

### 2.3.1 AF Generators - Encoding Enable

**:AF:GENerator:ENCODE:ENABLE**

**:AF:GENerator:ENCODE:ENABLE?**

**Description:** Set command Enables/Disables (sends) one Tone.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :AF:GENerator:ENCODE:ENABLE ON  
Sends one Tone from Audio Generator.

**Query Response:** :AF:GENerator:ENCODE:ENABLE?  
1

### 2.3.2 AF Generators - Encoded Signal Type

**:AF:GENerator:ENCODE:TYPE**

**:AF:GENerator:ENCODE:TYPE?**

**Description:** Set command defines type of signal being Encoded by the AF Generator.  
Query command returns parameter setting.

**Parameter:** TWOTONE | TONESEQ | TONEREM

**Default:** TWOTONE

**Set/Query Format:** CPD | CRD

**Example:** :AF:GENerator:ENCODE:TYPE TWOTONE  
Sets Audio Generator Tone Signaling Type to Two Tone Sequential.

**Query Response:** :AF:GENerator:ENCODE:TYPE?  
TWOTONE

### 2.3.3 AF Generators - Tone Remote Function Duration

**:AF:GEN:TONE:REMote:FUNction:DURation**

**:AF:GEN:TONE:REMote:FUNction:DURation?**

**Description:** Set command defines length of single Tone.  
Query command returns parameter setting.

**Range:** 20 to 500 ms

**Units:** ms | s

**Default:** 40 ms

**Set/Query Format:** NRf | NR1 (ms)

**Example:** :AF:GEN:TONE:REMote:FUNction:DURation 50ms  
Sets length of single Tone to 50 milliseconds.

**Query Response:** :AF:GEN:TONE:REMote:FUNction:DURation?  
50



### 2.3.4 AF Generators - Tone Remote Function Frequency

**:AF:GEN:TONE:REMOte:FUNCTion:FREQuency**

**:AF:GEN:TONE:REMOte:FUNCTion:FREQuency?**

**Description:** Set command defines the Tone frequency.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 2.999 kHz

**Units:** Hz | kHz

**Default Value:** 1.050 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :AF:GEN:TONE:REMOte:FUNCTion:FREQuency 15Hz  
Sets Tone Frequency to 15.0 Hz.

**Query Response:** :AF:GEN:TONE:REMOte:FUNCTion:FREQuency?  
15.0

### 2.3.5 AF Generators - Tone Remote Function Level

**:AF:GEN:TONE:REMOte:FUNCTion:LEVEl**

**:AF:GEN:TONE:REMOte:FUNCTion:LEVEl?**

**Description:** Set command defines the Tone Audio Level.  
Query command returns parameter setting.

**Range:** -20.0 to +20.0 dB

**Units:** dB

**Default Value:** 0.0 dB

**Set/Query Format:** NRf | NR2

**Example:** :AF:GEN:TONE:REMOte:FUNCTion:LEVEl 5dB  
Sets the Tone Audio Level to 5.0 dB.

**Query Response:** :AF:GEN:TONE:REMOte:FUNCTion:LEVEl?  
5.0

### 2.3.6 AF Generators - Tone Remote Guard Duration

**:AF:GEN:TONE:REMOte:GUARD:DURation**

**:AF:GEN:TONE:REMOte:GUARD:DURation?**

**Description:** Set command defines length of single Tone.  
Query command returns parameter setting.

**Range:** 1 to 6,000,000 ms

**Units:** ms | s | ks

**Default:** 120 ms

**Set/Query Format:** NRf | NR1 (ms)

**Example:** :AF:GEN:TONE:REMOte:GUARD:DURation 50ms  
Sets length of single Tone 50 milliseconds.

**Query Response:** :AF:GEN:TONE:REMOte:GUARD:DURation?  
50

### 2.3.7 AF Generators - Tone Remote Guard Frequency

**:AF:GEN:TONE:REMOte:GUARD:FREQuency**  
**:AF:GEN:TONE:REMOte:GUARD:FREQuency?**

**Description:** Set command defines the Tone frequency.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 2.999 kHz

**Units:** Hz | kHz

**Default Value:** 2.175 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :AF:GEN:TONE:REMOte:GUARD:FREQuency 15Hz  
Sets Tone Frequency to 15.0 Hz.

**Query Response:** :AF:GEN:TONE:REMOte:GUARD:FREQuency?  
15.0

### 2.3.8 AF Generators - Tone Remote Guard Level

**:AF:GEN:TONE:REMOte:GUARD:LEVel**  
**:AF:GEN:TONE:REMOte:GUARD:LEVel?**

**Description:** Set command defines the Tone Audio Level.  
Query command returns parameter setting.

**Range:** -20.0 to +20.0 dB

**Units:** dB

**Default Value:** -20.0 dB

**Set/Query Format:** NRf | NR2

**Example:** :AF:GEN:TONE:REMOte:GUARD:LEVel 5dB  
Sets the Tone Audio Level to 5.0 dB.

**Query Response:** :AF:GEN:TONE:REMOte:GUARD:LEVel?  
5.0

### 2.3.9 AF Generators - Tone Remote Maximum Duration

**:AF:GEN:TONE:REMOte:MAXimum:DURation**  
**:AF:GEN:TONE:REMOte:MAXimum:DURation?**

**Description:** Set command defines length of single Tone.  
Query command returns parameter setting.

**Range:** 20 to 500 ms

**Units:** ms | s

**Default:** 120 ms

**Set/Query Format:** NRf | NR1 (ms)

**Example:** :AF:GEN:TONE:REMOte:MAXimum:DURation 50ms  
Sets length of single Tone to 50 milliseconds.

**Query Response:** :AF:GEN:TONE:REMOte:MAXimum:DURation?  
50

### 2.3.10 AF Generators - Tone Remote Maximum Frequency

**:AF:GEN:TONE:REMOte:MAXimum:FREQuency**  
**:AF:GEN:TONE:REMOte:MAXimum:FREQuency?**

**Description:** Set command defines the Tone frequency.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 2.999 kHz

**Units:** Hz | kHz

**Default Value:** 2.175 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :AF:GEN:TONE:REMOte:MAXimum:FREQuency 15Hz  
Sets Tone Frequency to 15.0 Hz.

**Query Response:** :AF:GEN:TONE:REMOte:MAXimum:FREQuency?  
15.0

### 2.3.11 AF Generators - Tone Remote Maximum Level

**:AF:GEN:TONE:REMOte:MAXimum:LEVel**  
**:AF:GEN:TONE:REMOte:MAXimum:LEVel?**

**Description:** Set command defines the Tone Audio Level.  
Query command returns parameter setting.

**Range:** -20.0 to +20.0 dB

**Units:** dB

**Default Value:** 10.0 dB

**Set/Query Format:** NRf | NR2

**Example:** :AF:GEN:TONE:REMOte:MAXimum:LEVel 5dB  
Sets the Tone Audio Level to 5.0 dB.

**Query Response:** :AF:GEN:TONE:REMOte:MAXimum:LEVel?  
5.0

### 2.3.12 AF Generators - Tone Remote Reference Level

**:AF:GEN:TONE:REMOte:REFerence:LEVel**  
**:AF:GEN:TONE:REMOte:REFerence:LEVel?**

**Description:** Set command defines the Tone Reference Audio Level.  
Query command returns parameter setting.

**Range:** 20.0 to 5000.0 mV

**Units:** mV | V

**Default Value:** 1.0 V

**Set/Query Format:** NRf | NR2 (mV)

**Example:** :AF:GEN:TONE:REMOte:REFerence:LEVel 2.5V  
Sets the Tone Reference Audio Level to 2.5 Volts.

**Query Response:** :AF:GEN:TONE:REMOte:REFerence:LEVel?  
2500

### 2.3.13 AF Generators - Tone Sequential Audio Level

**:AF:GEN:TONE:SEQUential:MASTER:LEVel**

**:AF:GEN:TONE:SEQUential:MASTER:LEVel?**

**Description:** Set command defines the Audio Level for Tone Sequential tones.  
Query command returns parameter setting.

**Range:** 20.0 to 5000.0 mV

**Units:** mV | V

**Default Value:** 1.0 V

**Set/Query Format:** NRf | NR2 (mV)

**Example:** :AF:GEN:TONE:SEQUential:MASTER:LEVel 2V  
Sets the Audio Level for Tone Sequential tones to 2.0 Volts.

**Query Response:** :AF:GEN:TONE:SEQUential:MASTER:LEVel?  
2000.0

### 2.3.14 AF Generators - Tone Sequential Mode

**:AF:GEN:TONE:SEQUential:MODE**

**:AF:GEN:TONE:SEQUential:MODE?**

**Description:** Set command selects Tone Mode of operation.  
Query command returns parameter setting.

**Parameter:** SINGLE | CONTINUOUS

**Default Value:** SINGLE

**Set/Query Format:** CPD | CRD

**Example:** :AF:GEN:TONE:SEQUential:MODE CONTINUOUS  
Sets Mode of Tone Sequential burst to Continuous.

**Query Response:** :AF:GEN:TONE:SEQUential:MODE?  
CONTINUOUS

### 2.3.15 AF Generators - Tone Sequential Protocol

**:AF:GEN:TONE:SEQUential:PROTocol**

**:AF:GEN:TONE:SEQUential:PROTocol?**

**Description:** Set command selects protocol of single tone.  
Query command returns parameter setting.

**Parameter:** ZVEI1 | ZVEI2 | ZVEI3 | PZVEI | DZVEI | PDZVEI | CCIR1 | CCIR2 | PCCIR |  
EEA | EUROSIG | NATEL | EIA | MODAT

**Default Value:** ZVEI1

**Set/Query Format:** CPD | CRD

**Example:** :AF:GEN:TONE:SEQUential:PROTocol PZVEI  
Sets Protocol for tone to PZVEI.

**Query Response:** :AF:GEN:TONE:SEQUential:PROTocol?  
PZVEI

**2.3.16 AF Generators - Tone Sequential Sequence****:AF:GEN:TONE:SEQuential:SEQuence****:AF:GEN:TONE:SEQuential:SEQuence?**

**Description:** Set command defines Sequence of single tone.  
Query command returns parameter setting.

**Parameter:** 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F  
maximum of 8 characters encased in double quotes “ “

**Default Value:** 01234

**Set/Query Format:** hex string

**Example:** :AF:GEN:TONE:SEQuential:SEQuence "ABCD1245"  
Sets Tone Sequential Sequence to ABCD1245.

**Query Response:** :AF:GEN:TONE:SEQuential:SEQuence?  
ABCD1245

**2.3.17 AF Generators - Two Tone Sequential Duration****:AF:GENerator:TTS:nTONE:DURation****:AF:GENerator:TTS:nTONE:DURation?**

**Description:** Set command defines length of single specified Tone.  
Query command returns parameter setting.

**Range:** 100 ms to 10 s

**Units:** ms | s

**Default:** 1.0 s

**Set/Query Format:** NRf | NR1 (ms)

**Example:** :AF:GENerator:TTS:ATONE:DURation 5s  
Sets length of single Tone A burst to 5 seconds.

**Query Response:** :AF:GENerator:TTS:ATONE:DURation?  
5000

**NOTE**

nTone = A or B (Tone A or B)

**2.3.18 AF Generators - Two Tone Sequential Frequency****:AF:GENerator:TTS:nTONE:FREQuency****:AF:GENerator:TTS:nTONE:FREQuency?**

**Description:** Set command defines AF Generator Frequency for specified Tone.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 2.999 kHz

**Units:** Hz | kHz

**Default Value:** Tone A: 500.0 Hz  
Tone B: 1.0 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :AF:GENerator:TTS:ATONE:FREQuency 150Hz  
Sets AF Generator Frequency for Tone A to 150.0 Hz.

**Query Response:** :AF:GENerator:TTS:ATONE:FREQuency?  
150.00

**NOTE**

nTone = A or B (Tone A or B)

### 2.3.19 AF Generators - Two Tone Sequential Level

**:AF:GENerator:TTS:LEVel**

**:AF:GENerator:TTS:LEVel?**

**Description:** Set command defines the Level for single tone.  
Query command returns parameter setting.

**Range:** 20.0 mV to 5.0 Vrms

**Units:** mV | V

**Default Value:** 1.0 V

**Set/Query Format:** NRf | NR2 (mV)

**Example:** :AF:GENerator:TTS:LEVel 3V  
Sets AF Generator Level (Amplitude) to 3.0 Volts.

**Query Response:** :AF:GENerator:TTS:LEVel?  
3000.0

## 2.4 MOD GENERATOR CONFIGURATION

### 2.4.1 Modulation Generators - Enable

**:MOD:GENErator:SOURceN:ENABle**

**:MOD:GENErator:SOURceN:ENABle?**

**Description:** Set command Enables/Disables the specified Modulation Generator.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :MOD:GENErator:SOURce1:ENABle ON  
Enables Modulation Generator 1.

**Query Response:** :MOD:GENErator:SOURce1:ENABle?  
1

**NOTE**

:RF:MODUlatorN:ENABle deprecated in software version 1.7.9.  
SourceN = 1, 2 or 3 (Modulator 1, 2 or 3)

### 2.4.2 Modulation Generators - Frequency

**:MOD:GENErator:SOURceN:FREQUency**

**:MOD:GENErator:SOURceN:FREQUency?**

**Description:** Set command defines Frequency for the specified Modulation Generator.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 5.0 kHz

**Units:** Hz | kHz

**Default Value:** Mod 1: 1.0 kHz  
Mod 2: 300.0 Hz  
Mod 3: 3.4 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :MOD:GENErator:SOURce1:FREQUency 2kHz  
Sets Modulation Generator 1 Frequency to 2.0 kHz.

**Query Response:** :MOD:GENErator:SOURce1:FREQUency?  
2000.0

**NOTE**

RF:MODUlatorN:FREQUency deprecated in software version 1.7.9.  
SOURceN = 1, 2 or 3 (Mod Generator 1, 2 or 3)

### 2.4.3 Modulation Generators - Level

**:MOD:GENERator:SOURceN:LEVel**

**:MOD:GENERator:SOURceN:LEVel?**

**Description:** Set command defines Level for specified Modulation Generator.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 150.0 kHz

**Units:** Hz | kHz

**Default Value:** 2.5 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :MOD:GENERator:SOURce3:LEVel 3kHz  
Sets Modulation Generator 3 Level to 3.0 kHz.

**Query Response:** :MOD:GENERator:SOURce3:LEVel?  
3000.00

**NOTE**

:RF:MODulatorN:LEVel deprecated in software version 1.7.9.  
SOURceN = 1, 2 or 3 (Modulator 1, 2 or 3)

### 2.4.4 Modulation Generators - Level as a Percent (%)

**:MOD:GENERator:SOURceN:LEVel:PERcent**

**:MOD:GENERator:SOURceN:LEVel:PERcent?**

**Description:** Set command defines Level for specified Modulation Generator.  
Query command returns parameter setting.

**Range:** 0 to 100%

**Units:** % (Percent)

**Default Value:** 1.667%

**Set/Query Format:** NRf | NR2 (%)

**Example:** :MOD:GENERator:SOURce3:LEVel:PERcent 15  
Sets Modulation Generator 3 Level to 15.0%.

**Query Response:** :MOD:GENERator:SOURce3:LEVel:PERcent?  
15.0

**NOTE**

:RF:MODulatorN:LEVel:PERcent deprecated in software version 1.7.9.  
SOURceN = 1, 2 or 3 (Modulator 1, 2 or 3)



## 2.4.5 Modulation Generators - Waveform

**:MOD:GENERator:SOURceN:SHAPE**

**:MOD:GENERator:SOURceN:SHAPE?**

**Description:** Set command defines Waveform Shape for the specified Modulation Generator.  
Query command returns parameter setting.

**Set Parameters:** SINE | SQUARE | TRIangle | RAMP | DCS | DCSINV | DTMF

**Query Data:** SINE | SQUARE | TRIangle | RAMP | DCS | DCSINV | DTMF | TRKGEN

**Default Value:** SINE

**Set/Query Format:** CPD | CRD

**Example:** :MOD:GENERator:SOURce2:SHAPE SQUARE  
Sets Modulation Generator 2 Waveform Shape to Square.

**Query Response:** :MOD:GENERator:SOURce2:SHAPE?  
SQU

**NOTE**

:RF:MODulatorN:SHAPE deprecated in software version 1.7.9.

SOURceN = 1, 2 or 3 (Mod Generator 1, 2 or 3)

DTMF is not a valid parameter for Modulator 2 and Modulator 3. DTMF may be returned as query data for Modulator 2.

## 2.5 MODULATION GENERATORS - TONE ENCODING

### 2.5.1 Modulation Generators - DCS Code

**:MOD:GENErator:SOURceN:CODEword "xxx"**

**:MOD:GENErator:SOURceN:CODEword?**

**Description:** Set command defines the DCS code for specified Mod Generator Source.  
Query command returns parameter setting.

**Parameter:** Refer to Appendix A of 3900 Series Remote Programming Manual for supported DCS codes.

**Default Value:** 023

**Set/Query Format:** NR1

**Example:** :MOD:GENErator:SOURce1:CODEword "071"  
Sets Mod Generator 1 DCS Code to 071.

**Query Response:** :MOD:GENErator:SOURce1:CODEword?  
071

**NOTE**

Command only valid when Mod Generator Shape (Waveform) is set to DCS.  
SOURceN = 1, 2 or 3 (Mod Generator 1, 2 or 3)

### 2.5.2 Modulation Generators - DTMF Burst Length

**:MOD:GENErator:SOURce1:MARK**

**:MOD:GENErator:SOURce1:MARK?**

**Description:** Set command defines length of time a DTMF burst is ON for Mod Generator 1.  
Query command returns parameter setting.

**Range:** 1 to 6,000,000 ms

**Units:** ms

**Default Value:** 100 ms

**Set/Query Format:** NRF | NR1

**Example:** :MOD:GENErator:SOURce1:MARK 5000ms  
Sets length of Mod Generator 1 DTMF burst to 5000 milliseconds.

**Query Response:** :MOD:GENErator:SOURce1:MARK?  
5000

**NOTE**

DTMF waveform is only supported on Mod Generator 1

### 2.5.3 Modulation Generators - DTMF Dead Time

**:MOD:GENErator:SOURce1:END**

**:MOD:GENErator:SOURce1:END?**

**Description:** Set command defines the dead time between DTMF tones for Mod Generator 1.  
Query command returns parameter setting.

**Range:** 1 to 6,000,000 ms

**Units:** ms

**Default Value:** 500 ms

**Set/Query Format:** NRf | NR1

**Example:** :MOD:GENErator:SOURce1:END 1000ms  
Sets dead time between DTMF tones to 1000 milliseconds.

**Query Response:** :MOD:GENErator:SOURce1:END?  
1000

**NOTE**

DTMF waveform is only supported on Mod Generator 1.

### 2.5.4 Modulation Generators - DTMF Sequence

**:MOD:GENErator:SOURce1:SEQuence**

**:MOD:GENErator:SOURce1:SEQuence?**

**Description:** Set command defines DTMF Sequence when DTMF Waveform is selected.  
Query command returns parameter setting.

**Parameter:** 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | # | \*  
maximum of 16 characters encased in double quotes “ “

**Default Value:** 01234567

**Set/Query Format:** hex string

**Example:** :MOD:GENErator:SOURce1:SEQuence "ABCD\*1234#5678"  
Sets Mod Generator DTMF Sequence to ABCD\*1245#5678.

**Query Response:** :MOD:GENErator:SOURce1:SEQuence?  
ABCD\*1245#5678

**NOTE**

Command only valid when Mod Generator 1 Waveform is set to DTMF.  
DMTF waveform is only supported on Mod Generator 1.

### 2.5.5 Modulation Generators - DTMF Sequence Mode

**:MOD:GENErator:SOURce1:SEQuence:Mode**

**:MOD:GENErator:SOURce1:SEQuence:Mode?**

**Description:** Set command defines DTMF sequence mode of operation for Mod Generator 1. Query command returns parameter setting.

**Parameter:** SINGLE | CONTINUOUS

**Default Value:** SINGLE

**Set/Query Format:** NR1

**Example:** :MOD:GENErator:SOURce1:SEQuence:Mode CONTINUOUS  
Sets DTMF Sequence Mode of Mod Generator 1 to Continuous.

**Query Response:** :MOD:GENErator:SOURce1:SEQuence:Mode?  
CONTINUOUS

**NOTE**

Command only valid when Mod Generator 1 Waveform is set to DTMF. DTMF waveform is only supported on Mod Generator 1.

### 2.5.6 Modulation Generators - DTMF Sequence Spacing

**:MOD:GENErator:SOURce1:SPACe**

**:MOD:GENErator:SOURce1:SPACe?**

**Description:** Set command defines the dead time between DTMF tone sequence when operating in Continuous Sequence mode of operation for RF Mod Generator 1. Query command returns parameter setting.

**Range:** 1 to 6,000,000 ms

**Units:** ms

**Default Value:** 500 ms

**Set/Query Format:** NRf | NR1

**Example:** :MOD:GENErator:SOURce1:SPACe 1000ms  
Sets dead time between DTMF tone sequences to 1000 milliseconds.

**Query Response:** :MOD:GENErator:SOURce1:SPACe?  
1000

**NOTE**

Command only valid when Continuous Sequence Mode is selected. DTMF waveform is only supported on Mod Generator 1.

### 2.5.7 Modulation Generators - Encoding Enable

**:MOD:GENErator:ENCODE:ENABLE**

**:MOD:GENErator:ENCODE:ENABLE?**

**Description:** Set command Enables/Disables (sends) one Tone from Modulation Generator. Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :MOD:GENErator:ENCODE:ENABLE ON  
Sends one Tone from Modulation Generator.

**Query Response:** :MOD:GENErator:ENCODE:ENABLE?  
1

### 2.5.8 Modulation Generators - Encoded Signal Type

**:MOD:GENerator:ENCODE:TYPE**

**:MOD:GENerator:ENCODE:TYPE?**

**Description:** Set command defines type of signal being Encoded by the Modulation Generator.

Query command returns parameter setting.

**Parameter:** TWOTONE | TONESEQ | TONEREM

**Default:** TWOTONE

**Set/Query Format:** CPD | CRD

**Example:** :MOD:GENerator:ENCODE:TYPE TWOTONE

Sets Modulation Generator Tone Signaling Type to Two Tone Sequential.

**Query Response:** :MOD:GENerator:ENCODE:TYPE?

TWOTONE

### 2.5.9 Modulation Generators - Tone Remote Functional Duration

**:MOD:GEN:TONE:REMOte:FUNctio:n:DURation**

**:MOD:GEN:TONE:REMOte:FUNctio:n:DURation?**

**Description:** Set command defines length of single Tone.

Query command returns parameter setting.

**Range:** 20 to 500 ms

**Units:** ms | s

**Default:** 40 ms

**Set/Query Format:** NRf | NR1 (ms)

**Example:** :MOD:GEN:TONE:REMOte:FUNctio:n:DURation 50ms

Sets length of single Tone burst to 50 milliseconds.

**Query Response:** :MOD:GEN:TONE:REMOte:FUNctio:n:DURation?

50

### 2.5.10 Modulation Generators - Tone Remote Functional Frequency

**:MOD:GEN:TONE:REMOte:FUNctio:n:FREQuency**

**:MOD:GEN:TONE:REMOte:FUNctio:n:FREQuency?**

**Description:** Set command defines the Tone frequency.

Query command returns parameter setting.

**Range:** 1.0 Hz to 2.999 kHz

**Units:** Hz | kHz

**Default Value:** 1.050 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :MOD:GEN:TONE:REMOte:FUNctio:n:FREQuency 15Hz

Sets Tone Frequency to 15.0 Hz.

**Query Response:** :MOD:GEN:TONE:REMOte:FUNctio:n:FREQuency?

15.0

### 2.5.11 Modulation Generators - Tone Remote Functional Level

**:MOD:GEN:TONE:REMOte:FUNCTion:LEVEl**

**:MOD:GEN:TONE:REMOte:FUNCTion:LEVEl?**

**Description:** Set command defines the Tone Level.  
Query command returns parameter setting.

**Range:** -20.0 to +20.0 dB

**Units:** dB

**Default Value:** 0.0 dB

**Set/Query Format:** NRf | NR2

**Example:** :MOD:GEN:TONE:REMOte:FUNCTion:LEVEl 5dB  
Sets the Tone Level to 5.0 dB.

**Query Response:** :MOD:GEN:TONE:REMOte:FUNCTion:LEVEl?  
5.0

### 2.5.12 Modulation Generators - Tone Remote Guard Duration

**:MOD:GEN:TONE:REMOte:GUARD:DURation**

**:MOD:GEN:TONE:REMOte:GUARD:DURation?**

**Description:** Set command defines length of single Tone Remote burst.  
Query command returns parameter setting.

**Range:** 1 to 6,000,000 ms

**Units:** ms | s | ks

**Default:** 120 ms

**Set/Query Format:** NRf | NR1 (ms)

**Example:** :MOD:GEN:TONE:REMOte:GUARD:DURation 50ms  
Sets length of single Tone Remote burst to 50 milliseconds.

**Query Response:** :MOD:GEN:TONE:REMOte:GUARD:DURation?  
50

### 2.5.13 Modulation Generators - Tone Remote Guard Frequency

**:MOD:GEN:TONE:REMOte:GUARD:FREQuency**

**:MOD:GEN:TONE:REMOte:GUARD:FREQuency?**

**Description:** Set command defines Tone Frequency.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 2.999 kHz

**Units:** Hz | kHz

**Default Value:** 2.175 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :MOD:GEN:TONE:REMOte:GUARD:FREQuency 15Hz  
Sets Tone Frequency to 15.0 Hz.

**Query Response:** :MOD:GEN:TONE:REMOte:GUARD:FREQuency?  
15.0

### 2.5.14 Modulation Generators - Tone Remote Guard Level

**:MOD:GEN:TONE:REMOte:GUARD:LEVel**  
**:MOD:GEN:TONE:REMOte:GUARD:LEVel?**

**Description:** Set command defines the Tone Level.  
Query command returns parameter setting.

**Range:** -20.0 to +20.0 dB

**Units:** dB

**Default Value:** -20.0 dB

**Set/Query Format:** NRf | NR2

**Example:** :MOD:GEN:TONE:REMOte:GUARD:LEVel 5dB  
Sets the Tone Level to 5.0 dB.

**Query Response:** :MOD:GEN:TONE:REMOte:GUARD:LEVel?  
5.0

### 2.5.15 Modulation Generators - Tone Remote Maximum Duration

**:MOD:GEN:TONE:REMOte:MAXimum:DURation**  
**:MOD:GEN:TONE:REMOte:MAXimum:DURation?**

**Description:** Set command defines length of single Tone.  
Query command returns parameter setting.

**Range:** 20 to 500 ms

**Units:** ms | s

**Default:** 120 ms

**Set/Query Format:** NRf | NR1 (ms)

**Example:** :MOD:GEN:TONE:REMOte:MAXimum:DURation 50ms  
Sets length of single Tone burst to 50 milliseconds.

**Query Response:** :MOD:GEN:TONE:REMOte:MAXimum:DURation?  
50

### 2.5.16 Modulation Generators - Tone Remote Maximum Frequency

**:MOD:GEN:TONE:REMOte:MAXimum:FREQuency**  
**:MOD:GEN:TONE:REMOte:MAXimum:FREQuency?**

**Description:** Set command defines the Tone frequency.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 2.999 kHz

**Units:** Hz | kHz

**Default Value:** 2.175 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :MOD:GEN:TONE:REMOte:MAXimum:FREQuency 15Hz  
Sets Tone Frequency to 15.0 Hz.

**Query Response:** :MOD:GEN:TONE:REMOte:MAXimum:FREQuency?  
15.0

**2.5.17 Modulation Generators - Tone Remote Maximum Level****:MOD:GEN:TONE:REMOte:MAXimum:LEVel****:MOD:GEN:TONE:REMOte:MAXimum:LEVel?**

**Description:** Set command defines the Tone Level.  
Query command returns parameter setting.

**Range:** -20.0 to +20.0 dB

**Units:** dB

**Default Value:** 10.0 dB

**Set/Query Format:** NRf | NR2

**Example:** :MOD:GEN:TONE:REMOte:MAXimum:LEVel 5dB  
Sets the Tone Level to 5.0 dB.

**Query Response:** :MOD:GEN:TONE:REMOte:MAXimum:LEVel?  
5.0

**2.5.18 Modulation Generators - Tone Remote Reference Deviation****:MOD:GEN:TONE:REMOte:REFerence:DEViation****:MOD:GEN:TONE:REMOte:REFerence:DEViation?**

**Description:** Set command defines the Tone Reference Deviation.  
Query command returns parameter setting.

**Range:** 414.0 Hz to 150.0 kHz

**Units:** Hz | kHz

**Default Value:** 2.5 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :MOD:GEN:TONE:REMOte:REFerence:DEViation 1.75kHz  
Sets the Tone Reference Deviation to 1.75 kHz.

**Query Response:** :MOD:GEN:TONE:REMOte:REFerence:DEViation?  
1750.0

**2.5.19 Modulation Generators - Tone Sequential FM Deviation****:MOD:GEN:TONE:SEQuential:MASTER:DEViation****:MOD:GEN:TONE:SEQuential:MASTER:DEViation?**

**Description:** Set command defines the Modulation FM Deviation for Tone Sequential Encoding.  
Query command returns parameter setting.

**Range:** 414.0 Hz to 150.0 kHz

**Units:** Hz | kHz

**Default Value:** 2.5 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :MOD:GEN:TONE:SEQuential:MASTER:DEViation 1.75kHz  
Sets the Tone FM Deviation to 1.75 kHz.

**Query Response:** :MOD:GEN:TONE:SEQuential:MASTER:DEViation?  
1750.0



### 2.5.20 Modulation Generators - Tone Sequential Mode

**:MOD:GEN:TONE:SEQUential:MODE**

**:MOD:GEN:TONE:SEQUential:MODE?**

**Description:** Set command selects Tone Mode of operation.  
Query command returns parameter setting.

**Parameter:** SINGLE | CONTINUOUS

**Default Value:** SINGLE

**Set/Query Format:** CPD | CRD

**Example:** :MOD:GEN:TONE:SEQUential:MODE CONTINUOUS  
Sets Tone Sequential Mode to Continuous.

**Query Response:** :MOD:GEN:TONE:SEQUential:MODE?  
CONTINUOUS

### 2.5.21 Modulation Generators - Tone Sequential Protocol

**:MOD:GEN:TONE:SEQUential:PROTOcol**

**:MOD:GEN:TONE:SEQUential:PROTOcol?**

**Description:** Set command selects Tone protocol.  
Query command returns parameter setting.

**Parameter:** ZVEI1 | ZVEI2 | ZVEI3 | PZVEI | DZVEI | PDZVEI | CCIR1 | CCIR2 | PCCIR |  
EEA | EUROSIG | NATEL | EIA | MODAT

**Default Value:** ZVEI1

**Set/Query Format:** CPD | CRD

**Example:** :MOD:GEN:TONE:SEQUential:PROTOcol PZVEI  
Sets Tone Protocol to PZVEI.

**Query Response:** :MOD:GEN:TONE:SEQUential:PROTOcol?  
PZVEI

### 2.5.22 Modulation Generators - Two Tone Sequential FM Deviation

**:MOD:GENerator:TTS:DEViation**

**:MOD:GENerator:TTS:DEViation?**

**Description:** Set command defines the Tone Deviation for Modulation Generator.  
Query command returns parameter setting.

**Range:** 414.0 Hz to 150.0 kHz

**Units:** Hz | kHz

**Default Value:** 2.5 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :MOD:GENerator:TTS:DEViation 4kHz  
Sets Mod Generator Deviation to 4.0 kHz

**Query Response:** :MOD:GENerator:TTS:DEViation?  
4000.0

**2.5.23 Modulation Generators - Two Tone Sequential Duration****:MOD:GENErator:TTS:nTONE:DURation****:MOD:GENErator:TTS:nTONE:DURation?**

**Description:** Set command defines length of single Tone.  
Query command returns parameter setting.

**Range:** 100 ms to 10 s

**Units:** ms | s

**Default:** Tone A: 1.0 s  
Tone B: 3.0 s

**Set/Query Format:** NRf | NR1 (ms)

**Example:** :MOD:GENErator:TTS:ATONE:DURation 5s  
Sets length of single Tone A burst to 5 seconds.

**Query Response:** :MOD:GENErator:TTS:ATONE:DURation?  
5000

nTone = A or B (Tone A or B)

NOTE
------

**2.5.24 Modulation Generators - Two Tone Sequential Frequency****:MOD:GENErator:TTS:nTONE:FREQuency****:MOD:GENErator:TTS:nTONE:FREQuency?**

**Description:** Set command defines Tone frequency for Modulation Generator.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 2.999 kHz

**Units:** Hz | kHz

**Default Value:** Tone A: 500.0 Hz  
Tone B: 1.0 kHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :MOD:GENErator:TTS:ATONE:FREQuency 150Hz  
Sets Mod Generator Frequency for Tone A to 150.0 Hz.

**Query Response:** :MOD:GENErator:TTS:ATONE:FREQuency?  
150.00

nTone = A or B (Tone A or B)

NOTE
------

## 2.6 EXTERNAL MODULATION GENERATOR

### 2.6.1 External Modulation Source - Enable

**MOD:GENerator:ESource:ENABle**

**MOD:GENerator:ESource:ENABle?**

**Description:** Set command Enables/Disables External Modulation source.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** MOD:GENerator:ESource:ENABle ON  
Enables selected External Modulation source.

**Query Response:** MOD:GENerator:ESource:ENABle?  
1

**NOTE**

RF:ESource:ENABle deprecated in software version 1.7.9.

### 2.6.2 External Modulation Generator - Impedance

**MOD:GENerator:ESource:SOURce:LOAD**

**MOD:GENerator:ESource:SOURce:LOAD?**

**Description:** Set command defines the Impedance of External Modulation source.  
Query command returns parameter setting.

**Parameter:** UNBHI | UNB600

**Default Value:** UNB600

**Set/Query Format:** CPD | CRD

**Example:** MOD:GENerator:ESource:SOURce:LOAD UNBHI  
Sets Impedance of External Source to Unbalanced Hi-Z.

**Query Response:** MOD:GENerator:ESource:SOURce:LOAD?  
UNBHI

**NOTE**

:RF:ESource:SOURce:LOAD deprecated in software version 1.7.9.

### 2.6.3 External Modulation Generator - Level

**MOD:GENerator:ESource:LEVel**

**MOD:GENerator:ESource:LEVel?**

**Description:** Set command defines level of the External Modulation Generator.  
Query command returns parameter setting.

**Range:** 1.0 Hz to 150.0 kHz

**Units:** Hz | kHz

**Default Value:** 2.5 kHz

**Set/Query Format:** NR2 <units> | NR1 <Hz>

**Example:** MOD:GENerator:ESource:LEVel 100kHz  
Sets Level of the External Modulation Generator to 100.0 kHz

**Query Response:** MOD:GENerator:ESource:LEVel?  
10000

#### 2.6.4 External Modulation Generator - Level in Percent

**MOD:GENerator:ESource:LEVel:PERcent**

**MOD:GENerator:ESource:LEVel:PERcent?**

**Description:** Set command defines level of the External Modulation Generator as a percent.  
Query command returns parameter setting.

**Range:** 0.0% to 100%

**Units:** %

**Default Value:** 1.667%

**Set/Query Format:** NR2

**Example:** MOD:GENerator:ESource:LEVel:PERcent 25  
Sets Level of the External Modulation Generator to 25.0%.

**Query Response:** MOD:GENerator:ESource:LEVel:PERcent?  
25

#### 2.6.5 External Modulation Generator - Source

**MOD:GENerator:ESource:SOURce**

**MOD:GENerator:ESource:SOURce?**

**Description:** Set command defines external source for the Modulation Generator.  
Query command returns parameter setting.

**Parameter:** AUD1 | AUD2 | MIC | BAL

**Default Value:** AUD1

**Set/Query Format:** CPD | CRD

**Example:** MOD:GENerator:ESource:SOURce MIC  
Select Microphone as the External Modulation Source.

**Query Response:** MOD:GENerator:ESource:SOURce?  
MIC

**NOTE**

:RF:ESource:SOURce has been deprecated in software version 1.7.9.

## 2.7 RF GENERATOR/TRANSMIT CHANNEL CONFIGURATION

### 2.7.1 RF Generator - Enable

**:RF:GENerator:ENABle**

**:RF:GENerator:ENABle?**

**Description:** Set command Enables/Disables RF Generator.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :RF:GENerator:ENABle ON  
Enables RF Generator.

**Query Response:** :RF:GENerator:ENABle?  
1

### 2.7.2 RF Generator - Frequency

**:RF:GENerator:CH1:FREQuency**

**:RF:GENerator:CH1:FREQuency?**

**Description:** Set command defines RF Generator Frequency.  
Query command returns parameter setting.

**Range:** 100.0 kHz to 2.71 GHz

**Units:** Hz | kHz | MHz | GHz

**Default Value:** 150.0 MHz

**Set/Query Format:** NRf | NR1 (Hz)

**Example:** :RF:GENerator:CH1:FREQuency 850MHz  
Sets RF Generator Frequency to 850.0 MHz.

**Query Response:** :RF:GENerator:CH1:FREQuency?  
850000000

### 2.7.3 RF Generator - Level

**:RF:GENerator:CH1:LEVel**

**:RF:GENerator:CH1:LEVel?**

**Description:** Set command defines RF Generator Level.  
Query command returns parameter setting.

**Range:** **TR:** -138.0 to -30.0 dBm

**GEN** -130.0 to +10.0 dBm  
:

**Units:** dBm

**Default Value:** -30.0 dBm

**Set/Query Format:** NRf | NR2 (dBm)

**Example:** :RF:GENerator:CH1:LEVel -75dBm  
Set RF Generator Level to -75.0 dBm.

**Query Response:** :RF:GENerator:CH1:LEVel?  
-75.0

#### 2.7.4 RF Generator - Level Mode

**:RF:GENerator:CH1:LMODe**

**:RF:GENerator:CH1:LMODe?**

**Description:** Set command defines RF Generator Level type.  
Query command returns parameter setting.

**Parameter:** 0 = PD  
1 = EMF

**Default Value:** 0 (PD)

**Set/Query Format:** NR1

**Example:** :RF:GENerator:CH1:LMODe 1  
Set RF Generator Level to Display value in EMF.

**Query Response:** :RF:GENerator:CH1:LMODe?  
1

#### 2.7.5 RF Generator - Offset Enable

**:CONFigure:OFFSet:GENerator:ENABLE**

**:CONFigure:OFFSet:GENerator:ENABLE?**

**Description:** Set command Enables/Disables RF Generator Offset.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :CONFigure:OFFSet:GENerator:ENABLE ON  
Enables RF Generator Offset.

**Query Response:** :CONFigure:OFFSet:GENerator:ENABLE?  
1

#### 2.7.6 RF Generator - Offset Value

**:CONFigure:OFFSet:GENerator:VALue**

**:CONFigure:OFFSet:GENerator:VALue?**

**Description:** Set command defines RF Generator Offset Value.  
Query command returns parameter setting.

**Range:** -100.0 to +100.0 dB

**Units:** dB

**Default Value:** 0.0 dB

**Set/Query Format:** NRf | NR2 (dB)

**Example:** :CONFigure:OFFSet:GENerator:VALue 2.5dB  
Set RF Generator Offset to 2.5 dB.

**Query Response:** :CONFigure:OFFSet:GENerator:VALue?  
2.5

### 2.7.7 RF Generator - Output Connector

**:RF:GENErator:PORT**

**:RF:GENErator:PORT?**

**Description:** Set command selects the RF Output Connector.  
Query command returns parameter setting.

**Parameter:** TR | GEN

**Default Value:** TR

**Set/Query Format:** CPD | CRD

**Example:** :RF:GENErator:PORT GEN

Selects the GEN (Generator) Connector as RF Output Connector.

**Query Response:** :RF:GENErator:PORT?  
GEN

### 2.7.8 Transmit Channel - Pattern

**:TRANsmit:CH1:PATTern**

**:TRANsmit:CH1:PATTern?**

**Description:** Set command defines Pattern for Transmit Channel.  
Query command returns parameter setting.

**Parameter:**

**ARIB -T98:** STD1031 | STDCAL | STDPN9 | STDPN15

**ARIB -T102:** STD1031 | STD511 | FSWPN9

**Default Value:** STD1031

**Set/Query Format:** CPD | CRD

**Example:** :TRANsmit:CH1:PATTern STDPN9

Sets ARIB STD-T98 Channel to transmit STD PN9 Pattern.

**Query Response:** :TRANsmit:CH1:PATTern?  
STDPN9

**NOTE**

STD PN9 (STD 511) and STD PN15 Patterns are defined per ITU-T definition.  
Valid parameter depends on defined Tx Protocol (:TRANsmit:CH1:PROTOcol ARIB or :TRANsmit:CH1:PROTOcol ARIBT102).

### 2.7.9 Transmit Channel - Protocol

**:TRANsmit:CH1:PROTOcol**

**:TRANsmit:CH1:PROTOcol?**

**Description:** Set command selects Transmit Protocol.  
Query command returns parameter setting.

**Parameter:** ANALOG | ARIB | ARIBT102

**Default Value:** ARIB (ARIB-T98)

**Set/Query Format:** CPD | CRD

**Example:** :TRANsmit:CH1:PROTOcol ANALOG

Sets Tx Channel Protocol to Analog.

**Query Response:** :TRANsmit:CH1:PROTOcol?  
ANALOG

## 2.8 CABLE LOSS MEASUREMENTS

### 2.8.1 Cable Loss - List of Available Files

#### **CONFigure:OFFSet:FILElist?**

**Description:** Query command returns list of available Cable Loss files.

**Query Data Format:** ascii string, space delimited

**Query Response:** CONFigure:OFFSet:FILElist?  
{None} {Cable\_1} { Cable\_2}

**NOTE**

Command is only valid when the Tracking Generator Option is installed in the Test Set.

### 2.8.2 Cable Loss - Load RF Generator Reference File

#### **CONFigure:OFFSet:GENErator:FILE filename**

#### **CONFigure:OFFSet:GENErator:FILE?**

**Description:** Set command loads specified Cable Loss file.  
Query command returns parameter setting.

**Parameter:** filename

**Example:** CONFigure:OFFSet:GENErator:FILE Cable\_1  
Loads Cable Loss File titled Cable\_1.

**Query Response:** CONFigure:OFFSet:GENErator:FILE?  
Cable\_1

**NOTE**

Command is only valid when the Tracking Generator Option is installed in the Test Set.

### 2.8.3 Cable Loss - Load RF Analyzer Reference File

#### **CONFigure:OFFSet:ANALyzer:FILE filename**

#### **CONFigure:OFFSet:ANALyzer:FILE?**

**Description:** Set command loads specified Cable Loss file.  
Query command returns parameter setting.

**Parameter:** filename

**Example:** CONFigure:OFFSet:ANALyzer:FILE Cable\_1  
Loads Cable Loss File titled Cable\_1.

**Query Response:** CONFigure:OFFSet:ANALyzer:FILE?  
Cable\_1

**NOTE**

Command is only valid when the Tracking Generator Option is installed in the Test Set.



## 2.8.4 Cable Loss - Target File for Offset Query

### **CABLEloss:TARGet:FILEName parameter**

**Description:** Set command targets specified Cable Loss file for offset value to be queried.

**Parameter:** filename

**Example:** CABLEloss:TARGet:FILEName Cable\_1  
Targets the Cable Loss File titled Cable\_1.

**Query Response:** CABLEloss:TARGet:FILEName?  
Cable\_1

#### NOTE

Command is only valid when the Tracking Generator Option is installed in the Test Set.

Related commands: CABLEloss:TARGet:FREQUENCY and CABLEloss:TARGet:OFFSet?

## 2.8.5 Cable Loss - Frequency for Offset Query

### **CABLEloss:TARGet:FREQUENCY**

### **CABLEloss:TARGet:FREQUENCY?**

**Description:** Set command defines the frequency in the cable loss file where the offset value is to be returned.

Query command returns defined frequency value.

**Parameter:** 100.0 to 1000.0 MHz

**Units:** Hz | kHz | MHz

**Default Value:** 100.00 MHz

**Set/Query Format:** NRf | NR2 (MHz)

**Example:** CABLEloss:TARGet:FREQUENCY 650MHz  
Targets 650 MHz for Frequency Offset Query.

**Query Response:** CABLEloss:TARGet:FREQUENCY?  
650.0

#### NOTE

Command is only valid when the Tracking Generator Option is installed in the Test Set.

Target file (CABLEloss:TARGet:FILEName) must be defined before sending this command. Offset value is queried using CABLEloss:TARGet:OFFSet? command.

## 2.8.6 Cable Loss - Return Offset Value

### **CABLEloss:TARGet:OFFSet?**

**Description:** Query command queries defined Cable Loss File and returns Offset value at frequency defined in CABLEloss:TARGet:Frequency command.

**Query Response:** CABLEloss:TARGet:OFFSet?  
-0.04

#### NOTE

Command is only valid when the Tracking Generator Option is installed in the Test Set.

Target file (CABLEloss:TARGet:FILEName) and frequency (CABLEloss:TARGet:FREQUENCY) must be defined before sending this command

THIS PAGE INTENTIONALLY LEFT BLANK.

---

## Chapter 3 - Analyzer/Receive Channel Remote Commands

### 3.1 INTRODUCTION

This chapter describes the Remote Commands for configuring ARIB Transmit and Receive System Parameters. Commands are listed alphabetically under Transmit and Receiver headings.

### 3.2 ACQUIRE SIGNAL

#### 3.2.1 Reset Signal Acquisition

##### **:RECeive:RESEt:ACQuisition**

**Description:** Command resets signal acquisition

**Parameter/Query:** none

### 3.3 AUDIO MEASUREMENTS CONFIGURATION

#### 3.3.1 AF Measurements - Filter Type

**:AF:ANALyzer:MFILter**

**:AF:ANALyzer:MFILter?**

**Description:** Set command selects the Audio Analyzer Post Detection Filter.  
Query command returns parameter setting.

**Parameter:** PSOPh | None | LP1 | LP2 | LP3 | LP4 | LP5 | LP6 | LP7 | HP1 | HP2 | HP3 | BP0 | BP1 | BP2 | BP3 | BP4 | BP5 | BP6 | BP7 | BP8 | BP9 | BP10 | BP11 | BP12 | BP13 | BP14 | BP15 | BP16

**where:**

NONE = No Filter	BP2 = 0.3 to 5.0 kHz BP
PSOPh = Psoph (CMESS or CCITT)	BP3 = 0.3 to 20.0 kHz BP
LP1 = 300.0 Hz LP	BP4 = 0.3 to 15.0 kHz BP
LP2 = 5.0 kHz LP	BP5 = 20.0 to 300.0 Hz BP
LP3 = 20.0 kHz LP	BP6 = 0.02 to 3.0 kHz BP
LP4 = 15.0 kHz LP	BP7 = 0.02 to 3.4 kHz BP
LP5 = 3.0 kHz LP	BP8 = 0.02 to 5.0 kHz BP
LP6 = 625.0 kHz LP*	BP9 = 0.02 to 15.0 kHz BP
LP7 = 10.0 kHz LP*	BP10 = 0.02 to 20.0 kHz BP
LP8 = 100.0 Hz LP*	BP11 = 0.05 to 300.0 Hz BP
HP1 = 300.0 Hz HP	BP12 = 0.05 to 3.0 kHz BP
HP2 = 20.0 Hz HP	BP13 = 0.05 to 3.4 kHz BP
HP3 = 50.0 Hz HP	BP14 = 0.05 to 5.0 kHz BP
BP0 = 0.3 to 3.0 kHz BP	BP15 = 0.05 to 15.0 kHz BP
BP1 = 0.3 to 3.4 kHz BP	BP16 = 0.05 to 20.0 kHz BP

**Default Value:** NONE (No Filter)

**Set/Query Format:** CPD | CRD

**Example:** :AF:ANALyzer:MFILter LP3  
Selects 20.0 kHz Low Pass Filter for AF measurements.

**Query Response:** :AF:ANALyzer:MFILter?  
LP3

**NOTE**

Filter selected should be appropriate for signal received from UUT.  
When PSOPH is selected, Filter weight is defined using :CONFigure:AF:MFILter command.  
Test Set does not process any commands following this one until this command is completed.  
\*LP6, LP7 and LP8 are used by the Audio Analyzer Tracking Generator and can not be defined by user, but may be returned as query data.

### 3.3.2 AF Measurements - Filter Weight

**:CONFigure:AF:MFILter**

**:CONFigure:AF:MFILter?**

**Description:** Set command defines the weight of psoph filter for AF Analyzer when Psoph filter is selected.

Query command returns parameter setting.

**Parameter:** CMESs | CCITt

**Default Value:** CMES

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:AF:MFILter CCITt

Selects CCITT Psoph Filter for AF measurement.

**Query Response:** :CONFigure:AF:MFILter?

CCIT

**NOTE**

AF Filter type must be defined as Psoph (:AF:ANALyzer:MFILter PSOPH) for this command to be valid.

### 3.3.3 AF Measurements - Impedance

**:CONFigure:AF:ANALyzer:SOURce:LOAD**

**:CONFigure:AF:ANALyzer:SOURce:LOAD?**

**Description:** Set command defines the Impedance of selected Audio Frequency (Receiver) source.

Query command returns parameter setting.

**Parameter:** UNBHI | UNB600

**Default Value:** Audio Source defined

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:AF:ANALyzer:SOURce:LOAD UNBHI

Sets Impedance of selected Audio Frequency (Receiver) Source to Unbalanced Hi-Z.

**Query Response:** :CONFigure:AF:ANALyzer:SOURce:LOAD?

UNBHI

**NOTE**

Command not valid when AF Analyzer Source is set to Balanced (:CONFigure:AF:ANALyzer:SOURce is set to BAL).

### 3.3.4 AF Measurements - Impedance External Load

**:CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD**  
**:CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD?**

**Description:** Set command defines the Impedance of selected Audio Frequency Analyzer (Receiver) source.  
Query command returns parameter setting.

**Range:** 1 to 9999 Ohms

**Units:** Ohms

**Default Value:** 8 Ohms

**Set/Query Format:** NRf | NR1

**Example:** :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD 100OHMS  
Sets External Load to 100 Ohms for Audio Frequency Analyzer (Receiver).

**Query Response:** :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD?  
100

**NOTE**

Command only valid when Impedance is set to Unbalanced Hi-Z (:CONFigure:AF:ANALyzer:SOURce:LOAD UNBHI).

### 3.3.5 AF Measurements - Impedance External Load Enable

**:CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD:ENABLE**  
**:CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD:ENABLE?**

**Description:** Set command enables External Load for Impedance.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD:ENABLE ON  
Enables and applies defined External Impedance Load.

**Query Response:** :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD:ENABLE?  
1

**NOTE**

Command :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD defines the external load applied when External Load is enabled.

### 3.4 AF ANALYZER - TONE DECODE

#### 3.4.1 AF Analyzer - Clear Decode Log

##### **:AF:ANALyzer:DECODE:LOGS:CLEAR**

**Description:** Command clears all AF data logs for Tone Remote, Tone Sequential and Two Tone Sequential signal types.

**Parameter/Query:** none

#### 3.4.2 AF Analyzer - DCS Decode Value

##### **:FETCh:AF:ANALyzer:DECODE:DCS:VALue?**

**Description:** Command returns decode value of received signal.

**Query Format:** ascii

**Query Response:** :FETCh:AF:ANALyzer:DECODE:DCS:VALue?  
047

#### 3.4.3 AF Analyzer - Decode Protocol

##### **:AF:ANALyzer:DECODE:PROTOcol**

##### **:AF:ANALyzer:DECODE:PROTOcol?**

**Description:** Set command selects Protocol to be decoded by the AF Analyzer.  
Query command returns parameter setting.

**Parameter:** ZVEI1 | ZVEI2 | ZVEI3 | PZVEI | DZVEI | PDZVEI | CCIR1 | CCIR2 | PCCIR |  
EEA | EUROSIG | NATEL | EIA | MODAT

**Default Value:** ZVEI1

**Set/Query Format:** CPD | CRD

**Example:** :AF:ANALyzer:DECODE:PROTOcol PZVEI  
Sets AF Analyzer to decode PZVEI Protocol.

**Query Response:** :AF:ANALyzer:DECODE:PROTOcol?  
PZVEI

#### 3.4.4 AF Analyzer - DTMF Decode Value

##### **:FETCh:AF:ANALyzer:DECODE:DTMF:VALue?**

**Description:** Command returns decode value of received signal.

**Query Format:** ascii

**Query Response:** :FETCh:AF:ANALyzer:DECODE:DTMF:VALue?  
047

### 3.4.5 AF Analyzer - Tone Remote Decode Data

#### **:FETCh:AF:ANALyzer:DECODE:TONEREM:LOG?**

**Description:** Command returns received Tone Remote data.

**Query Data:** <frequency>,<spec frequency>,<% error>,<freq error>,<duration>

**frequency (NR2):** Hz

**spec frequency (NR2):** Hz

**% error (NR2):** percent (%)

**freq error (NR2):** Hz

**duration (NR2):** ms

**no activity:** returned when no log data is available

**Query Response:** :FETCh:AF:ANALyzer:DECODE:TONEREM:LOG?

2173.8,2175.0,0.054,1.2,1422.9

1048.8,1050.0,0.112,1.2,1422.9

2173.8,2175.0,0.054,1.2,1422.9

### 3.4.6 AF Analyzer - Tone Sequential Decode Data

#### **:FETCh:AF:ANALyzer:DECODE:TONESEQ:LOG?**

**Description:** Command returns received Tone Sequential data.

**Query Format:** ascii data string

**Query Data:** <decoded tone>,<frequency>,<spec frequency>,<% error>,<freq error>,<duration>

**decoded tone (hex):** 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | A | B | C | D | E | F

**frequency (NR2):** Hz

**spec frequency (NR2):** Hz

**% error (NR2):** percent (%)

**freq error (NR2):** Hz

**duration (NR2):** ms

**no activity:** returned when no log data is available

**Query Response:** :FETCh:AF:ANALyzer:DECODE:TONESEQ:LOG?

0,2399.4,2400.0,0.024,0.6,85.3

1,1060.5,1060.0,0.052,0.5,64.0

2,1160.2,1160.0,0.013,0.2,74.7

3,1280.3,1270.0,0.809,10.3,74.7

4,1400.4,1400.0,0.028,0.4,74.7



### 3.4.7 AF Analyzer - Two Tone Sequential Decode Data

#### **:FETCh:AF:ANALyzer:DECODE:TWOTONE:LOG?**

**Description:** Command returns received Two Tone Sequential data.

**Query Data:** <frequency>,<duration>

**frequency (NR2):** Hz

**duration (NR2):** ms

**no activity:** returned when no log data is available

**Query Response:** :FETCh:AF:ANALyzer:DECODE:TWOTONE:LOG?  
1004.9,7349.3  
501.0,1013.3  
999.0,3008.0  
501.0,1013.3  
999.0,3008.0

### 3.4.8 AF Analyzer - Decode Signal Type

#### **:AF:ANALyzer:DECODE:TYPE**

#### **:AF:ANALyzer:DECODE:TYPE?**

**Description:** Set command defines type of Signal being Decoded by the Audio Analyzer.  
Query command returns parameter setting.

**Parameter:** OFF | DTMF | TONESEQ | TONEREM | TWOTONE

**Default:** OFF (Demod)

**Set/Query Format:** CPD | CRD

**Example:** :AF:ANALyzer:DECODE:TYPE TONESEQ

Sets type of signal being decoded by Audio Analyzer to Tone Sequential.

**Query Response:** :AF:ANALyzer:DECODE:TYPE?  
TONESEQ

**NOTE**

:AF:ANALyzer:DECODE:TONETYPE was deprecated in software version 1.7.9.

## 3.5 MODULATION ANALYZER - TONE DECODING

### 3.5.1 Modulation Analyzers - Clear Decode Log

#### **:MOD:ANALyzer:DECODE:LOGS:CLEAR**

**Description:** Command clears all modulation data logs for Tone Remote, Tone Sequential and Two Tone Sequential signal types.

**Parameter/Query:** none

### 3.5.2 Modulation Analyzers - DCS Decode Value

#### **:FETCh:MOD:ANALyzer:DECODE:DCS:VALue?**

**Description:** Command returns decode value of received signal.

**Query Format:** ascii

**Query Response:** :FETCh:MOD:ANALyzer:DECODE:DCS:VALue?  
047

### 3.5.3 Modulation Analyzers - Decode Protocol

#### **:MOD:ANALyzer:DECODE:PROTOcol**

#### **:MOD:ANALyzer:DECODE:PROTOcol?**

**Description:** Set command selects Protocol to be decoded by the Modulation Analyzer. Query command returns parameter setting.

**Parameter:** ZVEI1 | ZVEI2 | ZVEI3 | PZVEI | DZVEI | PDZVEI | CCIR1 | CCIR2 | PCCIR | EEA | EUROSIG | NATEL | EIA | MODAT

**Default Value:** ZVEI1

**Set/Query Format:** CPD | CRD

**Example:** :MOD:ANALyzer:DECODE:PROTOcol PZVEI  
Sets Modulation Analyzer to decode PZVEI Protocol.

**Query Response:** :MOD:ANALyzer:DECODE:PROTOcol?  
PZVEI

### 3.5.4 Modulation Analyzers - Decode Signal Tone

#### **:MOD:ANALyzer:DECODE:TYPE**

#### **:MOD:ANALyzer:DECODE:TYPE?**

**Description:** Set command defines type of Signal being Decoded by the Modulation Analyzer. Query command returns parameter setting.

**Parameter:** OFF | DCS | DCSINV | DTMF | TONESEQ | TONEREM | TWOTONE

**Default:** OFF (Demod)

**Set/Query Format:** CPD | CRD

**Example:** :MOD:ANALyzer:DECODE:TYPE DCS  
Sets type of signal being decoded by Modulation Analyzer to DCS.

**Query Response:** :MOD:ANALyzer:DECODE:TYPE?  
DCS

**NOTE**

:MOD:ANALyzer:DECODE:TONETYPE deprecated in software version 1.7.9.

### 3.5.5 Modulation Analyzers - DTMF Decode Value

#### **:FETCh:MOD:ANALyzer:DECODE:DTMF:VALue?**

**Description:** Command returns decode value of received signal.

**Query Format:** ascii

**Query Response:** :FETCh:MOD:ANALyzer:DECODE:DTMF:VALue?  
047

### 3.5.6 Modulation Analyzers - Tone Remote Decoded Data

#### **:FETCh:MOD:ANALyzer:DECODE:TONEREM:LOG?**

**Description:** Command returns received Tone Remote data.

**Query Data:** <frequency>,<spec frequency>,<% error>,<freq error>,<duration>

**frequency (NR2):** Hz

**spec frequency (NR2):** Hz

**% error (NR2):** percent (%)

**freq error (NR2):** Hz

**duration (NR2):** ms

**no activity:** returned when no log data is available

**Query Response:** :FETCh:MOD:ANALyzer:DECODE:TONEREM:LOG?  
2173.8,2175.0,0.054,1.2,1422.9  
1051.8,1050.0,0.167,1.8,1422.9  
2176.8,2175.0,0.081,1.8,1422.9

### 3.5.7 Modulation Analyzers - Tone Sequential Decoded Data

#### **:FETCh:MOD:ANALyzer:DECODE:TONESEQ:LOG?**

**Description:** Command returns received Modulation Tone Sequential data.

**Query Format:** ascii data string

**Query Data:** <decoded tone>,<frequency>,<spec frequency>,<% error>,<freq error>,<duration>

**decoded tone (hex):** 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | A | B | C | D | E | F

**frequency (NR2):** Hz

**spec frequency (NR2):** Hz

**% error (NR2):** percent (%)

**freq error (NR2):** Hz

**duration (NR2):** ms

**no activity:** returned when no log data is available

**Query Response:** :FETCh:MOD:ANALyzer:DECODE:TONESEQ:LOG?  
0,2399.4,2400.0,0.024,0.6,74.7  
1,1057.6,1060.0,0.225,2.4,74.7  
2,1163.1,1160.0,0.266,3.1,64.0  
3,1274.4,1270.0,0.348,4.4,74.7  
4,1400.4,1400.0,0.028,0.4,74.7

### 3.5.8 Modulation Analyzers - Two Tone Sequential Decoded Data

#### **:FETCh:MOD:ANALyzer:DECODE:TWOTONE:LOG?**

**Description:** Command returns received Two Tone Sequential data.

**Query Data:** <frequency>,<duration>

**frequency (NR2):** Hz

**duration (NR2):** ms

**no activity:** returned when no log data is available

**Query Response:** :FETCh:MOD:ANALyzer:DECODE:TWOTONE:LOG?  
501.0,1013.3  
1002.0,3008.0

## 3.6 RECEIVER (ANALYZER) CONFIGURATION

### 3.6.1 Function Generator / Demod Out Connector

**:CONFigure:PORT:FGEN**

**:CONFigure:PORT:FGEN?**

**Description:** Set command selects Function Generator / Demod Out Connector.  
Query command returns parameter setting.

**Parameter:** FGEN | AUDio | DEMod

**Default Value:** FGEN

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:PORT:FGEN DEMod  
Selects Demod as the Function Generator / Demod Out Connector.

**Query Response:** :CONFigure:PORT:FGEN?  
DEM

### 3.6.2 RF Analyzer - AutoTune Frequency Resolution Value

**:CONFigure:RF:ANALyzer:FMODE:FRESolution**

**:CONFigure:RF:ANALyzer:FMODE:FRESolution?**

**Description:** Set command defines AutoTune Frequency Resolution value when AutoTune is enabled.  
Query command returns parameter setting.

**Parameter:** 1 | 10 | 100 | 1000

**Units:** Hz

**Default Value:** 1 Hz

**Set/Query Format:** NRf | NR1

**Example:** :CONFigure:RF:ANALyzer:FMODE:FRESolution 10  
Sets AutoTune Threshold to 10 Hz.

**Query Response:** :CONFigure:RF:ANALyzer:FMODE:FRESolution?  
10

### 3.6.3 RF Analyzer - AutoTune Mode of Operation

**:RF:ANALyzer:FMODE**

**:RF:ANALyzer:FMODE?**

**Description:** Set command selects AutoTune Frequency mode of operation.  
Query command returns parameter setting.

**Parameter:** AUTo | MANual

**Default Value:** Manual

**Set/Query Format:** CPD | CRD

**Example:** :RF:ANALyzer:FMODE AUTO  
Sets RF Analyzer to Autotune received frequency.

**Query Response:** :RF:ANALyzer:FMODE?  
AUT

**NOTE**

AutoTune must be set to Manual to enter a specific Receive frequency.

### 3.6.4 RF Analyzer - AutoTune Operating Status

#### **:RF:ANALyzer:FMODE:STATUs?**

**Description:** Command indicates whether AutoTune frequency search is running or complete.

**Query Data:** 0 = Search complete  
1 = Searching

**Query Format:** NR1

**Query Response:** :RF:ANALyzer:FMODE:STATUs?  
1

**NOTE**

This command has been deprecated in software version 3.7.0. Replace the command with :RF:ANALyzer:FMODE:STATE command to avoid script failures.

### 3.6.5 RF Analyzer - AutoTune Start Frequency

#### **:RF:ANALyzer:FMODE:START**

#### **:RF:ANALyzer:FMODE:START?**

**Description:** Set command defines Start Frequency of AutoTune range.  
Query command returns parameter setting.

**Range:** 100.0 kHz to 2.71 GHz

**Units:** Hz | kHz | MHz | GHz

**Default Value:** 10.0 MHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :RF:ANALyzer:FMODE:START 20kHz  
Sets AutoTune Start Frequency to 20.0 kHz.

**Query Response:** :RF:ANALyzer:FMODE:START?  
200000.00 (Hz)

**NOTE**

AutoTune mode must be set to Auto for command to be valid.

### 3.6.6 RF Analyzer - AutoTune Start Frequency Enable

#### **:RF:ANALyzer:FMODE:START:ENABLE**

#### **:RF:ANALyzer:FMODE:START:ENABLE?**

**Description:** Set command activates/deactivates AutoTune Start frequency.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :RF:ANALyzer:FMODE:START:ENABLE ON  
Activates AutoTune Start frequency.

**Query Response:** :RF:ANALyzer:FMODE:START:ENABLE?  
1

**NOTE**

Command only valid when AutoTune mode of operation is set to Auto.

### 3.6.7 RF Analyzer - AutoTune Stop Frequency

**:RF:ANALyzer:FMODE:STOP**

**:RF:ANALyzer:FMODE:STOP?**

**Description:** Set command defines the Stop Frequency of AutoTune range.  
Query command returns parameter setting.

**Parameter:** 100.0 kHz to 2.71 GHz

**Units:** Hz | kHz | MHz | GHz

**Default Value:** 500.0 MHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :RF:ANALyzer:FMODE:STOP 650MHz  
Sets RF Analyzer AutoTune Stop Frequency to 650.0 MHz.

**Query Response:** :RF:ANALyzer:FMODE:STOP?  
650000000.00

**NOTE**

Command only valid when AutoTune mode of operation is set to Auto.

### 3.6.8 RF Analyzer - AutoTune Stop Frequency Enable

**:RF:ANALyzer:FMODE:STOP:ENABLE**

**:RF:ANALyzer:FMODE:STOP:ENABLE?**

**Description:** Set command enables/disables AutoTune Stop Frequency.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :RF:ANALyzer:FMODE:STOP:ENABLE ON  
Activates AutoTune Stop Frequency.

**Query Response:** :RF:ANALyzer:FMODE:STOP:ENABLE?  
1

**NOTE**

Command only valid when AutoTune mode of operation is set to Auto.

### 3.6.9 RF Analyzer - AutoTune Threshold Value

**:RF:ANALyzer:FMODE:THREsh**

**:RF:ANALyzer:FMODE:THREsh?**

**Description:** Set command defines the AutoTune Threshold value.  
Query command returns parameter setting.

**Range:** -75.0 to +20.0 dBm

**Units:** dBm

**Default Value:** -30.0 dBm

**Set/Query Format:** NRF | NR2

**Example:** RF:ANALyzer:FMODE:THREsh -45dBm  
Sets AutoTune Threshold value to -45.0 dBm.

**Query Response:** RF:ANALyzer:FMODE:THREsh?  
-45.000000

**NOTE**

:CONFigure:RF:ANALyzer:THREsh command also supported for this function.

### 3.6.10 RF Analyzer - Frequency

**:RF:ANALyzer:CH1:FREQuency**

**:RF:ANALyzer:CH1:FREQuency?**

**Description:** Set command defines the RF Analyzer Frequency for signal.  
Query command returns parameter setting.

**Range:** 20.0 kHz to 2.71 GHz

**Units:** Hz | kHz | MHz | GHz

**Default Value:** 150.0 MHz

**Set/Query Format:** NRF | NR1 (Hz)

**Example:** :RF:ANALyzer:CH1:FREQuency 650MHz  
Sets RF Analyzer Frequency to 650.0 MHz.

**Query Response:** :RF:ANALyzer:CH1:FREQuency?  
650000000

### 3.6.11 RF Analyzer - Input Connector

**:RF:ANALyzer:PORT**

**:RF:ANALyzer:PORT?**

**Description:** Set command selects the RF Input Connector.  
Query command returns parameter setting.

**Parameter:** TR | ANT

**Default Value:** TR

**Set/Query Format:** CPD | CRD

**Example:** :RF:ANALyzer:PORT ANT  
Selects Antenna Connector as RF Input Connector.

**Query Response:** :RF:ANALyzer:PORT?  
ANT

**NOTE**

Refer to 3900 Platform Specifications for maximum input values.



### 3.6.12 RF Analyzer - FM IF Bandwidth

**:RF:ANALyzer:FMIF**

**:RF:ANALyzer:FMIF?**

**Description:** Set command defines the FM IF Bandwidth.  
Query command returns parameter setting.

**Parameter:** 12.5 kHz | 30.0 kHz | 100.0 kHz

**Default Value:** 12.5 kHz

**Set/Query Format:** NRf | NR2

**Example:** :RF:ANALyzer:FMIF 30kHz

Sets RF Analyzer FM IF Bandwidth to 30.0 kHz.

**Query Response:** :RF:ANALyzer:FMIF?  
30.0kHz

**NOTE**

IF Bandwidth applies to ANALOG Protocol.

### 3.6.13 RF Analyzer - Offset Enable

**:CONFigure:OFFSet:ANALyzer:ENABLE**

**:CONFigure:OFFSet:ANALyzer:ENABLE?**

**Description:** Set command Enables/Disables the RF Analyzer Offset.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :CONFigure:OFFSet:ANALyzer:ENABLE ON

Enables RF Analyzer Offset.

**Query Response:** :CONFigure:OFFSet:ANALyzer:ENABLE?  
1

### 3.6.14 RF Analyzer - Offset Mode of Operation

**:RECEive:CH1:LOCK**

**:RECEive:CH1:LOCK?**

**Description:** Set command defines the RF Analyzer Offset mode of operation.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF (Unlocked)

**Set/Query Format:** Boolean

**Example:** :RECEive:CH1:LOCK ON

Locks Frequency Offset to RF Analyzer Frequency.

**Query Response:** :RECEive:CH1:LOCK?  
1

**NOTE**

Offset value defaults to 0.0 unless defined by user.

### 3.6.15 RF Analyzer - Offset Value

**:CONFigure:OFFSet:ANALyzer:VALue**  
**:CONFigure:OFFSet:ANALyzer:VALue?**

**Description:** Set command defines the RF Analyzer Offset Value.  
Query command returns parameter setting.

**Range:** -40.0 to +40.0 dB

**Units:** dB

**Default Value:** 0.0 dB

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :CONFigure:OFFSet:ANALyzer:VALue -10dB  
Sets RF Analyzer Offset to -10.0 dB.

**Query Response:** :CONFigure:OFFSet:ANALyzer:VALue?  
-10.00

### 3.6.16 Receiver - Pre-Amplifier Enable

**:RF:ANALyzer:RECeiver:AMP**  
**:RF:ANALyzer:RECeiver:AMP?**

**Description:** Set command Enables/Disables Receiver Pre-Amplifier.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :RF:ANALyzer:RECeiver:AMP ON  
Enables Receiver Pre-Amplifier.

**Query Response:** :RF:ANALyzer:RECeiver:AMP?  
1

### 3.6.17

### 3.6.18 RF Analyzer - Receive Offset

**:RF:ANALyzer:CH1:OFFSet**  
**:RF:ANALyzer:CH1:OFFSet?**

**Description:** Set command defines the Receive Offset Value.  
Query command returns parameter setting.

**Range:** -999.0 to +999.0 MHz

**Units:** Hz | kHz | MHz | GHz

**Default Value:** 0.0 MHz

**Set/Query Format:** NRf | NR2 (Hz)

**Example:** :RF:ANALyzer:CH1:OFFSet -100kHz  
Sets Receive Offset to -100.0 kHz.

**Query Response:** :RF:ANALyzer:CH1:OFFSet?  
-100000.00

### 3.6.19 Receive Channel - Protocol

**:RECEive:CH1:PROTOcol**

**:RECEive:CH1:PROTOcol?**

**Description:** Set command selects Receive Channel Protocol.  
Query command returns parameter setting.

**Parameter:** ANALOG | ARIB | ARIBT102

**Default Value:** ARIB (ARIB-T98)

**Set/Query Format:** CPD | CRD

**Example:** :RECEive:CH1:PROTOcol ANALOG  
Sets Rx Channel Protocol to Analog.

**Query Response:** :RECEive:CH1:PROTOcol?  
ANALOG

THIS PAGE INTENTIONALLY LEFT BLANK.

---

## Chapter 4 - ARIB Signal Meter Remote Commands

### 4.1 INTRODUCTION

This chapter describes the Remote Commands used for configuring and obtaining ARIB signal measurement data. Remote Commands are listed alphabetically by meter name.

### 4.2 RESET MEASUREMENT DATA

#### 4.2.1 Reset Signal Acquisition

##### **:RECEive:RESET:ACQuisition**

**Description:** Command resets signal acquisition

**Parameter/Query:** none

### 4.3 BIT ERROR RATE (BER)

#### 4.3.1 Bit Error Rate - Averages

##### **:METERs:BER:CH1:AVERaging**

##### **:METERs:BER:CH1:AVERaging?**

**Description:** Set command defines number of readings taken to calculate Average Bit Error Rate measurement.

Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :METERs:BER:CH1:AVERaging 100

Sets the number of readings taken to calculate Average Bit Error Rate measurement to 100.

**Query Response:** :METERs:BER:CH1:AVERaging?  
100

#### 4.3.2 Bit Error Rate - Average Measurement Reset

##### **:METERs:BER:CH1:CLEAR:AVG**

**Description:** Command clears and resets Average Bit Error Rate measurement.

**Parameter/Query:** none

### 4.3.3 Bit Error Rate - Lower Limit Enable

**:LIMits:BER:CH1:LOWer:ENABle**

**:LIMits:BER:CH1:LOWer:ENABle?**

**Description:** Set command Enables/Disables Lower Limit for Bit Error Rate measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:BER:CH1:LOWer:ENABle ON  
Enables Lower Limit for Bit Error Rate measurement.

**Query Response:** :LIMits:BER:CH1:LOWer:ENABle?  
1

### 4.3.4 Bit Error Rate - Lower Limit Value

**:LIMits:BER:CH1:LOWer:VALue**

**:LIMits:BER:CH1:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Bit Error Rate Measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 100.0%

**Units:** % (percent)

**Default Value:** 0.0%

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:BER:CH1:LOWer:VALue 1  
Sets Lower Limit Value for Bit Error Rate Measurement to 1.0%.

**Query Response:** :LIMits:BER:CH1:LOWer:VALue?  
1.0000000000

### 4.3.5 Bit Error Rate - Measurement Query

**:METERs:BER:CH1:STATus?**

**Description:** Command returns Bit Error Rate measurement data.

**Query Data:** <statusbyte>,<failbyte>,<precision>,<percentage>,<avg>,<max>,<min>,<units>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :METERs:BER:CH1:STATus?  
0,0,10, 100.000, 0.0099751540,0.0100574717,0.0000000000,0

### 4.3.6 Bit Error Rate - Peak Measurement Reset

**:METERs:BER:CH1:CLear:PEAK**

**Description:** Command clears and resets Peak Bit Error Rate measurement.

**Parameter/Query:** none

### 4.3.7 Bit Error Rate - Receive Pattern

**:METERs:BER:PATtern**  
**:METERs:BER:PATtern?**

**Description:** Set command defines Receive Pattern for Bit Error Rate measurement.  
 Query command returns parameter setting.

**Parameter:**

**ARIB -T98:** STD1031 | STDCAL | STDPN9 | STDPN15

**ARIB -T102:** STD1031 | STD511 | FSWPN9

**Default Value:** STD1031

**Set/Query Format:** CPD | CRD

**Example:** :METERs:BER:PATtern STDCAL

Sets Receive Pattern for Bit Error Rate measurement to STD CAL Pattern.

**Query Response:** :METERs:BER:PATtern?

STDCAL

**NOTE**

STD PN9 (STD 511) and STD PN15 Patterns are defined per ITU-T definition.  
 Valid parameter depends on defined Rx Protocol (:RECeive:CH1:PROTOcol ARIB or :RECeive:CH1:PROTOcol ARIBT102).

### 4.3.8 Bit Error Rate - Upper Limit Enable

**:LIMits:BER:CH1:UPPer:ENABle**  
**:LIMits:BER:CH1:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for Bit Error Rate measurement.  
 Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:BER:CH1:UPPer:ENABle ON

Enables Upper Limit for Bit Error Rate measurement.

**Query Response:** :LIMits:BER:CH1:UPPer:ENABle?

1

### 4.3.9 Bit Error Rate - Upper Limit Value

**:LIMits:BER:CH1:UPPer:VALue**  
**:LIMits:BER:CH1:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for Bit Error Rate measurement.  
 Query command returns parameter setting.

**Range:** 0.0 to 100.0%

**Units:** % (percent)

**Default Value:** 0.0%

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:BER:CH1:UPPer:VALue 5

Sets Upper Limit Value for Bit Error Rate measurements to 5%.

**Query Response:** :LIMits:BER:CH1:UPPer:VALue?

5.0000000000

## 4.4 BROADBAND POWER

### 4.4.1 Broadband Power - Averages

**:CONFigure:RF:ANALyzer:TRBPower:AVERAge**  
**:CONFigure:RF:ANALyzer:TRBPower:AVERAge?**

**Description:** Set command defines number of readings taken to calculate Average Broadband Power measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:RF:ANALyzer:TRBPower:AVERAge 25  
Sets number of readings taken to calculate Average Broadband Power measurement to 25.

**Query Response:** :CONFigure:RF:ANALyzer:TRBPower:AVERAge?  
25

### 4.4.2 Broadband Power - Lower Limit Enable

**:LIMits:RF:TRBPower:LOWer:ENABLE**  
**:LIMits:RF:TRBPower:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Broadband Power measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:RF:TRBPower:LOWer:ENABLE ON  
Enables Lower Limit for Broadband Power measurement.

**Query Response:** :LIMits:RF:TRBPower:LOWer:ENABLE?  
1

### 4.4.3 Broadband Power - Lower Limit Value

**:LIMits:RF:TRBPower:LOWer:VALue**  
**:LIMits:RF:TRBPower:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Broadband Power measurement.  
Query command returns parameter setting.

**Range:** -140.0 to +70.0 dBm

**Units:** mW | W | dBW | dBm

**Default Value:** 100.0  $\mu$ W

**Set/Query Format:** NRf | NR2 (W)

**Example:** :LIMits:RF:TRBPower:LOWer:VALue -45dBm  
Sets Lower Limit Value for Broadband measurement to -45.0 dBm.

**Query Response:** :LIMits:RF:TRBPower:LOWer:VALue?  
0.0



#### 4.4.4 Broadband Power - Measurement Query

##### **:FETCh:RF:ANALyzer:TRBPower? <units>**

**Description:** Command returns Broadband Power measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Units:** W | dBW | dBM

**Query Response:** :FETCh:RF:ANALyzer:TRBPower? DBW  
1,5,1,0.0013

**NOTE**

RF Input must be set to TR to return valid data.

#### 4.4.5 Broadband Power - Peak Measurement Query

##### **:FETCh:RF:ANALyzer:TRBPower:HOLD?**

**Description:** Command returns Peak Broadband Power measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Units:** W | dBW | dBM

**Query Response:** :FETCh:RF:ANALyzer:TRBPower:HOLD?  
1,5,0.0091

**NOTE**

RF Input must be set to TR to return valid data.

#### 4.4.6 Broadband Power - Units

##### **:CONFigure:RF:ANALyzer:TRBPower:UNIts**

##### **:CONFigure:RF:ANALyzer:TRBPower:UNIts?**

**Description:** Set command defines the unit of measurement for Broadband Power measurement.

Query command returns parameter setting.

**Parameter:** W | dBW | dBm

**Default Value:** W

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:RF:ANALyzer:TRBPower:UNIts DBW  
Displays Broadband Power measurement in dBW.

**Query Response:** :CONFigure:RF:ANALyzer:TRBPower:UNIts?  
DBW

#### 4.4.7 Broadband Power - Upper Limit Enable

**:LIMits:RF:TRBPower:UPPer:ENABLE**

**:LIMits:RF:TRBPower:UPPer:ENABLE?**

**Description:** Set command Enables/Disables Upper Limit for Broadband Power measurement.

Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:RF:TRBPower:UPPer:ENABLE ON

Enables Upper Limit for Broadband Power measurement.

**Query Response:** :LIMits:RF:TRBPower:UPPer:ENABLE?

1

#### 4.4.8 Broadband Power - Upper Limit Value

**:LIMits:RF:TRBPower:UPPer:VALue**

**:LIMits:RF:TRBPower:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for Broadband Power measurement.  
Query command returns parameter setting.

**Range:** -140.0 to +70.0 dBm

**Units:** mW | W | dBW | dBm

**Default Value:** 100.0  $\mu$ W

**Set/Query Format:** NRf | NR2 (W)

**Example:** :LIMits:RF:TRBPower:UPPer:VALue -25dBm

Sets Upper Limit Value for Broadband Power measurement to -25.0 dBm.

**Query Response:** :LIMits:RF:TRBPower:UPPer:VALue?

0.0

## 4.5 FREQUENCY CORRECTION

### 4.5.1 Frequency Error - Average

**:METERs:FCR:CH1:AVERaging**  
**:METERs:FCR:CH1:AVERaging?**

**Description:** Set command defines the number of readings taken to calculate Average Frequency Error measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :METERs:FCR:CH1:AVERaging 100  
Sets the number of readings taken to calculate Average Frequency Error measurement to 100.

**Query Response:** :METERs:FCR:CH1:AVERaging?  
100

### 4.5.2

### 4.5.3 Frequency Error - Average Measurement Reset

**:METERs:FCR:CH1:CLEAR:AVG**

**Description:** Command clears and resets Average Frequency Correction measurement.

**Parameter/Query:** none

### 4.5.4 Frequency Error - Lower Limit Enable

**:LIMits:FCR:CH1:LOWer:ENABLE**  
**:LIMits:FCR:CH1:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Frequency Correction measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:FCR:CH1:LOWer:ENABLE ON  
Enables Lower Limit for Frequency Correction measurement.

**Query Response:** :LIMits:FCR:CH1:LOWer:ENABLE?  
1

#### 4.5.5 Frequency Error - Lower Limit Value

**:LIMits:FCR:CH1:LOWer:VALue**

**:LIMits:FCR:CH1:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Frequency Correction measurement.

Query command returns parameter setting.

**Range:** -2000.0 to +2000.0 Hz

**Units:** Hz

**Default Value:** 0.0 Hz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:FCR:CH1:LOWer:VALue 250Hz

Sets Lower Limit Value for Frequency Correction measurement to 250.0 Hz.

**Query Response:** :LIMits:FCR:CH1:LOWer:VALue?  
250.00

#### 4.5.6 Frequency Error - Measurement Query

**:METERs:FCR:CH1:STATus?**

**Description:** Command returns Frequency Error measurement data.

**Query Data:** <statusbyte>,<failbyte>,<precision>,<percentage>,<avg>,<max>,<min>,<units>

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**NOTE**

**Query Response:** :METERs:FCR:CH1:STATus?  
0,0,3 100.00, -0.044, 0.204, -16.907,2

#### 4.5.7 Frequency Error - Peak Measurement Reset

**:METERs:FCR:CH1:CLEAR:PEAK**

**Description:** Command clears and resets Peak Frequency Correction measurement.

**Parameter/Query:** none

#### 4.5.8 Frequency Error - Upper Limit Enable

**:LIMits:FCR:CH1:UPPer:ENABLE**

**:LIMits:FCR:CH1:UPPer:ENABLE?**

**Description:** Set command Enables/Disables Upper Limit for Frequency Correction measurement.

Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:FCR:CH1:UPPer:ENABLE ON

Enables Upper Limit for Frequency Correction measurement.

**Query Response:** :LIMits:FCR:CH1:UPPer:ENABLE?  
1

#### 4.5.9 Frequency Error - Upper Limit Value

**:LIMits:FCR:CH1:UPPer:VALue**

**:LIMits:FCR:CH1:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for Frequency Correction measurement.  
Query command returns parameter setting.

**Range:** -2000.0 to +2000.0 Hz

**Units:** Hz

**Default Value:** 0.0 Hz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:FCR:CH1:UPPer:VALue 500Hz  
Sets Upper Limit Value for Frequency Correction measurements to 500.0 Hz.

**Query Response:** :LIMits:FCR:CH1:UPPer:VALue?  
500.00

## 4.6 FSK ERROR

### 4.6.1 FSK Error - Averages

**:METERs:FSKERR:CH1:AVERaging**

**:METERs:FSKERR:CH1:AVERaging?**

**Description:** Set command defines number of readings taken to calculate Average FSK Error measurement.

Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :METERs:FSKERR:CH1:AVERaging 100

Sets the number of readings taken to calculate Average FSK Error measurement to 100.

**Query Response:** :METERs:FSKERR:CH1:AVERaging?  
100

### 4.6.2 FSK Error - Average Measurement Reset

**:METERs:FSKERR:CH1:CLEAR:AVG**

**Description:** Command clears and resets Average FSK Error measurement.

**Parameter/Query:** none

### 4.6.3 FSK Error - Lower Limit Enable

**:LIMits:FSKERR:CH1:LOWer:ENABLE**

**:LIMits:FSKERR:CH1:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for FSK Error measurement.

Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:FSKERR:CH1:LOWer:ENABLE ON

Enables Lower Limit for FSK Error measurement.

**Query Response:** :LIMits:FSKERR:CH1:LOWer:ENABLE?  
1

#### 4.6.4 FSK Error - Lower Limit Value

**:LIMits:FSKERR:CH1:LOWer:VALue**  
**:LIMits:FSKERR:CH1:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for FSK Error measurement.  
 Query command returns parameter setting.

**Range:** 0.0 to 200.0%

**Units:** % (percent)

**Default Value:** 0.0%

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:FSKERR:CH1:LOWer:VALue 100  
 Sets Lower Limit Value for FSK Error measurement to 100.0%.

**Query Response:** :LIMits:FSKERR:CH1:LOWer:VALue?  
 100.00

#### 4.6.5 FSK Error - Measurement Query

**:METERs:FSKERR:CH1:STATus?**

**Description:** Command returns FSK Error measurement data.

**Query Data:** <statusbyte>,<failbyte>,<precision>,<percentage>,<avg>,<max>,<min>,<units>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query:** :METERs:FSKERR:CH1:STATus?

**Response:** 0,0,3, 100.000, 0.581, 113.982, 0.000,1

#### 4.6.6 FSK Error - Measurement Type

**:METERs:FSKERR:CH1:MODE**  
**:METERs:FSKERR:CH1:MODE?**

**Description:** Set command defines FSK Error measurement type.  
 Query command returns parameter setting.

**Parameter:** PEAK | AVERAge

**Default Value:** PEAK

**Set/Query Format:** CPD | CRD

**Example:** :METERs:FSKERR:CH1:MODE AVERAge  
 Sets FSK Error measurement to Average.

**Query Response:** :METERs:FSKERR:CH1:MODE?  
 AVER

#### 4.6.7 FSK Error - Peak Measurement Reset

**:METERs:FSKERR:CH1:CLEAR:PEAK**

**Description:** Command clears and resets Peak FSK Error measurement.

**Parameter/Query:** none

#### 4.6.8 FSK Error - Upper Limit Enable

**:LIMits:FSKERR:CH1:UPPer:ENABle**

**:LIMits:FSKERR:CH1:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for FSK Error measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:FSKERR:CH1:UPPer:ENABle ON  
Enables Upper Limit for FSK Error measurement.

**Query Response:** :LIMits:FSKERR:CH1:UPPer:ENABle?  
1

#### 4.6.9 FSK Error - Upper Limit Value

**:LIMits:FSKERR:CH1:UPPer:VALue**

**:LIMits:FSKERR:CH1:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for FSK Error measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 200.0%

**Units:** % (percent)

**Default Value:** 0.0%

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:FSKERR:CH1:UPPer:VALue 100  
Sets Upper Limit Value for FSK Error measurement to 100.0%.

**Query Response:** :LIMits:FSKERR:CH1:UPPer:VALue?  
100.00



## 4.7 SIGNAL POWER

### 4.7.1 Signal Power - Averages

**:METERs:POWer:CH1:AVERaging**

**:METERs:POWer:CH1:AVERaging?**

**Description:** Set command defines the number of readings taken to calculate Average Signal Power measurement.

Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :METERs:POWer:CH1:AVERaging 100

Sets the number of readings taken to calculate Average Signal Power measurement to 100.

**Query Response:** :METERs:POWer:CH1:AVERaging?  
100

### 4.7.2 Signal Power - Average Measurement Reset

**:METERs:POWer:CH1:CLEAR:AVG**

**Description:** Command clears and resets Average Signal Power measurement.

**Parameter/Query:** none

### 4.7.3 Signal Power - Lower Limit Enable

**:LIMits:POWer:CH1:LOWer:ENABLE**

**:LIMits:POWer:CH1:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Signal Power measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:POWer:CH1:LOWer:ENABLE ON

Enables Lower Limit for Signal Power measurement.

**Query Response:** :LIMits:POWer:CH1:LOWer:ENABLE?  
1

#### 4.7.4 Signal Power - Lower Limit Value

**:LIMits:POWer:CH1:LOWer:VALue**

**:LIMits:POWer:CH1:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Signal Power measurement.  
Query command returns parameter setting.

**Range:** -140.0 to +70.0 dBm

**Units:** dBm

**Default Value:** 0.0 dBm

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:POWer:CH1:LOWer:VALue -90dBm  
Sets Lower Limit Value for Signal Power measurement to -90.0 dBm.

**Query Response:** :LIMits:POWer:CH1:LOWer:VALue?  
-90.00

#### 4.7.5 Signal Power - Measurement Query

**:METERs:POWer:CH1:STATus?**

**Description:** Command returns Signal Power measurement data.

**Query Data:** <statusbyte>,<failbyte>,<precision>,<percentage>,<avg>,<max>,<min>,<units>  
Refer to Chapter 1 for UUT Measurement Meter Return Data.

**NOTE**

**Query Response:** :METERs:POWer:CH1:STATus?  
0,0,3 100.00, -30.183, -30.140, -30.241,6

#### 4.7.6 Signal Power - Measurement Type

**:METERs:POWer:TYPE**

**:METERs:POWer:TYPE?**

**Description:** Set command defines Signal Power measurement type.  
Query command returns parameter setting.

**Parameter:** AVER | MAX | MIN

**Default Value:** PEAK

**Set/Query Format:** CPD | CRD

**Example:** :METERs:POWer:TYPE AVER  
Sets Signal Power measurement to Average.

**Query Response:** :METERs:POWer:TYPE?  
AVER

#### 4.7.7 Signal Power - Peak Measurement Reset

**:METERs:POWer:CH1:CLEAR:PEAK**

**Description:** Command clears and resets Peak Signal Power measurement.

**Parameter/Query:** none

#### 4.7.8 Signal Power - Units

**:METERs:POWer:UNIts**

**:METERs:POWer:UNIts?**

**Description:** Set command defines the unit of measurement for Signal Power measurement.  
Query command returns parameter setting.

**Parameter:** dBm | W | dBW | V | dB $\mu$ V

**Default Value:** dBm

**Set/Query Format:** CPD | CRD

**Example:** :METERs:POWer:UNIts W  
Displays Signal Power measurement in Watts.

**Query Response:** :METERs:POWer:UNIts?  
W

#### 4.7.9 Signal Power - Upper Limit Enable

**:LIMits:POWer:CH1:UPPer:ENABle**

**:LIMits:POWer:CH1:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for Signal Power measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:POWer:CH1:UPPer:ENABle ON  
Enables Upper Limit for Signal Power measurement.

**Query Response:** :LIMits:POWer:CH1:UPPer:ENABle?  
1

#### 4.7.10 Signal Power - Upper Limit Value

**:LIMits:POWer:CH1:UPPer:VALue**

**:LIMits:POWer:CH1:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for Signal Power measurement.  
Query command returns parameter setting.

**Range:** -140.0 to +70.0 dBm

**Units:** dBm

**Default Value:** 0.0 dBm

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:POWer:CH1:UPPer:VALue -80dBm  
Sets Upper Limit Value for Signal Power measurements to -80.0 dBm.

**Query Response:** :LIMits:POWer:CH1:UPPer:VALue?  
-80.00

## 4.8 SYMBOL CLOCK ERROR

### 4.8.1 Symbol Clock Error - Averages

**:METERs:SCE:CH1:AVERaging**  
**:METERs:SCE:CH1:AVERaging?**

**Description:** Set command defines the number of readings taken to calculate Average Symbol Clock Error measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :METERs:SCE:CH1:AVERaging 100

Sets the number of readings taken to calculate Average Symbol Clock Error measurement to 100.

**Query Response:** :METERs:SCE:CH1:AVERaging?  
100

### 4.8.2 Symbol Clock Error - Average Measurement Reset

**:METERs:SCE:CH1:CLEAR:AVG**

**Description:** Command clears and resets Average Symbol Clock Error measurement.

**Parameter/Query:** none

### 4.8.3 Symbol Clock Error - Lower Limit Enable

**:LIMits:SCE:CH1:LOWer:ENABLE**  
**:LIMits:SCE:CH1:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Symbol Clock Error measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:SCE:CH1:LOWer:ENABLE ON

Enables Lower Limit for Symbol Clock Error measurement.

**Query Response:** :LIMits:SCE:CH1:LOWer:ENABLE?  
1

**4.8.4 Symbol Clock Error - Lower Limit Value****:LIMits:SCE:CH1:LOWer:VALue****:LIMits:SCE:CH1:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Symbol Clock Error measurement.  
Query command returns parameter setting.

**Range:** 0.0 to +1000.0 mHz

**Units:** mHz

**Default Value:** 0.0 mHz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:SCE:CH1:LOWer:VALue -500mHz  
Sets Lower Limit Value for Symbol Clock Error measurement to -500.0 mHz.

**Query Response:** :LIMits:SCE:CH1:LOWer:VALue?  
-500.00

**4.8.5 Symbol Clock Error - Measurement Query****:METERs:SCE:CH1:STATus?**

**Description:** Command returns Symbol Clock Error measurement data.

**Query Data:** <statusbyte>,<failbyte>,<precision>,<percentage>,<avg>,<max>,<min>,<units>

Refer to Chapter 1 for UUT Measurement Meter Return Data.

NOTE
------

**Query Response:** :METERs:SCE:CH1:STATus?  
0,0,3 100.00, -2.487, -0.346, -6.642,18

**4.8.6 Symbol Clock Error - Peak Measurement Reset****:METERs:SCE:CH1:CLEAR:PEAK**

**Description:** Command clears and resets Peak Symbol Clock Error measurement.

**Parameter/Query:** none

**4.8.7 Symbol Clock Error - Upper Limit Enable****:LIMits:SCE:CH1:UPPer:ENABLE****:LIMits:SCE:CH1:UPPer:ENABLE?**

**Description:** Set command Enables/Disables Upper Limit for Symbol Clock Error measurement.

Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:SCE:CH1:UPPer:ENABLE ON  
Enables Upper Limit for Symbol Clock Error measurement.

**Query Response:** :LIMits:SCE:CH1:UPPer:ENABLE?  
1

#### 4.8.8 Symbol Clock Error - Upper Limit Value

**:LIMits:SCE:CH1:UPPer:VALue**

**:LIMits:SCE:CH1:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for Symbol Clock Error measurement.  
Query command returns parameter setting.

**Range:** 0.0 to +1000.0 mHz

**Units:** mHz

**Default Value:** 0.0 mHz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:SCE:CH1:UPPer:VALue 500mHz  
Sets Upper Limit Value for Symbol Clock Error measurement to 500.0 mHz.

**Query Response:** :LIMits:SCE:CH1:UPPer:VALue?  
500.00

## 4.9 SYMBOL DEVIATION

### 4.9.1 Symbol Deviation - Averages

**:METERs:SYMdev:CH1:AVERaging**  
**:METERs:SYMdev:CH1:AVERaging?**

**Description:** Set command defines the number of readings taken to calculate Average Symbol Deviation measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :METERs:SYMdev:CH1:AVERaging 100

Sets the number of readings taken to calculate Average Symbol Deviation measurement to 100.

**Query Response:** :METERs:SYMdev:CH1:AVERaging?  
100

### 4.9.2 Symbol Deviation - Average Measurement Reset

**:METERs:SYMdev:CH1:CLEAR:AVG**

**Description:** Command clears and resets Average Symbol Deviation measurement.

**Parameter/Query:** none

### 4.9.3 Symbol Deviation - Lower Limit Enable

**:LIMits:SYMdev:CH1:LOWer:ENABLE**  
**:LIMits:SYMdev:CH1:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Symbol Deviation measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:SYMdev:CH1:LOWer:ENABLE ON

Enables Lower Limit for Symbol Deviation measurement.

**Query Response:** :LIMits:SYMdev:CH1:LOWer:ENABLE?  
1

**4.9.4 Symbol Deviation - Lower Limit Value****:LIMits:SYMdev:CH1:LOWer:VALue****:LIMits:SYMdev:CH1:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Symbol Deviation measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 10,000.0 Hz

**Units:** Hz

**Default Value:** 0.0 Hz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:SYMdev:CH1:LOWer:VALue 250Hz

Sets Lower Limit Value for Symbol Deviation measurement to 250.0 Hz.

**Query Response:** :LIMits:SYMdev:CH1:LOWer:VALue?  
250.00

**4.9.5 Symbol Deviation - Measurement Query****:METERs:SYMdev:CH1:STATus?**

**Description:** Command returns Symbol Deviation measurement data.

**Query Data:** <statusbyte>,<failbyte>,<precision>,<percentage>,<avg>,<max>,<min>,<units>

Refer to Chapter 1 for UUT Measurement Meter Return Data.

NOTE
------

**Query Response:** :METERs:SYMdev:CH1:STATus?  
0,0,2,100.000,1946.569,2046.316,1800.000,2

**4.9.6 Symbol Deviation - Peak Measurement Reset****:METERs:SYMdev:CH1:CLEAR:PEAK**

**Description:** Command clears and resets Peak Symbol Deviation measurement.

**Parameter/Query:** none

**4.9.7 Symbol Deviation - Upper Limit Enable****:LIMits:SYMdev:CH1:UPPer:ENABLE****:LIMits:SYMdev:CH1:UPPer:ENABLE?**

**Description:** Set command Enables/Disables Upper Limit for Symbol Deviation measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:SYMdev:CH1:UPPer:ENABLE ON

Enables Upper Limit for Symbol Deviation measurement.

**Query Response:** :LIMits:SYMdev:CH1:UPPer:ENABLE?  
1



#### 4.9.8 Symbol Deviation - Upper Limit Value

**:LIMits:SYMdev:CH1:UPPer:VALue**

**:LIMits:SYMdev:CH1:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for Symbol Deviation measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 10,000.0 Hz

**Units:** Hz

**Default Value:** 0.0 Hz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:SYMdev:CH1:UPPer:VALue 500Hz

Sets Upper Limit Value for Symbol Deviation measurement to 500.0 Hz.

**Query Response:** :LIMits:SYMdev:CH1:UPPer:VALue?  
500.00

THIS PAGE INTENTIONALLY LEFT BLANK.

---

## Chapter 5 - Audio/Demod Signal Rx Meter Remote Commands

### 5.1 INTRODUCTION

This chapter describes the Remote Commands used for configuring and obtaining Audio/Demod signal measurement data. Remote Commands are listed alphabetically by meter name.

### 5.2 AUDIO MEASUREMENT CONFIGURATION

#### 5.2.1 AF Measurements - Audio Source

**:CONFigure:AF:ANALyzer:SOURce**  
**:CONFigure:AF:ANALyzer:SOURce?**

**Description:** Set command defines the Source for Audio Frequency Analyzer (Receiver) and Site Sensitivity Search (Option).  
Query command returns parameter setting.

**Parameter:** AUD1 | AUD2 | BAL | MIC

**Default Value:** AUD1

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:AF:ANALyzer:SOURce MIC  
Selects Microphone as the Audio Frequency Analyzer (Receiver) Source.

**Query Response:** :CONFigure:AF:ANALyzer:SOURce?  
MIC

**NOTE**

Test Set does not process any commands following this one until this command is completed.

### 5.2.2 AF Measurements - Filter Type

**:AF:ANALyzer:MFILter**

**:AF:ANALyzer:MFILter?**

**Description:** Set command selects the Audio Analyzer Post Detection Filter.  
Query command returns parameter setting.

**Parameter:** PSOPh | None | LP1 | LP2 | LP3 | LP4 | LP5 | LP6 | LP7 | HP1 | HP2 | HP3 | BP0 | BP1 | BP2 | BP3 | BP4 | BP5 | BP6 | BP7 | BP8 | BP9 | BP10 | BP11 | BP12 | BP13 | BP14 | BP15 | BP16

**where:**

NONE = No Filter	BP2 = 0.3 to 5.0 kHz BP
PSOPh = Psoph (CMESS or CCITT)	BP3 = 0.3 to 20.0 kHz BP
LP1 = 300.0 Hz LP	BP4 = 0.3 to 15.0 kHz BP
LP2 = 5.0 kHz LP	BP5 = 20.0 to 300.0 Hz BP
LP3 = 20.0 kHz LP	BP6 = 0.02 to 3.0 kHz BP
LP4 = 15.0 kHz LP	BP7 = 0.02 to 3.4 kHz BP
LP5 = 3.0 kHz LP	BP8 = 0.02 to 5.0 kHz BP
LP6 = 625.0 kHz LP*	BP9 = 0.02 to 15.0 kHz BP
LP7 = 10.0 kHz LP*	BP10 = 0.02 to 20.0 kHz BP
LP8 = 100.0 Hz LP*	BP11 = 0.05 to 300.0 Hz BP
HP1 = 300.0 Hz HP	BP12 = 0.05 to 3.0 kHz BP
HP2 = 20.0 Hz HP	BP13 = 0.05 to 3.4 kHz BP
HP3 = 50.0 Hz HP	BP14 = 0.05 to 5.0 kHz BP
BP0 = 0.3 to 3.0 kHz BP	BP15 = 0.05 to 15.0 kHz BP
BP1 = 0.3 to 3.4 kHz BP	BP16 = 0.05 to 20.0 kHz BP

**Default Value:** NONE (No Filter)

**Set/Query Format:** CPD | CRD

**Example:** :AF:ANALyzer:MFILter LP3  
Selects 20.0 kHz Low Pass Filter for AF measurements.

**Query Response:** :AF:ANALyzer:MFILter?  
LP3

**NOTE**

Filter selected should be appropriate for signal received from UUT.  
When PSOPH is selected, Filter weight is defined using :CONFIgure:AF:MFILter command.  
Test Set does not process any commands following this one until this command is completed.  
\*LP6, LP7 and LP8 are used by the Audio Analyzer Tracking Generator and can not be defined by user, but may be returned as query data.

### 5.2.3 AF Measurements - Filter Weight

**:CONFigure:AF:MFILter**

**:CONFigure:AF:MFILter?**

**Description:** Set command defines the weight of psoph filter for AF Analyzer when Psoph filter is selected.

Query command returns parameter setting.

**Parameter:** CMESs | CCITt

**Default Value:** CMES

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:AF:MFILter CCITt

Selects CCITT Psoph Filter for AF measurement.

**Query Response:** :CONFigure:AF:MFILter?

CCIT

**NOTE**

AF Filter type must be defined as Psoph (:AF:ANALyzer:MFILter PSOPH) for this command to be valid.

### 5.2.4 AF Measurements - Impedance

**:CONFigure:AF:ANALyzer:SOURce:LOAD**

**:CONFigure:AF:ANALyzer:SOURce:LOAD?**

**Description:** Set command defines the Impedance of selected Audio Frequency (Receiver) source.

Query command returns parameter setting.

**Parameter:** UNBHI | UNB600

**Default Value:** Audio Source defined

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:AF:ANALyzer:SOURce:LOAD UNBHI

Sets Impedance of selected Audio Frequency (Receiver) Source to Unbalanced Hi-Z.

**Query Response:** :CONFigure:AF:ANALyzer:SOURce:LOAD?

UNBHI

**NOTE**

Command not valid when AF Analyzer Source is set to Balanced (:CONFigure:AF:ANALyzer:SOURce is set to BAL).

### 5.2.5 AF Measurements - Impedance External Load

**:CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD**  
**:CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD?**

**Description:** Set command defines the Impedance of selected Audio Frequency Analyzer (Receiver) source.  
 Query command returns parameter setting.

**Range:** 1 to 9999 Ohms

**Units:** Ohms

**Default Value:** 8 Ohms

**Set/Query Format:** NRf | NR1

**Example:** :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD 100OHMS  
 Sets External Load to 100 Ohms for Audio Frequency Analyzer (Receiver).

**Query Response:** :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD?  
 100

**NOTE**

Command only valid when Impedance is set to Unbalanced Hi-Z (:CONFigure:AF:ANALyzer:SOURce:LOAD UNBHI).

### 5.2.6 AF Measurements - Impedance External Load Enable

**:CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD:ENABLE**  
**:CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD:ENABLE?**

**Description:** Set command enables External Load for Impedance.  
 Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD:ENABLE ON  
 Enables and applies defined External Impedance Load.

**Query Response:** :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD:ENABLE?  
 1

**NOTE**

Command :CONFigure:AF:ANALyzer:SOURce:VARiable:LOAD defines the external load applied when External Load is enabled.

### 5.2.7 Loudspeaker

**:CONFigure:PORT:LOUDspeaker**  
**:CONFigure:PORT:LOUDspeaker?**

**Description:** Set command selects Loudspeaker port.  
 Query command returns selected Loudspeaker port.

**Parameter:** OFF | AUDio | DEMod

**Default Value:** OFF

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:PORT:LOUDspeaker AUDio  
 Selects Audio as the Loudspeaker port.

**Query Response:** :CONFigure:PORT:LOUDspeaker?  
 AUD

## 5.3 MODULATION MEASUREMENT CONFIGURATION

### 5.3.1 Modulation - Filter Type

**:MOD:ANALyzer:MFILter**

**:MOD:ANALyzer:MFILter?**

**Description:** Set command selects the Mod Analyzer Post Detection Filter.  
Query command returns parameter setting.

**Parameter:** PSOPh | None | LP1 | LP2 | LP3 | LP4 | LP5 | LP6 | LP7 | HP1 | HP2 | HP3 | BP0 | BP1 | BP2 | BP3 | BP4 | BP5 | BP6 | BP7 | BP8 | BP9 | BP10 | BP11 | BP12 | BP13 | BP14 | BP15 | BP16

**where:**

NONE = No Filter	BP2 = 0.3 to 5.0 kHz BP
PSOPh = Psoph (CMESS or CCITT)	BP3 = 0.3 to 20.0 kHz BP
LP1 = 300.0 Hz LP	BP4 = 0.3 to 15.0 kHz BP
LP2 = 5.0 kHz LP	BP5 = 20 to 300.0 Hz BP
LP3 = 20.0 kHz LP	BP6 = 0.02 to 3.0 kHz BP
LP4 = 15.0 kHz LP	BP7 = 0.02 to 3.4 kHz BP
LP5 = 3.0 kHz LP	BP8 = 0.02 to 5.0 kHz BP
LP6 = 625.0 kHz LP*	BP9 = 0.02 to 15.0 kHz BP
LP7 = 10.0 kHz LP*	BP10 = 0.02 to 20.0 kHz BP
LP8 = 100.0 Hz LP*	BP11 = 0.05 to 300.0 Hz BP
HP1 = 300.0 Hz HP	BP12 = 0.05 to 3.0 kHz BP
HP2 = 20.0 Hz HP	BP13 = 0.05 to 3.4 kHz BP
HP3 = 50.0 Hz HP	BP14 = 0.05 to 5.0 kHz BP
BP0 = 0.3 to 3.0 kHz BP	BP15 = 0.05 to 15.0 kHz BP
BP1 = 0.3 to 3.4 kHz BP	BP16 = 0.05 to 20.0 kHz BP

**Default Value:** NONE (No Filter)

**Set/Query Format:** CPD | CRD

**Example:** :MOD:ANALyzer:MFILter BP4  
Selects 0.3 to 15.0 kHz band pass filter for receiver signal path.

**Query Response:** :MOD:ANALyzer:MFILter?  
BP4

**NOTE**

Filter selected should be appropriate for signal received from UUT.  
When PSOPH is selected, Filter weight is defined using :CONFigure:MOD:MFILter command.  
Test Set does not process any commands following this one until this command is completed.  
\*LP6, LP7 and LP8 are used by the Audio Analyzer Tracking Generator and can not be defined by user, but may be returned as query data.

### 5.3.2 Modulation Measurements - Filter Weight

**:CONFigure:MOD:MFILter**

**:CONFigure:MOD:MFILter?**

**Description:** Set command defines the weight of psoph filter for Modulation Analyzer when Psoph filter is selected.  
Query command returns parameter setting.

**Parameter:** CMESs | CCITt

**Default Value:** CMESs

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:MOD:MFILter CCITt  
Selects CCITT Psoph Filter for modulation measurement.

**Query Response:** :CONFigure:MOD:MFILter?  
CCIT

**NOTE**

Filter type must be defined as Psoph (:MOD:ANALyzer:MFILter PSOPH) for this command to be valid.

### 5.3.3 Function Generator / Demod Out Connector

**:CONFigure:PORT:FGEN**

**:CONFigure:PORT:FGEN?**

**Description:** Set command selects Function Generator / Demod Out Connector.  
Query command returns parameter setting.

**Parameter:** FGEN | AUDio | DEMod

**Default Value:** FGEN

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:PORT:FGEN DEMod  
Selects Demod as the Function Generator / Demod Out Connector.

**Query Response:** :CONFigure:PORT:FGEN?  
DEM



## 5.4 AF DISTORTION MEASUREMENTS

### 5.4.1 AF Distortion - Averages

**:CONFigure:AF:ANALyzer:DISToTtion:AVERAge**

**:CONFigure:AF:ANALyzer:DISToTtion:AVERAge?**

**Description:** Set command defines the number of readings taken to calculate Average AF Distortion measurement.

Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:AF:ANALyzer:DISToTtion:AVERAge 75

Sets number of readings taken to calculate Average AF Distortion measurements to 75.

**Query Response:** :CONFigure:AF:ANALyzer:DISToTtion:AVERAge?  
75

### 5.4.2 AF Distortion - Average Measurement Reset

**:AF:ANALyzer:DISToTtion:CLear:AVG**

**Description:** Command clears and resets Average AF Distortion measurement.

**Parameter/Query:** none

### 5.4.3 AF Distortion - Lower Limit Enable

**:LIMits:AF:DISToTtion:LOWer:ENABle**

**:LIMits:AF:DISToTtion:LOWer:ENABle?**

**Description:** Set command Enables/Disables Lower Limit for AF Distortion measurement. Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:AF:DISToTtion:LOWer:ENABle ON

Enables Lower Limit for AF Distortion measurement.

**Query Response:** :LIMits:AF:DISToTtion:LOWer:ENABle?  
1

#### 5.4.4 AF Distortion - Lower Limit Value

**:LIMits:AF:DISToRtion:LOWer:VALue**  
**:LIMits:AF:DISToRtion:LOWer:VALue?**

**Description:** Set command defines the Lower Limit Value for AF Distortion measurement.  
 Query command returns parameter setting.

**Range:** 0.0 to 100.0%

**Units:** % (percent)

**Default Value:** 5.0%

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:AF:DISToRtion:LOWer:VALue 1  
 Sets Lower Limit Value for AF Distortion measurement to 1.0%.

**Query Response:** :LIMits:AF:DISToRtion:LOWer:VALue?  
 1.00

#### 5.4.5 AF Distortion - Measurement Query

**:FETCh:AF:ANALyzer:DISToRtion?**

**Description:** Command returns AF Analyzer Distortion measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg%>,<wc%>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:AF:ANALyzer:DISToRtion?  
 0,0,1,99.97,99.99

**NOTE**

Protocol must be set to Analog to return valid AF Distortion measurement data.

#### 5.4.6 AF Distortion - Peak Measurement Reset

**:AF:ANALyzer:DISToRtion:CLEAR:PEAK**

**Description:** Command clears and resets Peak AF Distortion measurement.

**Parameter/Query:** none

#### 5.4.7 AF Distortion - Upper Limit Enable

**:LIMits:AF:DISToRtion:UPPer:ENABLE**  
**:LIMits:AF:DISToRtion:UPPer:ENABLE?**

**Description:** Set command Enables/Disables Upper Limit for AF Distortion measurement.  
 Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:AF:DISToRtion:UPPer:ENABLE ON  
 Enables Upper Limit for AF Distortion measurement.

**Query Response:** :LIMits:AF:DISToRtion:UPPer:ENABLE?  
 1

### 5.4.8 AF Distortion - Upper Limit Value

**:LIMits:AF:DISTortion:UPPer:VALue**

**:LIMits:AF:DISTortion:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for AF Distortion measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 100.0%

**Units:** % (percent)

**Default Value:** 5.0%

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:AF:DISTortion:UPPer:VALue 1

Sets Upper Limit Value for AF Distortion measurement to 1.0%.

**Query Response:** :LIMits:AF:DISTortion:UPPer:VALue?

1.00

## 5.5 AF FREQUENCY MEASUREMENTS

### 5.5.1 AF Frequency - Averages

**:CONFigure:AF:ANALyzer:FREQuency:AVERage**  
**:CONFigure:AF:ANALyzer:FREQuency:AVERage?**

**Description:** Set command defines the number of readings taken to calculate Average AF Frequency measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:AF:ANALyzer:FREQuency:AVERage 75  
Sets number of readings taken to calculate Average AF Frequency measurement to 75.

**Query Response:** :CONFigure:AF:ANALyzer:FREQuency:AVERage?  
75

### 5.5.2 AF Frequency - Average Measurement Reset

**:AF:ANALyzer:FREQuency:CLEAR:AVG**

**Description:** Command clears and resets Average AF Frequency measurement.

**Parameter/Query:** none

### 5.5.3 AF Frequency - Lower Limit Enable

**:LIMits:AF:FREQuency:LOWer:ENABLE**  
**:LIMits:AF:FREQuency:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for AF Frequency measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :LIMits:AF:FREQuency:LOWer:ENABLE ON  
Enables Lower Limit for AF Frequency measurement.

**Query Response:** :LIMits:AF:FREQuency:LOWer:ENABLE?  
1

#### 5.5.4 AF Frequency - Lower Limit Value

**:LIMits:AF:FREQuency:LOWer:VALue**  
**:LIMits:AF:FREQuency:LOWer:VALue?**

**Description:** Set command defines the Lower Limit Value for AF Frequency measurement.  
 Query command returns parameter setting.

**Range:** 0.0 Hz to 20.0 kHz

**Units:** Hz | kHz

**Default Value:** 0.0 kHz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:AF:FREQuency:LOWer:VALue 1Hz  
 Sets Lower Limit Value for AF Frequency measurement to 1.0 Hz.

**Query Response:** :LIMits:AF:FREQuency:LOWer:VALue?  
 1.0

#### 5.5.5 AF Frequency - Measurement Query

**:FETCh:AF:ANALyzer:FREQuency?**

**Description:** Command returns AF Frequency measurement data.

**Query Data:** <statusbyte>, <avgcount>, <avg(Hz)>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:AF:ANALyzer:FREQuency?  
 0,25,1000.0

**NOTE**

Protocol must be set to Analog to return valid AF Frequency measurement data.

#### 5.5.6 AF Frequency - Peak Measurement Reset

**:AF:ANALyzer:FREQuency:CLEAR:PEAK**

**Description:** Command clears and resets Peak AF Frequency measurement.

**Parameter/Query:** none

#### 5.5.7 AF Frequency - Upper Limit Enable

**:LIMits:AF:FREQuency:UPPer:ENABLE**  
**:LIMits:AF:FREQuency:UPPer:ENABLE?**

**Description:** Set command Enables/Disables Upper Limit for AF Frequency measurement.  
 Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :LIMits:AF:FREQuency:UPPer:ENABLE ON  
 Enables Upper Limit for AF Frequency measurement.

**Query Response:** :LIMits:AF:FREQuency:UPPer:ENABLE?  
 1

### 5.5.8 AF Frequency - Upper Limit Value

**:LIMits:AF:FREQuency:UPPer:VALue**

**:LIMits:AF:FREQuency:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for AF Frequency measurement.  
Query command returns parameter setting.

**Range:** 0.0 Hz to 20.0 kHz

**Units:** Hz | kHz

**Default Value:** 0.0 kHz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:AF:FREQuency:UPPer:VALue 2Hz  
Sets Upper Limit Value for AF Frequency measurement to 2.0 Hz.

**Query Response:** :LIMits:AF:FREQuency:UPPer:VALue?  
2.0

## 5.6 AF HUM & NOISE MEASUREMENTS

### 5.6.1 AF Hum & Noise - Averages

**:CONFigure:AF:ANALyzer:HN:AVERage**  
**:CONFigure:AF:ANALyzer:HN:AVERage?**

**Description:** Set command defines the number of readings taken to calculate Average AF Hum & Noise measurement.  
 Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:AF:ANALyzer:HN:AVERage 75  
 Sets number of readings being taken to calculate Average AF Hum & Noise measurement to 75.

**Query Response:** :CONFigure:AF:ANALyzer:HN:AVERage?  
 75

#### NOTE

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPE SN) and SNR measurement defined as Hum & Noise (:CONFigure:AF:ANALyzer:SNR:MODE 0) to obtain valid Hum & Noise measurement.

### 5.6.2 AF Hum & Noise - Average Measurement Reset

**:AF:ANALyzer:HN:CLEAR:AVG**

**Description:** Command clears and resets Average AF Hum & Noise measurement.

**Parameter/Query:** none

### 5.6.3 AF Hum & Noise - Lower Limit Enable

**:LIMits:AF:HN:LOWer:ENABLE**  
**:LIMits:AF:HN:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for AF Hum and Noise measurement.  
 Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:AF:HN:LOWer:ENABLE ON  
 Enables Lower Limit for Hum & Noise measurement.

**Query Response:** :LIMits:AF:HN:LOWer:ENABLE?  
 1

#### NOTE

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPE SN) and SNR measurement defined as Hum & Noise (:CONFigure:AF:ANALyzer:SNR:MODE 0) to obtain valid Hum & Noise measurement.

#### 5.6.4 AF Hum & Noise - Lower Limit Value

**:LIMits:AF:HN:LOWer:VALue**

**:LIMits:AF:HN:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for AF Hum and Noise measurement. Query command returns parameter setting.

**Range:** -100.0 to +100.0 dBr

**Units:** dBr

**Default Value:** 0.0 dBr

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:AF:HN:LOWer:VALue -50dBr  
Sets Lower Limit Value for AF Hum & Noise measurement to -50.0 dBr.

**Query Response:** :LIMits:AF:HN:LOWer:VALue?  
-50.00

**NOTE**

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPe SN) and SNR measurement defined as Hum & Noise (:CONFigure:AF:ANALyzer:SNR:MODE 0) to obtain valid Hum & Noise measurement.

#### 5.6.5 AF Hum & Noise - Measurement Query

**:FETCh:AF:ANALyzer:HN?**

**Description:** Command returns AF Hum and Noise measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg(dB)>,<wc(dB)>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:AF:ANALyzer:HN?  
0,0,10,-8.43,-8.43

**NOTE**

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPe SN) and SNR measurement defined as Hum & Noise (:CONFigure:AF:ANALyzer:SNR:MODE 0) to obtain valid Hum & Noise measurement.

#### 5.6.6 AF Hum & Noise - Peak Measurement Reset

**:AF:ANALyzer:HN:CLEAR:PEAK**

**Description:** Command clears and resets Peak AF Hum & Noise measurement.

**Parameter/Query:** none

#### 5.6.7 AF Hum & Noise - Reference Lock

**:CONFigure:AF:ANALyzer:HN:REFerence**

**Description:** Command locks AF Hum and Noise reference to current meter reading.

**Parameter/Query:** none

**NOTE**

SNR measurement must be defined as Hum & Noise to obtain valid Hum & Noise measurement (:CONFigure:AF:ANALyzer:SNR:MODE HN).



### 5.6.8 AF Hum & Noise - Reference Value

**:CONFigure:AF:ANALyzer:HN:REFeRence:VALue**

**:CONFigure:AF:ANALyzer:HN:REFeRence:VALue?**

**Description:** Set command defines the reference value for AF Hum and Noise measurement.  
Query command returns parameter setting.

**Range:** -100.0 to +100.0 dB

**Units:** dB

**Default Value:** 12.0 dB

**Set/Query Format:** NRf | NR2

**Example:** :CONFigure:AF:ANALyzer:HN:REFeRence:VALue 1dB  
Sets Hum & Noise Reference value to 1.0 dB.

**Query Response:** :CONFigure:AF:ANALyzer:HN:REFeRence:VALue?  
1.00

**NOTE**

Query command returns HN Reference Value using  
:CONFigure:AF:ANALyzer:HN:REFeRence command.

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio  
(:AF:ANALyzer:NTYPe SN) and SNR measurement defined as Hum & Noise  
(:CONFigure:AF:ANALyzer:SNR:MODE 0) to obtain valid Hum & Noise  
measurement.

### 5.6.9 AF Hum & Noise - Upper Limit Enable

**:LIMits:AF:HN:UPPer:ENABle**

**:LIMits:AF:HN:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for AF Hum and Noise  
measurement.

Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:AF:HN:UPPer:ENABle ON  
Enables Upper Limit for Hum & Noise measurement.

**Query Response:** :LIMits:AF:HN:UPPer:ENABle?.  
1

**NOTE**

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio  
(:AF:ANALyzer:NTYPe SN) and SNR measurement defined as Hum & Noise  
(:CONFigure:AF:ANALyzer:SNR:MODE 0) to obtain valid Hum & Noise  
measurement.

### 5.6.10 AF Hum & Noise - Upper Limit Value

**:LIMits:AF:HN:UPPer:VALue**

**:LIMits:AF:HN:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for AF Hum and Noise measurement.

Query command returns parameter setting.

**Range:** -100.0 to +100.0 dBr

**Units:** dBr

**Default Value:** 10.0 dBr

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:AF:HN:UPPer:VALue 25dBr

Sets Lower Limit Value for AF Hum & Noise measurement to 25.0 dBr.

**Query Response:** :LIMits:AF:HN:UPPer:VALue?

25

**NOTE**

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPe SN) and SNR measurement defined as Hum & Noise (:CONFigure:AF:ANALyzer:SNR:MODE 0) to obtain valid Hum & Noise measurement.

## 5.7 AF LEVEL MEASUREMENTS

### 5.7.1 AF Level - Averages

**:CONFigure:AF:ANALyzer:LEVel:AVERage**  
**:CONFigure:AF:ANALyzer:LEVel:AVERage?**

**Description:** Set command defines the number of readings taken to calculate Average AF Level measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Set/Query Format:** NR1

**Default Value:** 1

**Example:** :CONFigure:AF:ANALyzer:LEVel:AVERage 75  
Sets number of readings being taken to calculate Average AF Level measurement to 75.

**Query Response:** :CONFigure:AF:ANALyzer:LEVel:AVERage?  
75

### 5.7.2 AF Level - Average Measurement Reset

**:AF:ANALyzer:LEVel:CLEAR:AVG**

**Description:** Command clears and resets Average AF Level measurement.

**Parameter/Query:** none

### 5.7.3 AF Level - Lower Limit Enable

**:LIMits:AF:LEVel:LOWer:ENABLE**  
**:LIMits:AF:LEVel:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for AF Level measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :LIMits:AF:LEVel:LOWer:ENABLE ON  
Enables Lower Limit for AF Level measurement.

**Query Response:** :LIMits:AF:LEVel:LOWer:ENABLE?  
1

#### 5.7.4 AF Level - Lower Limit Value

**:LIMits:AF:LEVel:LOWer:VALue**  
**:LIMits:AF:LEVel:LOWer:VALue?**

**Description:** Set command defines the Lower Limit Value for AF Level measurement.  
 Query command returns parameter setting.

**Range:** 1.0 mV to 30.0 V

**Units:** mV | V | dBV | dBr | dBm

**Default Value:** 1.0 mV

**Set/Query Format:** NRf <units>| NR1 <units>

**Example:** :LIMits:AF:LEVel:LOWer:VALue 2V  
 Sets Lower Limit Value for AF Level measurement to 2 Volts.

**Query Response:** :LIMits:AF:LEVel:LOWer:VALue? mV  
 2000.0

**NOTE**

If units is not defined in Set or Query command, value defaults to units specified for AF Level measurements.  
 dBV is not valid when Audio Balanced (BAL) is selected as the Audio Input Source.

#### 5.7.5 AF Level - Measurement Query

**:FETCh:AF:ANALyzer:LEVel?**

**Description:** Command return the AF Level measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Units:** V (Unbalanced)  
 dBm (Balanced)

**Query Response:** :FETCh:AF:ANALyzer:LEVel?  
 0,0,1,3.11

**NOTE**

Protocol must be set to Analog to return valid measurement data.

#### 5.7.6 AF Level - Peak Measurement Reset

**:AF:ANALyzer:LEVel:CLEAR:PEAK**

**Description:** Command clears and resets Peak AF Level measurement.

**Parameter/Query:** none

### 5.7.7 AF Level - Units

**:CONFigure:AF:ANALyzer:LEVel:UNIts**  
**:CONFigure:AF:ANALyzer:LEVel:UNIts?**

**Description:** Set command defines the unit of measure for AF Level measurement.  
 Query command returns parameter setting.

**Parameter:** V | dBV | dBm | dBr

**Default Value:** dBm

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:AF:ANALyzer:LEVel:UNIts dBr  
 Displays AF Level measurement in dBr.

**Query Response:** :CONFigure:AF:ANALyzer:LEVel:UNIts?  
 DBR

### 5.7.8 AF Level - Upper Limit Enable

**:LIMits:AF:LEVel:UPPer:ENABLE**  
**:LIMits:AF:LEVel:UPPer:ENABLE?**

**Description:** Set command Enables/Disables Upper Limit for AF Level measurement.  
 Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :LIMits:AF:LEVel:UPPer:ENABLE ON  
 Enables Upper Limit for AF Level measurement.

**Query Response:** :LIMits:AF:LEVel:UPPer:ENABLE?  
 1

### 5.7.9 AF Level - Upper Limit Value

**:LIMits:AF:LEVel:UPPer:VALue**  
**:LIMits:AF:LEVel:UPPer:VALue?**

**Description:** Set command define the Upper Limit Value for AF Level measurement.  
 Query command returns parameter setting.

**Range:** 1.0 mV to 30.0 V

**Units:** mV | V | dBV | dBr | dBm

**Default Value:** 10.0 V

**Set/Query Format:** NRf <units>| NR1 <units>

**Example:** :LIMits:AF:LEVel:UPPer:VALue 5V  
 Sets Upper Limit Value for AF Level measurement to 5 Volts

**Query Response:** :LIMits:AF:LEVel:UPPer:VALue? mV  
 5000.0

**NOTE**

If units is not defined in Set or Query command, value defaults to units specified for AF Level measurements.  
 dBV is not valid when Audio Balanced (BAL) is selected as the Audio Input Source.

## 5.8 AF SINAD MEASUREMENTS

### 5.8.1 AF Sinad - Averages

**:CONFigure:AF:ANALyzer:SINad:AVERAge**  
**:CONFigure:AF:ANALyzer:SINad:AVERAge?**

**Description:** Set command defines the number of readings taken to calculate Average AF Sinad measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:AF:ANALyzer:SINad:AVERAge 25  
Sets number of readings taken to calculate Average AF Sinad measurement to 75.

**Query Response:** :CONFigure:AF:ANALyzer:SINad:AVERAge?  
75

### 5.8.2 AF Sinad - Average Measurement Reset

**:AF:ANALyzer:SINad:CLEAR:AVG**

**Description:** Command clears and resets Average AF Sinad measurement.

**Parameter/Query:** none

### 5.8.3 AF Sinad - Lower Limit Enable

**:LIMits:AF:SINad:LOWer:ENABLE**  
**:LIMits:AF:SINad:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for AF Sinad measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:AF:SINad:LOWer:ENABLE ON  
Enables Lower Limit for AF Sinad measurement.

**Query Response:** :LIMits:AF:SINad:LOWer:ENABLE?  
1

#### 5.8.4 AF Sinad - Lower Limit Value

**:LIMits:AF:SINad:LOWer:VALue**

**:LIMits:AF:SINad:LOWer:VALue?**

**Description:** Set command defines the Lower Limit Value for AF Sinad measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 100.0 dB

**Units:** dB

**Default Value:** 0.0 dB

**Set/Query Format:** NRf | NR1

**Example:** :LIMits:AF:SINad:LOWer:VALue 50dB  
Sets Lower Limit Value for AF Sinad measurement to 50 dB.

**Query Response:** :LIMits:AF:SINad:LOWer:VALue?  
50

#### 5.8.5 AF Sinad - Measurement Query

**:FETCh:AF:ANALyzer:SINad?**

**Description:** Command returns Sinad measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg(dB)>,<wc(dB)>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:AF:ANALyzer:SINad?  
0,0,25,0.01,0.03

**NOTE**

Protocol must be set to Analog to return valid AF Sinad measurement data.

#### 5.8.6 AF Sinad - Peak Measurement Reset

**:AF:ANALyzer:SINad:CLEAR:PEAK**

**Description:** Command clears and resets Peak AF Sinad measurement.

**Parameter/Query:** none

#### 5.8.7 AF Sinad - Upper Limit Enable

**:LIMits:AF:SINad:UPPer:ENABle**

**:LIMits:AF:SINad:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for AF Sinad measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:AF:SINad:UPPer:ENABle ON  
Enables Upper Limit for AF Sinad measurement.

**Query Response:** :LIMits:AF:SINad:UPPer:ENABle?  
1

### 5.8.8 AF Sinad - Upper Limit Value

**:LIMits:AF:SINad:UPPer:VALue**

**:LIMits:AF:SINad:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for AF Sinad measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 100.0 dB

**Units:** dB

**Default Value:** 0.0 dB

**Set/Query Format:** NRf | NR1

**Example:** :LIMits:AF:SINad:UPPer:VALue 50dB

Set Upper Limit Value for AF Sinad measurement to 50 dB.

**Query Response:** :LIMits:AF:SINad:UPPer:VALue?

50



## 5.9 AF SNR MEASUREMENTS

### 5.9.1 AF SNR - Averages

**:CONFigure:AF:ANALyzer:SNR:AVERAge**

**:CONFigure:AF:ANALyzer:SNR:AVERAge?**

**Description:** Set command defines the number of readings taken to calculate Average AF SNR measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:AF:ANALyzer:SNR:AVERAge 75

Sets number of readings taken to calculate Average AF SNR measurement to 75.

**Query Response:** :CONFigure:AF:ANALyzer:SNR:AVERAge?  
75

#### NOTE

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPE SN) and SNR measurement defined as Normal (:CONFigure:AF:ANALyzer:SNR:MODE 1) to obtain valid SNR measurement.

### 5.9.2 AF SNR - Average Measurement Reset

**:AF:ANALyzer:SNR:CLEAR:AVG**

**Description:** Command clears and resets Average AF Signal to Noise Ratio measurement.

**Parameter/Query:** none

### 5.9.3 AF SNR - Lower Limit Enable

**:LIMits:AF:SNR:LOWer:ENABLE**

**:LIMits:AF:SNR:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for AF Signal to Noise Ratio measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:AF:SNR:LOWer:ENABLE ON

Enables Lower Limit for AF SNR measurement.

**Query Response:** :LIMits:AF:SNR:LOWer:ENABLE?  
1

#### NOTE

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPE SN) and SNR measurement defined as Normal (:CONFigure:AF:ANALyzer:SNR:MODE 1) to obtain valid SNR measurement.

### 5.9.4 AF SNR - Lower Limit Value

**:LIMits:AF:SNR:LOWer:VALue**  
**:LIMits:AF:SNR:LOWer:VALue?**

**Description:** Set command defines the Lower Limit Value for AF Signal to Noise Ratio measurement.

Query command returns parameter setting.

**Range:** -100.0 to +100.0 dBr

**Units:** dBr

**Default Value:** 0.0 dBr

**Set/Query Format:** NRf | NR1

**Example:** :LIMits:AF:SNR:LOWer:VALue 50dBr

Sets Lower Limit Value for AF SNR measurement to 50.0 dBr.

**Query Response:** :LIMits:AF:SNR:LOWer:VALue?  
50

**NOTE**

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPE SN) and SNR measurement defined as Normal (:CONFigure:AF:ANALyzer:SNR:MODE 1) to obtain valid SNR measurement.

### 5.9.5 AF SNR - Mode

**:CONFigure:AF:ANALyzer:SNR:MODE**  
**:CONFigure:AF:ANALyzer:SNR:MODE?**

**Description:** Set command defines the SNR Meter Mode (Normal or Hum and Noise) when performing Signal to Noise Ratio measurement.

Query command returns parameter setting.

**Parameter:** 0 = Hum & Noise

1 = Normal

**Default Value:** 0

**Set/Query Format:** NR1

**Example:** :CONFigure:AF:ANALyzer:SNR:MODE 0

Sets AF Signal to Noise measurement to Hum & Noise measurement.

**Query Response:** :CONFigure:AF:ANALyzer:SNR:MODE?  
0

**NOTE**

AF Analyzers Noise measurement type must be defined as SN for command to be valid (:AF:ANALyzer:NTYPE SN).

### 5.9.6 AF SNR - Measurement Query

**:FETCh:AF:ANALyzer:SNR?**

**Description:** Command returns AF Signal to Noise Ratio measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avg(dB)>,<wc(dB)>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:AF:ANALyzer:SNR?  
0,0,25,-1.99

**NOTE**

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPE SN) and SNR measurement defined as Normal (:CONFigure:AF:ANALyzer:SNR:MODE 1) to obtain valid SNR measurement.  
 (\*rci meter mode compatible: see :SYSTem:RCI :METER:MODE)

### 5.9.7 AF SNR - Peak Measurement Reset

**:AF:ANALyzer:SNR:CLear:PEAK**

**Description:** Command clears and resets Peak AF Signal to Noise Ratio measurement.

**Parameter/Query:** none

### 5.9.8 AF SNR - Upper Limit Enable

**:LIMits:AF:SNR:UPPer:ENABle**

**:LIMits:AF:SNR:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for AF Signal to Noise Ratio measurement.

Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:AF:SNR:UPPer:ENABle ON

Enables Upper Limit for AF SNR measurement.

**Query Response:** :LIMits:AF:SNR:UPPer:ENABle?

1

**NOTE**

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPe SN) and SNR measurement defined as Normal (:CONFigure:AF:ANALyzer:SNR:MODE 1) to obtain valid SNR measurement.

### 5.9.9 AF SNR - Upper Limit Value

**:LIMits:AF:SNR:UPPer:VALue**

**:LIMits:AF:SNR:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for AF Signal to Noise Ratio measurement.

Query command returns parameter setting.

**Range:** -100.0 to +100.0 dBr

**Units:** dBr

**Default Value:** 10.0 dBr

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:AF:SNR:UPPer:VALue 50dBr

Sets Upper Limit Value for AF SNR measurement to 50.0 dBr.

**Query Response:** :LIMits:AF:SNR:UPPer:VALue?

50

**NOTE**

AF Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:AF:ANALyzer:NTYPe SN) and SNR measurement defined as Normal (:CONFigure:AF:ANALyzer:SNR:MODE 1) to obtain valid SNR measurement.

## 5.10 BROADBAND POWER

### 5.10.1 Broadband Power - Averages

**:CONFigure:RF:ANALyzer:TRBPower:AVERAge**  
**:CONFigure:RF:ANALyzer:TRBPower:AVERAge?**

**Description:** Set command defines number of readings taken to calculate Average Broadband Power measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:RF:ANALyzer:TRBPower:AVERAge 25  
Sets number of readings taken to calculate Average Broadband Power measurement to 25.

**Query Response:** :CONFigure:RF:ANALyzer:TRBPower:AVERAge?  
25

### 5.10.2 Broadband Power - Lower Limit Enable

**:LIMits:RF:TRBPower:LOWer:ENABLE**  
**:LIMits:RF:TRBPower:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Broadband Power measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:RF:TRBPower:LOWer:ENABLE ON  
Enables Lower Limit for Broadband Power measurement.

**Query Response:** :LIMits:RF:TRBPower:LOWer:ENABLE?  
1

### 5.10.3 Broadband Power - Lower Limit Value

**:LIMits:RF:TRBPower:LOWer:VALue**  
**:LIMits:RF:TRBPower:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Broadband Power measurement.  
Query command returns parameter setting.

**Range:** -140.0 to +70.0 dBm

**Units:** mW | W | dBW | dBm

**Default Value:** 100.0  $\mu$ W

**Set/Query Format:** NRf | NR2 (W)

**Example:** :LIMits:RF:TRBPower:LOWer:VALue -45dBm  
Sets Lower Limit Value for Broadband measurement to -45.0 dBm.

**Query Response:** :LIMits:RF:TRBPower:LOWer:VALue?  
0.0

#### 5.10.4 Broadband Power - Measurement Query

##### **:FETCh:RF:ANALyzer:TRBPower? <units>**

**Description:** Command returns Broadband Power measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Units:** W | dBW | dBm

**Query Response:** :FETCh:RF:ANALyzer:TRBPower? DBW  
1,5,1,0.0013

**NOTE**

RF Input must be set to TR to return valid data.

#### 5.10.5 Broadband Power - Peak Measurement Query

##### **:FETCh:RF:ANALyzer:TRBPower:HOLD?**

**Description:** Command returns Peak Broadband Power measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Units:** W | dBW | dBm

**Query Response:** :FETCh:RF:ANALyzer:TRBPower:HOLD?  
1,5,0.0091

**NOTE**

RF Input must be set to TR to return valid data.

#### 5.10.6 Broadband Power - Units

##### **:CONFigure:RF:ANALyzer:TRBPower:UNIts**

##### **:CONFigure:RF:ANALyzer:TRBPower:UNIts?**

**Description:** Set command defines the unit of measurement for Broadband Power measurement.

Query command returns parameter setting.

**Parameter:** W | dBW | dBm

**Default Value:** W

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:RF:ANALyzer:TRBPower:UNIts DBW  
Displays Broadband Power measurement in dBW.

**Query Response:** :CONFigure:RF:ANALyzer:TRBPower:UNIts?  
DBW

### 5.10.7 Broadband Power - Upper Limit Enable

**:LIMits:RF:TRBPower:UPPer:ENABle**

**:LIMits:RF:TRBPower:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for Broadband Power measurement.

Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:RF:TRBPower:UPPer:ENABle ON

Enables Upper Limit for Broadband Power measurement.

**Query Response:** :LIMits:RF:TRBPower:UPPer:ENABle?

1

### 5.10.8 Broadband Power - Upper Limit Value

**:LIMits:RF:TRBPower:UPPer:VALue**

**:LIMits:RF:TRBPower:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for Broadband Power measurement.

Query command returns parameter setting.

**Range:** -140.0 to +70.0 dBm

**Units:** mW | W | dBW | dBm

**Default Value:** 100.0  $\mu$ W

**Set/Query Format:** NRf | NR2 (W)

**Example:** :LIMits:RF:TRBPower:UPPer:VALue -25dBm

Sets Upper Limit Value for Broadband Power measurement to -25.0 dBm.

**Query Response:** :LIMits:RF:TRBPower:UPPer:VALue?

0.0

## 5.11 FM DEVIATION MEASUREMENTS

### 5.11.1 FM Deviation - Averages

**:CONFigure:MOD:ANALyzer:FM:AVERAge**

**:CONFigure:MOD:ANALyzer:FM:AVERAge?**

**Description:** Set command defines number of readings taken to calculate Average FM Deviation measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:MOD:ANALyzer:FM:AVERAge 75

Sets number of readings taken to calculate Average FM Deviation measurement to 75.

**Query Response:** :CONFigure:MOD:ANALyzer:FM:AVERAge?  
75

### 5.11.2 FM Deviation - Average Measurement Reset

**:MOD:ANALyzer:FM:CLEAR:AVG**

**Description:** Command clears and resets Average FM Deviation measurement.

**Parameter/Query:** none

### 5.11.3 FM Deviation - Lower Limit Enable

**:LIMits:MOD:FM:LOWer:ENABLE**

**:LIMits:MOD:FM:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for FM Deviation measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:MOD:FM:LOWer:ENABLE ON

Enables Lower Limit for FM Deviation measurement.

**Query Response:** :LIMits:MOD:FM:LOWer:ENABLE?  
1

#### 5.11.4 FM Deviation - Lower Limit Value

**:LIMits:MOD:FM:LOWer:VALue**  
**:LIMits:MOD:FM:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for FM Deviation measurement.  
 Query command returns parameter setting.

**Range:** 0.0 Hz to 150.0 kHz

**Default Value:** 0.0 Hz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:MOD:FM:LOWer:VALue 1.0Hz

Sets Lower Limit Value for FM Deviation measurement to 1.0 Hz.

**Query Response:** :LIMits:MOD:FM:LOWer:VALue?  
 1.0

**NOTE**

Units defined by :CONFigure:MOD:ANALyzer:FM:UNIts command.

#### 5.11.5 FM Deviation - Measurement Query

**:FETCh:MOD:ANALyzer:FM?**

**Description:** Command returns FM Deviation measurement data.

**Query Data:** <statusbyte>, <failbyte>, <avgcount>, <avg(Hz)>, <max(Hz)>, <min(Hz)>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:MOD:ANALyzer:FM?  
 0, 0, 1, 30.12, 43.47, 30.12

**NOTE**

Protocol must be set to Analog to return valid measurement data.

#### 5.11.6 FM Deviation - Peak Measurement Reset

**:MOD:ANALyzer:FM:CLear:PEAK**

**Description:** Command clears and resets Peak FM Deviation measurement.

**Parameter/Query:** none

#### 5.11.7 FM Deviation - Measurement Type

**:CONFigure:MOD:ANALyzer:FM:MTYPE**  
**:CONFigure:MOD:ANALyzer:FM:MTYPE?**

**Description:** Set command defines measurement type for FM Deviation measurement.  
 Query command returns parameter setting.

**Parameter:** PEAK | RMS

**Default Value:** PEAK

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:MOD:ANALyzer:FM:MTYPE RMS

Sets Mod Analyzer Distortion measurement to RMS.

**Query Response:** :CONFigure:MOD:ANALyzer:FM:MTYPE?  
 RMS



### 5.11.8 FM Deviation - Offset Enable

**:CONFigure:MOD:ANALyzer:FM:OFFSet:ENABle**

**:CONFigure:MOD:ANALyzer:FM:OFFSet:ENABle?**

**Description:** Set command defines the FM Deviation Offset mode of operation.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** ON

**Set/Query Format:** Boolean

**Example:** :CONFigure:MOD:ANALyzer:FM:OFFSet:ENABle ON  
Locks FM Deviation Frequency Offset to RF Analyzer Frequency.

**Query Response:** :CONFigure:MOD:ANALyzer:FM:OFFSet:ENABle?  
1

### 5.11.9 FM Deviation - Units

**:CONFigure:MOD:ANALyzer:FM:UNIts**

**:CONFigure:MOD:ANALyzer:FM:UNIts?**

**Description:** Set command defines the unit of measurement for FM Deviation measurement.  
Query command returns parameter setting.

**Parameter:** dBr | Hz

**Default Value:** Hz

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:MOD:ANALyzer:FM:UNIts dBr  
Displays FM Deviation measurements in dBr.

**Query Response:** :CONFigure:MOD:ANALyzer:FM:UNIts?  
dBr

**NOTE**

Command defines unit of measurement for Upper and Lower Limit commands.

### 5.11.10 FM Deviation - Upper Limit Enable

**:LIMits:MOD:FM:UPPer:ENABle**

**:LIMits:MOD:FM:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for FM Deviation measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:MOD:FM:UPPer:ENABle ON  
Enables Upper Limit for FM Deviation measurement.

**Query Response:** :LIMits:MOD:FM:UPPer:ENABle?  
1

### 5.11.11 FM Deviation - Upper Limit Value

**:LIMits:MOD:FM:UPPer:VALue**

**:LIMits:MOD:FM:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for FM Deviation measurement.  
Query command returns parameter setting.

**Range:** 0.0 Hz to 150.0 kHz

**Default Value:** 0.0 Hz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:MOD:FM:UPPer:VALue 2.0Hz

Sets Upper Limit Value for FM Deviation measurement to 2.0 Hz.

**Query Response:** :LIMits:MOD:FM:UPPer:VALue?

1.0

**NOTE**

Units defined by :CONFigure:MOD:ANALyzer:FM:UNIts command.

## 5.12 INBAND POWER MEASUREMENTS

### 5.12.1 Inband Power - Averages

**:METERs:POWer:CHn:INBand:AVERaging**  
**:METERs:POWer:CHn:INBand:AVERaging?**

**Description:** Set command defines number of readings taken to calculate Average Inband Power measurement.  
 Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :METERs:POWer:CH1:INBand:AVERaging 100  
 Sets the number of readings taken to calculate Channel 1 Inband Power measurements to 100.

**Query Response:** :METERs:POWer:CH1:INBand:AVERaging?  
 100

**NOTE**

CHn = 1 or 2 (Channel 1 or 2). Channel 2 is option enabled.

### 5.12.2 Inband Power - Average Measurement Reset

**:METERs:POWer:CHn:INBand:CLEAR:AVG**

**Description:** Command clears and resets Average Inband Power measurement.

**Parameter/Query:** none

**NOTE**

CHn = 1 or 2 (Channel 1 or 2). Channel 2 is option enabled.

### 5.12.3 Inband Power - Lower Limit Enable

**:LIMits:POWer:CHn:INBand:LOWer:ENABLE**  
**:LIMits:POWer:CHn:INBand:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Inband Power measurement.  
 Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:POWer:CH1:INBand:LOWer:ENABLE ON  
 Enables Lower Limit for Channel 1 Inband Power measurement.

**Query Response:** :LIMits:POWer:CH1:INBand:LOWer:ENABLE?  
 1

**NOTE**

CHn = 1 or 2 (Channel 1 or 2). Channel 2 is option enabled.

### 5.12.4 Inband Power - Lower Limit Value

**:LIMits:POWer:CHn:INBand:LOWer:VALue**  
**:LIMits:POWer:CHn:INBand:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Inband Power measurement. Query command returns parameter setting.

**Range:** -140.0 to +70.0 dBm

**Units:** W | dBW | dBm | V | dBμV

**Default Value:** 0.0 dBm

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:POWer:CH1:INBand:LOWer:VALue -45dBm  
 Sets Lower Limit for Channel 1 Inband measurements to -45.0 dBm.

**Query Response:** :LIMits:POWer:CH1:INBand:LOWer:VALue?  
 0.0

**NOTE**

CHn = 1 or 2 (Channel 1 or 2). Channel 2 is option enabled.

### 5.12.5 Inband Power - Measurement Query

**:METERs:POWer:CHn:INBand:STATus?**

**Description:** Command returns Inband Power measurement data.

**Query Data:** <statusbyte>,<failbyte>,<precision>,<percentage>,<avg>,<max>,<min>,<units>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :METERs:POWer:CH1:INBand:STATus?  
 0,0,3 100.00, -30.183, -30.140, -30.241,6

**NOTE**

CHn = 1 or 2 (Channel 1 or 2). Channel 2 is option enabled.  
 Protocol must be defined as ANALOG to return valid measurement data.

### 5.12.6 Inband Power - Peak Measurement Reset

**:METERs:POWer:CHn:INBand:CLear:PEAK**

**Description:** Command clears and resets Peak Inband Power measurement.

**Parameter/Query:** none

**NOTE**

CHn = 1 or 2 (Channel 1 or 2). Channel 2 is option enabled.

### 5.12.7 Inband Power - Units

**:METERs:POWer:INBand:UNIts**

**:METERs:POWer:INBand:UNIts?**

**Description:** Set command defines the unit of measurement for Inband Power measurement. Query command returns parameter setting.

**Parameter:** dBm | W | dBW | V | dBµV

**Default Value:** dBm

**Set/Query Format:** CPD | CRD

**Example:** :METERs:POWer:INBand:UNIts W  
Displays Inband Power measurements in Watts.

**Query Response:** :METERs:POWer:INBand:UNIts?  
W

### 5.12.8 Inband Power - Upper Limit Enable

**:LIMits:POWer:CHn:INBand:UPPer:ENABle**

**:LIMits:POWer:CHn:INBand:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for Inband Power measurement. Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :LIMits:POWer:CH1:INBand:UPPer:ENABle ON  
Enables Upper Limit for Channel 1 Inband Power measurement.

**Query Response:** :LIMits:POWer:CH1:INBand:UPPer:ENABle?  
1

**NOTE** CHn = 1 or 2 (Channel 1 or 2). Channel 2 is option enabled.

### 5.12.9 Inband Power - Upper Limit Value

**:LIMits:POWer:CHn:INBand:UPPer:VALue**

**:LIMits:POWer:CHn:INBand:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for Inband Power measurement Upper. Query command returns parameter setting.

**Range:** -140.0 to +70.0 dBm

**Units:** W | dBW | dBm | V | dBµV

**Default Value:** 0.0 dBm

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:POWer:CH1:INBand:UPPer:VALue -25dBm  
Sets Upper Limit for Channel 1 Inband Power Measurement to -25.0 dBm.

**Query Response:** :LIMits:POWer:CH1:INBand:UPPer:VALue?  
0.0

**NOTE** CHn = 1 or 2 (Channel 1 or 2). Channel 2 is option enabled.

## 5.13 MODULATION DISTORTION MEASUREMENTS

### 5.13.1 Modulation Distortion - Averages

**:CONFigure:MOD:ANALyzer:DISToTtion:AVERAge**

**:CONFigure:MOD:ANALyzer:DISToTtion:AVERAge?**

**Description:** Set command defines number of readings taken to calculate Average Modulation Distortion measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:MOD:ANALyzer:DISToTtion:AVERAge 75

Sets number of readings taken to calculate Average Modulation Distortion measurement to 75.

**Query Response:** :CONFigure:MOD:ANALyzer:DISToTtion:AVERAge?  
75

### 5.13.2 Modulation Distortion - Average Measurement Reset

**:MOD:ANALyzer:DISToTtion:CLear:AVG**

**Description:** Command clears and resets Average Modulation Distortion measurement.

**Parameter/Query:** none

### 5.13.3 Modulation Distortion - Lower Limit Enable

**:LIMits:MOD:DISToTtion:LOWer:ENABle**

**:LIMits:MOD:DISToTtion:LOWer:ENABle?**

**Description:** Set command Enables/Disables Lower Limit for Modulation Distortion measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:MOD:DISToTtion:LOWer:ENABle ON

Enables Lower Limit for Modulation Distortion measurement.

**Query Response:** :LIMits:MOD:DISToTtion:LOWer:ENABle?  
1

### 5.13.4 Modulation Distortion - Lower Limit Value

**:LIMits:MOD:DISToRTion:LOWer:VALue**

**:LIMits:MOD:DISToRTion:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Modulation Distortion measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 100.0%

**Units:** % (percent)

**Default Value:** 0.0%

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:MOD:DISToRTion:LOWer:VALue 1.0

Sets Lower Limit Value for Modulation Distortion measurement to 1.0%.

**Query Response:** :LIMits:MOD:DISToRTion:LOWer:VALue?  
1.0

### 5.13.5 Modulation Distortion - Measurement Query

**:FETCh:MOD:ANALyzer:DISToRTion?**

**Description:** Command returns Modulation Distortion measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgvount>,<avg%>,<wc%>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:MOD:ANALyzer:DISToRTion?  
0,0,1,99.59,99.99

**NOTE**

Protocol must be defined as Analog to obtain valid Modulation Distortion measurements data.

### 5.13.6 Modulation Distortion - Peak Measurement Reset

**:MOD:ANALyzer:DISToRTion:CLEAR:PEAK**

**Description:** Command clears and resets Peak Modulation Distortion measurement.

**Parameter/Query:** none

### 5.13.7 Modulation Distortion - Upper Limit Enable

**:LIMits:MOD:DISToRTion:UPPer:ENABLE**

**:LIMits:MOD:DISToRTion:UPPer:ENABLE?**

**Description:** Set command Enables/Disables Upper Limit for Modulation Distortion measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:MOD:DISToRTion:UPPer:ENABLE ON

Enables Upper Limit for Modulation Distortion measurement.

**Query Response:** :LIMits:MOD:DISToRTion:UPPer:ENABLE?  
1

### 5.13.8 Modulation Distortion - Upper Limit Value

**:LIMits:MOD:DISToRTion:UPPer:VALue**

**:LIMits:MOD:DISToRTion:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for Modulation Distortion measurement.

Query command returns parameter setting.

**Range:** 0.0 to 100.0%

**Units:** % (percent)

**Default Value:** 0.0%

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:MOD:DISToRTion:UPPer:VALue 1.0

Sets Upper Limit Value for Modulation Distortion measurements to 1.0%.

**Query Response:** :LIMits:MOD:DISToRTion:UPPer:VALue?

1.0



## 5.14 MODULATION FREQUENCY MEASUREMENTS

### 5.14.1 Modulation Frequency - Averages

**:CONFigure:MOD:ANALyzer:FREQuency:AVERage**

**:CONFigure:MOD:ANALyzer:FREQuency:AVERage?**

**Description:** Set command defines number of readings taken to calculate average Modulation Frequency measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:MOD:ANALyzer:FREQuency:AVERage 75

Sets number of readings taken to calculate Average Modulation Frequency measurement to 75.

**Query Response:** :CONFigure:MOD:ANALyzer:FREQuency:AVERage?  
75

### 5.14.2 Modulation Frequency - Average Measurement Reset

**:MOD:ANALyzer:FREQuency:CLEAR:AVG**

**Description:** Command clears and resets Average Modulation Frequency measurement.

**Parameter/Query:** none

### 5.14.3 Modulation Frequency - Lower Limit Enable

**:LIMits:MOD:FREQuency:LOWer:ENABLE**

**:LIMits:MOD:FREQuency:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Modulation Frequency measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :LIMits:MOD:FREQuency:LOWer:ENABLE ON

Enables Lower Limit for Modulation Frequency measurement.

**Query Response:** :LIMits:MOD:FREQuency:LOWer:ENABLE?  
1

**5.14.4 Modulation Frequency - Lower Limit Value**

**:LIMits:MOD:FREQuency:LOWer:VALue**  
**:LIMits:MOD:FREQuency:LOWer:VALue?**

**Description:** Set command defines the Lower Limit Value Modulation Frequency measurement.  
 Query command returns parameter setting.

**Range:** 0.0 Hz to 20.0 kHz

**Units:** Hz | kHz

**Default Value:** 0.0 kHz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:MOD:FREQuency:LOWer:VALue 1.0Hz

Sets Lower Limit Value for Modulation Frequency measurement to 1.0 Hz.

**Query Response:** :LIMits:MOD:FREQuency:LOWer:VALue?  
 1.0

**5.14.5 Modulation Frequency - Measurement Query**

**:FETCh:MOD:ANALyzer:FREQuency?**

**Description:** Command returns Modulation Frequency measurement data.

**Query Data:** <statusbyte>, <avgcount>, <avg(Hz)>

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**NOTE**

**Query Response:** :FETCh:MOD:ANALyzer:FREQuency?  
 0,0,2979.00

**NOTE**

Protocol must be defined as Analog to obtain valid Modulation Frequency measurement data.

**5.14.6 Modulation Frequency - Peak Measurement Reset**

**:MOD:ANALyzer:FREQuency:CLEAR:PEAK**

**Description:** Command clears and resets Peak Modulation Frequency measurement.

**Parameter/Query:** none

**5.14.7 Modulation Frequency - Sub-Audible Deviation Filter**

**:CONFigure:MOD:ANALyzer:SAUDDEV:FILter**  
**:CONFigure:MOD:ANALyzer:SAUDDEV:FILter?**

**Description:** Set command selects Sub-Audible filter to include in Demod Frequency path.  
 Query command returns parameter setting.

**Parameter:** HP300HZ | LP300HZ

**Default Value:** 300 Hz HP

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:MOD:ANALyzer:SAUDDEV:FILter LP300HZ

Selects 300 Hz LP Sub-Audible Filter for Demod Frequency path.

**Query Response:** :CONFigure:MOD:ANALyzer:SAUDDEV:FILter?  
 LP300HZ

**NOTE**

This command is only valid for SmartNet™/SmartZone™ protocol when configured for Analog Modulation.

### 5.14.8 Modulation Frequency - Upper Limit Enable

**:LIMits:MOD:FREQuency:UPPer:ENABle**

**:LIMits:MOD:FREQuency:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for Modulation Frequency measurement.

Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :LIMits:MOD:FREQuency:UPPer:ENABle ON

Enables Upper Limit for Modulation Frequency measurement.

**Query Response:** :LIMits:MOD:FREQuency:UPPer:ENABle?

1

### 5.14.9 Modulation Frequency - Upper Limit Value

**:LIMits:MOD:FREQuency:UPPer:VALue**

**:LIMits:MOD:FREQuency:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for Modulation Frequency measurement.

Query command returns parameter setting.

**Range:** 0.0 Hz to 20.0 kHz

**Units:** Hz | kHz

**Default Value:** 0.0 Hz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:MOD:FREQuency:UPPer:VALue 2.0Hz

Sets Upper Limit Value for Modulation Frequency measurement to 2.0 Hz.

**Query Response:** :LIMits:MOD:FREQuency:UPPer:VALue?

1.0

## 5.15 MODULATION HUM & NOISE MEASUREMENTS

### 5.15.1 Mod Hum & Noise - Averages

**:CONFigure:MOD:ANALyzer:HN:AVERAge**

**:CONFigure:MOD:ANALyzer:HN:AVERAge?**

**Description:** Set command defines number of readings taken to calculate the Average Mod Hum & Noise measurement.

Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:MOD:ANALyzer:HN:AVERAge 75

Sets number of readings taken to calculate Average Mod Distortion measurement to 75.

**Query Response:** :CONFigure:MOD:ANALyzer:HN:AVERAge?  
75

### 5.15.2

### 5.15.3 Mod Hum & Noise - Average Measurement Reset

**:MOD:ANALyzer:HN:CLEAR:AVG**

**Description:** Command clears and resets Average Mod Hum & Noise measurement.

**Parameter/Query:** none

### 5.15.4 Mod Hum & Noise - Lower Limit Enable

**:LIMits:MOD:HN:LOWer:ENABLE**

**:LIMits:MOD:HN:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Mod Hum & Noise measurement.

Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:MOD:HN:LOWer:ENABLE ON

Enables Lower Limit for Mod Hum & Noise measurement.

**Query Response:** :LIMits:MOD:HN:LOWer:ENABLE?  
1

### 5.15.5 Mod Hum & Noise - Lower Limit Value

**:LIMits:MOD:HN:LOWer:VALue**

**:LIMits:MOD:HN:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Mod Hum & Noise measurement. Query command returns parameter setting.

**Range:** -100.0 to +100.0 dBr

**Units:** dBr

**Default Value:** 0.0 dBr

**Set/Query Format:** NRf | NR1

**Example:** :LIMits:MOD:HN:LOWer:VALue -50dBr  
Sets Lower Limit Value for Mod Hum & Noise measurement to -50.0 dBr.

**Query Response:** :LIMits:MOD:HN:LOWer:VALue?  
-50

### 5.15.6 Mod Hum & Noise - Measurement Query

**:FETCh:MOD:ANALyzer:HN?**

**Description:** Command returns Mod and Noise measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg(dB)>,<wc(dB)>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:MOD:ANALyzer:HN?  
4,4,13,62.35,75.68

**NOTE**

Mod Analyzer Noise measurement type must be defined as Signal to Noise Ratio (:MOD:ANALyzer:NTYPE SN) and SNR measurement defined as Hum & Noise (:CONFigure:MOD:ANALyzer:SNR:MODE 0) to obtain valid Hum & Noise measurement.

### 5.15.7 Mod Hum & Noise - Peak Measurement Reset

**:MOD:ANALyzer:HN:CLEAR:PEAK**

**Description:** Command clears and resets Peak Mod Hum & Noise measurement.

**Parameter/Query:** none

### 5.15.8 Mod Hum & Noise - Reference Lock

**:CONFigure:MOD:ANALyzer:HN:REFerence**

**Description:** Command locks Mod Hum and Noise reference to current meter reading.

**Parameter/Query:** none

**NOTE**

SNR measurement must be defined as Hum & Noise to obtain valid Hum & Noise measurement (:CONFigure:MOD:ANALyzer:SNR:MODE HN).

### 5.15.9 Mod Hum & Noise - Reference Value

**:CONFigure:MOD:ANALyzer:HN:REFerence:VALue**  
**:CONFigure:MOD:ANALyzer:HN:REFerence:VALue?**

**Description:** Set command defines the reference for Modulation Analyzer Hum and Noise measurement.  
Query command returns parameter setting.

**Range:** -100.0 to +100.0 dB

**Units:** dB

**Default Value:** 12.0 dB

**Set/Query Format:** NRf | NR2

**Example:** :CONFigure:MOD:ANALyzer:HN:REFerence:VALue 1dB  
Sets Hum & Noise Reference value to 1.0 dB.

**Query Response:** :CONFigure:MOD:ANALyzer:HN:REFerence:VALue?  
1

### 5.15.10 Mod Hum & Noise - Upper Limit Enable

**:LIMits:MOD:HN:UPPer:ENABle**  
**:LIMits:MOD:HN:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for Mod Hum & Noise measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:MOD:HN:UPPer:ENABle ON  
Enables Upper Limit for Mod Hum & Noise measurement.

**Query Response:** :LIMits:MOD:HN:UPPer:ENABle?  
1

### 5.15.11 Mod Hum & Noise - Upper Limit Value

**:LIMits:MOD:HN:UPPer:VALue**  
**:LIMits:MOD:HN:UPPer:VALue?**

**Description:** Set command defines Upper Limit Value for Hum and Noise measurement.  
Query command returns parameter setting.

**Range:** -100.0 to +100.0 dBr

**Units:** dBr

**Default Value:** 10.0 dBr

**Set/Query Format:** NRf | NR1

**Example:** :LIMits:MOD:HN:UPPer:VALue 75dBr  
Sets Upper Limit Value for Mod Hum & Noise measurement to 75.0 dBr.

**Query Response:** :LIMits:MOD:HN:UPPer:VALue?  
75

## 5.16 MODULATION SINAD MEASUREMENTS

### 5.16.1 Modulation Sinad - Averages

**:CONFigure:MOD:ANALyzer:SINad:AVERAge**  
**:CONFigure:MOD:ANALyzer:SINad:AVERAge?**

**Description:** Set command defines number of readings taken to calculate the Average Modulation Sinad measurement.  
 Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:MOD:ANALyzer:SINad:AVERAge 25  
 Sets number of readings taken to calculate Average Modulation Sinad measurement to 75.

**Query response:** :CONFigure:MOD:ANALyzer:SINad:AVERAge?  
 75

### 5.16.2 Modulation Sinad - Average Measurement Reset

**:MOD:ANALyzer:SINad:CLEAR:AVG**

**Description:** Command clears and resets Average Modulation Sinad measurement.

**Parameter/Query:** none

### 5.16.3 Modulation Sinad - Lower Limit Enable

**:LIMits:MOD:SINad:LOWer:ENABLE**  
**:LIMits:MOD:SINad:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Modulation Sinad measurement.  
 Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Set/Query Format:** Boolean

**Default Value:** OFF

**Example:** :LIMits:MOD:SINad:LOWer:ENABLE ON  
 Enables Lower Limit for Modulation Sinad measurement.

**Query Response:** :LIMits:MOD:SINad:LOWer:ENABLE?  
 1

#### 5.16.4 Modulation Sinad - Lower Limit Value

**:LIMits:MOD:SINad:LOWer:VALue**

**:LIMits:MOD:SINad:LOWer:VALue?**

**Description:** Set command defines Lower Limit Value for Modulation Sinad measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 100.0 dB

**Units:** dB

**Default Value:** 26.0 dB

**Set/Query Format:** NRf | NR1

**Example:** :LIMits:MOD:SINad:LOWer:VALue 30dB  
Sets Lower Limit for Modulation Sinad measurement to 30 dB.

**Query Response:** :LIMits:MOD:SINad:LOWer:VALue?  
30

#### 5.16.5 Modulation Sinad - Measurement Query

**:FETCh:MOD:ANALyzer:SINad?**

**Description:** Command returns Modulation Sinad measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg(dB)>,<wc(dB)>  
Refer to Chapter 1 for UUT Measurement Meter Return Data.

**NOTE**

**Query Response:** :FETCh:MOD:ANALyzer:SINad?  
0,0,1,0.15,0.19

**NOTE**

Protocol must be defined as Analog to return valid measurement data.

#### 5.16.6 Modulation Sinad - Peak Measurement Reset

**:MOD:ANALyzer:SINad:CLEAR:PEAK**

**Description:** Command clears and resets Peak Modulation Sinad measurement.

**Parameter/Query:** none

#### 5.16.7 Modulation Sinad - Upper Limit Enable

**:LIMits:MOD:SINad:UPPer:ENABle**

**:LIMits:MOD:SINad:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for Modulation Sinad measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:MOD:SINad:UPPer:ENABle ON  
Enables Upper Limit for Modulation Sinad measurement.

**Query Response:** :LIMits:MOD:SINad:UPPer:ENABle?  
1



### 5.16.8 Modulation Sinad - Upper Limit Value

**:LIMits:MOD:SINad:UPPer:VALue**

**:LIMits:MOD:SINad:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for Modulation Sinad measurement.  
Query command returns parameter setting.

**Range:** 0.0 to 100.0 dB

**Units:** dB

**Default Value:** 26.0 dB

**Set/Query Format:** NRf | NR1

**Example:** :LIMits:MOD:SINad:UPPer:VALue 30dB

Sets Upper Limit Value for Modulation Sinad measurement to 30 dB.

**Query Response:** :LIMits:MOD:SINad:UPPer:VALue?

30

## 5.17 MODULATION SNR MEASUREMENTS

### 5.17.1 Mod SNR - Averages

**:CONFigure:MOD:ANALyzer:SNR:AVERAge**

**:CONFigure:MOD:ANALyzer:SNR:AVERAge?**

**Description:** Set command defines number of readings taken to calculate Average Mod Signal to Noise Ratio measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:MOD:ANALyzer:SNR:AVERAge 75

Sets number of readings taken to calculate Average Mod SNR measurement to 75.

**Query Response:** :CONFigure:MOD:ANALyzer:SNR:AVERAge?  
75

### 5.17.2 Mod SNR - Average Measurement Reset

**:MOD:ANALyzer:SNR:CLEAR:AVG**

**Description:** Command clears and resets Average Mod SNR measurement.

**Parameter/Query:** none

### 5.17.3 Mod SNR - Lower Limit Enable

**:LIMits:MOD:SNR:LOWer:ENABLE**

**:LIMits:MOD:SNR:LOWer:ENABLE?**

**Description:** Set command Enables/Disables Lower Limit for Mod SNR measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:MOD:SNR:LOWer:ENABLE ON  
Enables Lower Limit for Mod SNR measurement.

**Query Response:** :LIMits:MOD:SNR:LOWer:ENABLE?  
1

#### 5.17.4 Mod SNR - Lower Limit Value

**:LIMits:MOD:SNR:LOWer:VALue**

**:LIMits:MOD:SNR:LOWer:VALue?**

**Description:** Set command defines the Lower Limit Value for Mod SNR measurement.  
Query command returns parameter setting.

**Range:** -100.0 to +100.0 dBr

**Units:** dBr

**Default Value:** 26.0 dBr

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:MOD:SNR:LOWer:VALue 50dBr  
Sets Lower Limit for Mod SNR measurement to 50.0 dBr.

**Query Response:** :LIMits:MOD:SNR:LOWer:VALue?  
50

#### 5.17.5 Mod SNR - Mode

**:CONFigure:MOD:ANALyzer:SNR:MODE**

**:CONFigure:MOD:ANALyzer:SNR:MODE?**

**Description:** Set command defines the SNR Meter Mode (Normal or Hum and Noise) when performing Signal to Noise Ratio measurement.  
Query command returns parameter setting.

**Parameter:** 0 = Hum & Noise  
1 = Normal

**Default Value:** 0 (Hum & Noise)

**Set/Query Format:** NR1

**Example:** :CONFigure:MOD:ANALyzer:SNR:MODE 0  
Sets Mod SNR measurement to Hum & Noise.

**Query Response:** :CONFigure:MOD:ANALyzer:SNR:MODE?  
0

#### 5.17.6 Mod SNR - Measurement Query

**:FETCh:MOD:ANALyzer:SNR?**

**Description:** Command returns Modulation Signal to Noise Ratio measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avg(dB)>,<wc(dB)>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:MOD:ANALyzer:SNR?  
0,2,1,-0.00,13.02

**NOTE**

Mod Analyzer Noise measurement type must be defined as SNR to return valid Mod SNR measurement data (:MOD:ANALyzer:NTYPE SN.)  
(\*rci meter mode compatible: see :SYSTem:RCI :METER:MODE)

### 5.17.7 Mod SNR - Peak Measurement Reset

**:MOD:ANALyzer:SNR:CLEAR:PEAK**

**Description:** Command clears and resets Peak Mod SNR measurement.

**Parameter/Query:** none

### 5.17.8 Mod SNR - Upper Limit Enable

**:LIMits:MOD:SNR:UPPer:ENABle**

**:LIMits:MOD:SNR:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for Mod SNR measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:MOD:SNR:UPPer:ENABle ON  
Enables Upper Limit for Mod SNR measurement.

**Query Response:** :LIMits:MOD:SNR:UPPer:ENABle?  
1

### 5.17.9 Mod SNR - Upper Limit Value

**:LIMits:MOD:SNR:UPPer:VALue**

**:LIMits:MOD:SNR:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for Mod SNR measurement.  
Query command returns parameter setting.

**Range:** -100.0 to +100.0 dBr

**Units:** dBr

**Default Value:** 0.0 dBr

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:MOD:SNR:UPPer:VALue 50dBr  
Sets Upper Limit Value for Mod SNR measurement to 50.0 dBr.

**Query Response:** :LIMits:MOD:SNR:UPPer:VALue?  
50

## 5.18 RF ERROR MEASUREMENTS

### 5.18.1 RF Error - Averages

**:CONFigure:RF:ANALyzer:RFERRor:AVERAge**  
**:CONFigure:RF:ANALyzer:RFERRor:AVERAge?**

**Description:** Set command defines number of readings taken to calculate Average RF Error measurement.  
Query command returns parameter setting.

**Range:** 1 to 250

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONFigure:RF:ANALyzer:RFERRor:AVERAge 75  
Sets number of readings taken to calculate Average RF Error measurement to 75.

**Query Response:** :CONFigure:RF:ANALyzer:RFERRor:AVERAge?  
75

### 5.18.2 RF Error - Average Measurement Reset

**:RF:ANALyzer:RFERRor:CLEAR:AVG**

**Description:** Command clears and resets Average RF Error measurement.

**Parameter/Query:** none

### 5.18.3 RF Error - Frequency Resolution Value

**:CONFigure:RF:ANALyzer:RFERRor:FRESolution**  
**:CONFigure:RF:ANALyzer:RFERRor:FRESolution?**

**Description:** Set command defines RF Error Frequency Resolution.  
Query command returns parameter setting.

**Parameter:** 1 | 10

**Units:** Hz

**Default Value:** 1 Hz

**Set/Query Format:** NRf | NR1

**Example:** :CONFigure:RF:ANALyzer:RFERRor:FRESolution 10  
Sets RF Error Frequency Resolution to 10 Hz.

**Query Response:** :CONFigure:RF:ANALyzer:RFERRor:FRESolution?  
10

#### 5.18.4 RF Error - Lower Limit Enable

**:LIMits:RF:RFERRor:LOWer:ENABle**

**:LIMits:RF:RFERRor:LOWer:ENABle?**

**Description:** Set command Enables/Disables Lower Limit for RF Error measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:RF:RFERRor:LOWer:ENABle ON  
Enables Lower Limit for RF Error measurement.

**Query Response:** :LIMits:RF:RFERRor:LOWer:ENABle?  
1

#### 5.18.5 RF Error - Lower Limit Value

**:LIMits:RF:RFERRor:LOWer:VALue**

**:LIMits:RF:RFERRor:LOWer:VALue?**

**Description:** Set command defines the Lower Limit Value for RF Error measurement.  
Query command returns parameter setting.

**Range:** -5000000.0 to +5000000.0 Hz  
PPM: 0 to 1000

**Units:** Hz | PPM

**Default Value:** 0.0 Hz

**Set/Query Format:** NRf | NR2 (Hz)

**Command Example:** :LIMits:RF:RFERRor:LOWer:VALue 1000Hz

Sets Lower Limit Value for RF Error measurement to 1000.0 Hz.

**Query Response:** :LIMits:RF:RFERRor:LOWer:VALue?  
1000

#### 5.18.6 RF Error - Measurement Query

**:FETCh:RF:ANALyzer:RFERRor?**

**Description:** Command returns RF Error measurement data.

**Query Data:** <statusbyte>,<failbyte>,<avgcount>,<avg(dB)>,<max(dB)>

**NOTE**

Refer to Chapter 1 for UUT Measurement Meter Return Data.

**Query Response:** :FETCh:RF:ANALyzer:RFERRor?  
0,0,1,874.77,2437.64

#### 5.18.7 RF Error - Peak Measurement Reset

**:RF:ANALyzer:RFERRor:CLEAR:PEAK**

**Description:** Command clears and resets Peak RF Error measurement.

**Parameter/Query:** none

### 5.18.8 RF Error - Units

**:CONFigure:RF:ANALyzer:RFERRor:UNIts**

**:CONFigure:RF:ANALyzer:RFERRor:UNIts?**

**Description:** Set command defines the unit of measurement for RF Error measurement.  
Query command returns parameter setting.

**Parameter:** Hz | PPM

**Default Value:** Hz

**Set/Query Format:** CPD | CRD

**Example:** :CONFigure:RF:ANALyzer:RFERRor:UNIts PPM  
Displays RF Error measurement in PPM.

**Query Response:** :CONFigure:RF:ANALyzer:RFERRor:UNIts?  
PPM

### 5.18.9 RF Error - Upper Limit Enable

**:LIMits:RF:RFERRor:UPPer:ENABle**

**:LIMits:RF:RFERRor:UPPer:ENABle?**

**Description:** Set command Enables/Disables Upper Limit for RF Error measurement.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :LIMits:RF:RFERRor:UPPer:ENABle ON  
Enables Upper Limit for RF Error measurement.

**Query Response:** :LIMits:RF:RFERRor:UPPer:ENABle?  
1

### 5.18.10 RF Error - Upper Limit Value

**:LIMits:RF:RFERRor:UPPer:VALue**

**:LIMits:RF:RFERRor:UPPer:VALue?**

**Description:** Set command defines the Upper Limit Value for RF Error measurement.  
Query command returns the Upper Limit Value defined for RF Error measurement.

**Range:** Hz: -5000000.0 to +5000000.0  
PPM: 0 to 1000

**Default Value:** 0.0 Hz

**Set/Query Format:** NRf | NR2

**Example:** :LIMits:RF:RFERRor:UPPer:VALue 1000Hz  
Sets Upper Limit Value for RF Error measurements to 1000.0 Hz.

**Query Response:** :LIMits:RF:RFERRor:UPPer:VALue?  
1000

THIS PAGE INTENTIONALLY LEFT BLANK.



---

## Chapter 6 - Modulation Accuracy and Power Remote Commands

### 6.1 INTRODUCTION

This chapter describes the Remote Commands used for configuring and obtaining ARIB Modulation Accuracy and Power measurements. Remote Commands are listed alphabetically under Tile headings.

### 6.2 CONSTELLATION GRAPH

#### 6.2.1 Constellation - Persistence

**:CONStellation:PERStistence**  
**:CONStellation:PERStistence?**

**Description:** Set command sets Persistence on Constellation graph.  
Query command returns parameter setting.

**Range:** 1 to 10

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :CONStellation:PERStistence 5  
Sets Constellation Graph Persistence to 5.

**Query Response:** :CONStellation:PERStistence?  
5

#### 6.2.2 Constellation - Trace Enable

**:CONStellation:TRACe:ENABLe**  
**:CONStellation:TRACe:ENABLe?**

**Description:** Set command Enables/Disables Constellation trace.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :CONStellation:TRACe:ENABLe ON  
Enables Constellation trace.

**Query Response:** :CONStellation:TRACe:ENABLe?  
1

**NOTE**

Trace must be enabled (ON) to return valid data.

### 6.2.3 Constellation - Trace Data Query

#### **:CONStellation:TRACe:FETCh?**

**Description:** Command returns Constellation trace data.

**Query Data:** <statusbyte>,<#pairs>,<x data>,<y data>,<status message>

**statusbyte (NR1):** 0 = Invalid  
1 = Valid  
2 = Inaccurate

**#pairs (NR1):** Number of x,y coordinate pairs to follow

**x, y data (NR2):** coordinate value

**statuts message (ascii):** signal not acquired\n  
**(when present)** timed out waiting for TraceMutex\n  
timed out waiting for data\n

**Query Response:** :CONStellation:TRACe:FETCh?  
1,1,288,-1871.37,0.00,629.98,0.00,-1796.91,0.00,-619.88,0.00,-574.94,0.00,  
-631.87,0.00,-582.26,0.00,586.35,0.00,-1805.57,0.00,-1796.19,0.00,-1803.18,  
0.00,-605.25,0.00,-600.47,0.00,599.68,0.00,584.98,0.00,-1794.42,0.00,  
-603.39,0.00,-610.97,0.00,-1793.05,0.00,585.14,0.00,-1790.75,0.00,612.04,  
0.00,1793.31,0.00,607.42,0.00,1806.40,0.00,1788.95,0.00,-598.09,0.00,  
607.93,0.00,592.68,0.00,-590.26,0.00,611.98,0.00,586.29,0.00,617.14,0.00,  
593.83,0.00,-598.98,0.00,-605.47,0.00,-1783.44,0.00,585.87,0.00,-1800.64  
,0.00,-594.62,0.00,-603.46,0.00,-596.39,0.00,-597.52,0.00,593.43,0.00,  
-1803.41,0.00,-1798.85,0.00,-1798.32,0.00,-607.28,0.00,-593.63,0.00,601.10,  
0.00,595.16,0.00,-1795.80,0.00,-601.23,.....

**NOTE**

Returned data includes Sync, Pilot and Data values.  
Constellation Trace must be enabled to return valid data.

## 6.3 DISTRIBUTION GRAPH

### 6.3.1 Distribution - Persistence

#### **:DISTribution:PERsistence**

#### **:DISTribution:PERsistence?**

**Description:** Set command sets Persistence on Distribution graph.  
Query command returns parameter setting.

**Range:** 1 to 10

**Default Value:** 1

**Set/Query Format:** NR1

**Example:** :DISTribution:PERsistence 5

Sets Distribution Graph Persistence to 5.

**Query Response:** :DISTribution:PERsistence?  
5

### 6.3.2 Distribution - Trace Enable

#### **:DISTribution:TRACe:ENABle**

#### **:DISTribution:TRACe:ENABle?**

**Description:** Set command Enables/Disables Distribution trace.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :DISTribution:TRACe:ENABle ON

Enables Distribution trace.

**Query Response:** :DISTribution:TRACe:ENABle?  
1

**NOTE**

Trace must be enabled (ON) to return valid data.

### 6.3.3 Distribution - Trace Data Query

#### **:DISTribution:TRACe:FETCh?**

**Description:** Command returns Distribution trace data.

**Query Data:** <statusbyte>,<#pairs>,<x data>,<y data>,<status message>

**statusbyte (NR1):** 0 = Invalid

1 = Valid

2 = Inaccurate

**#pairs (NR1):** Number of x,y coordinate pairs to follow

**x, y data (NR2):** coordinate value

**statuts message (ascii):** signal not acquired\n

**(when present)** timed out waiting for TraceMutex\n

timed out waiting for data\n

**Query Response:** :DISTribution:TRACe:FETCh?

1,1,288,-1871.37,0.00,629.98,0.00,-1796.91,0.00,-619.88,0.00,-574.94,0.00,-6  
31.87,0.00,-582.26,0.00,586.35,0.00,-1805.57,0.00,-1796.19,0.00,-1803.18,  
0.00,-605.25,0.00,-600.47,0.00,599.68,0.00,584.98,0.00,-1794.42,0.00,  
-603.39,0.00,-610.97,0.00,-1793.05,0.00,585.14,0.00,-1790.75,0.00,612.04,  
0.00,1793.31,0.00,607.42,0.00,1806.40,0.00,1788.95,0.00,-598.09,0.00,  
607.93,0.00,592.68,0.00,-590.26,0.00,611.98,0.00,586.29,0.00,617.14,0.00,  
593.83,0.00,-598.98,0.00,-605.47,0.00,-1783.44,0.00,585.87,0.00,-1800.64  
,0.00,-594.62,0.00,-603.46,0.00,-596.39,0.00,-597.52,0.00,593.43,0.00,  
-1803.41,0.00,-1798.85,0.00,-1798.32,0.00,-607.28,0.00,-593.63,0.00,601.10,  
0.00,595.16,0.00,-1795.80,0.00,-601.23,.....

**NOTE**

Returned data includes Sync, Pilot and Data values.

Distribution Trace must be enabled to return valid data.

## 6.4 POWER OVER TIME

### 6.4.1 Power Over Time - Marker Enable

**:PTIME:TRACe:MARKn:ENABle**  
**:PTIME:TRACe:MARKn:ENABle?**

**Description:** Set command Enables/Disables Marker for Power Over Time graph.  
 Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :PTIME:TRACe:MARK2:ENABle ON  
 Enables Marker 2 for Power Over Time graph.

**Query Response:** :PTIME:TRACe:MARK2:ENABle?  
 1

**NOTE** MARKn = 1 or 2 (Marker 1 or 2)

### 6.4.2 Power Over Time - Marker Position

**:PTIME:TRACe:MARKn:XPOS**  
**:PTIME:TRACe:MARKn:XPOS?**

**Description:** Set command defines Marker position on Power Over Time graph.  
 Query command returns parameter setting.

**Range:** 0 to Span

**Units:** ms

**Default Value:** 0.0 ms

**Set/Query Format:** NRf | NR2

**Example:** :PTIME:TRACe:MARK2:XPOS 100ms  
 Positions Marker 2 at 100 ms on Power Over Time graph.

**Query Response:** :PTIME:TRACe:MARK2:XPOS?  
 100

**NOTE** MARKn = 1 or 2 (Marker 1 or 2)

### 6.4.3 Power Over Time - Marker Y Value Query

**:PTIME:TRACe:MARKn:YVALue?**

**Description:** Command returns Power Over Time Y value for Marker.

**Query Data:** <statusbyte>,<value>

**statusbyte (NR1):** 0 = Invalid  
 1 = Valid  
 2 = Inaccurate

**value (NR2):** dBm

**Query Response:** :PTIME:TRACe:MARK2:YVALue?  
 1,10.45

**NOTE** MARKn = 1 or 2 (Marker 1 or 2)  
 Marker must be enabled to obtain valid data.

#### 6.4.4 Power Over Time - Span

**:PTIME:SPAN**

**:PTIME:SPAN?**

**Description:** Set command sets Span of Power Over Time graph.  
Query command returns parameter setting.

**Range:** 10 to 1800 seconds

**Units:** seconds

**Default Value:** 10 seconds

**Set/Query Format:** NRf | NR1

**Example:** :PTIME:SPAN 500s  
Sets Power Over Time graph Span to 500 seconds.

**Query Response:** :PTIME:SPAN?  
500

#### 6.4.5 Power Over Time - Trace Enable

**:PTIME:TRACe:ENABLE**

**:PTIME:TRACe:ENABLE?**

**Description:** Set command Enables/Disables Power Over Time trace.  
Query command returns parameter setting.

**Parameter:** OFF | ON | 0 | 1

**Default Value:** OFF

**Set/Query Format:** Boolean

**Example:** :PTIME:TRACe:ENABLE ON  
Enables Power Over Time trace.

**Query Response:** :PTIME:TRACe:ENABLE?  
1

**NOTE**

Trace must be enabled (ON) to return valid data.

#### 6.4.6 Power Over Time - Trace Data Query

**:PTIME:TRACe:LIVE?**

**Description:** Command returns Power Over Time trace data.

**Query Data:** <statusbyte>,<#pairs>,<x data>,<y data>,<status message>

**statusbyte (NR1):** 0 = Invalid  
1 = Valid  
2 = Inaccurate

**#pairs (NR1):** Number of x,y coordinate pairs to follow

**x, y data (NR2):** coordinate value

**statuts message (ascii):** signal not acquired\n  
(when present) timed out waiting for TraceMutex\n  
timed out waiting for data\n

**Query Response:** :PTIME:TRACe:LIVE?  
1,2,0.00,10.45,330.00,10.45

**NOTE**

Power Over Time trace must be enabled to return valid data.



**Part of CD # 6047  
Revision M0  
Jan 2020**

**VIAVI Solutions, Inc.**

<b>North America:</b>	<b>1.844.GO VIAVI / 1.844.468.4284</b>
<b>Latin America</b>	<b>+52 55 5543 6644</b>
<b>EMEA</b>	<b>+49 7121 862273</b>
<b>APAC</b>	<b>+1 512 201 6534</b>
<b>All Other Regions:</b>	<b><a href="https://www.viavisolutions.com/contacts">viavisolutions.com/contacts</a></b>