

## Quick Card

# T-BERD<sup>®</sup>/MTS-2000 and SmartOTDR Fiber License Installation

This quick card outlines how to install a license on the T-BERD/MTS-2000 and SmartOTDR test set for the following options:

- ESMARTFTTH – FTTH Smart Link Mapper (identification of splitter types, acquisition at short and long pulse widths to detect all events before and after splitters, pass/fail thresholds per PON standards)
- ESMARTFTTA – FTTA Smart Link Mapper (detection and identification of FTTA network elements)
- ENTERPRISE – Enterprise Smart Link Mapper (Identification of specific elements, pass/fail thresholds and labeling schemes per Data Center/ Enterprise standards)
- ESMARTCABL – Cable Smart Link Mapper (high-level view for high-density fiber cable certification)
- ESMARTACQ – Smart Acquisition (uses differing pulse widths to characterize the different sections of a fiber link and combines results into a single view)
- SAA-L2 – Level 2 Smart Access Anywhere (remote connectivity on private networks via cloud-based server)

### Equipment Requirements:

- T-BERD/MTS-2000 or SmartOTDR
- 4GB to 16GB USB Flash Drive with license file



Figure 1: Equipment Requirements

### License Installation:

1. Press the **Power button**  to turn on the unit.
2. Press the **Home** hard key to display the Home screen.
3. Insert the USB Flash Drive into a USB port under the flap on the top of the T-BERD/MTS 2000 or SmartOTDR.
4. Tap the **Settings** icon  in the **Home** Screen to access **System Settings**




Figure 2: Home screen

- In the **System Settings** screen, tap the **Expert Tools** soft key  to relabel the soft keys.




Figure 3: System Settings

- Tap the **Install Option** soft key .




Figure 4: Install Option

- Tap the **Import File** soft key .

Note: If a USB Flash Drive is not connected to the platform, a warning message is displayed. Tap **Confirm** once the USB Flash Drive is connected.




Figure 5: Import File

- In the **File Explorer**, select the **usbflash** drive, and select the license file (.lic) to be imported.
- Tap the **Load** soft key and tap **Confirm**. Once the license is imported, you will be prompted to reboot.

- Tap the **Reboot** soft key  to complete license installation.



Figure 6: Reboot