

# Finding the Xgig Serial Number

## *How to locate the Serial Number for Xgig Products*

### **XGIG CHASSIS**

The Serial Number for an Xgig chassis can be found on the hardware or through the software.

**Hardware:** The Xgig chassis will have a serial number sticker on the rear or bottom of the chassis.

**Software:** The Xgig chassis serial number can be found by starting Xgig Trace Control, and discovering the desired chassis. Once connected to the chassis, hover the mouse over the right side of the image, and your chassis serial number will be shown.



### **XGIG BLADE**

The Serial Number for an Xgig blade can be found on the hardware or through the Web GUI.

**Hardware:** The Xgig blade will have a serial number sticker on the end connector or on the backside of the blade.

**Web GUI:** The Xgig blade serial number can be found by logging into the Xgig via a Web GUI session. Go to Configuration → License, and the serial number for each blade installed in the chassis that you're connecting to will be listed.