

# **AVX-10K**

# Flight Line Test Set

Performance verification testing of critical airborne systems from a single device.

The AVX-10K is a comprehensive flight line test solution providing today's Avionics Technician with an easy-to-use instrument for testing Communication, Navigation, and Surveillance systems. From a quick airborne system auto-test to an in-depth troubleshooting tool, testing can conveniently be done around the aircraft or in the cockpit from the touchscreen display or using your mobile device. Easy set-up, quick testing and reporting transferable via USB, Ethernet and wireless all done from a modern user interface, or the VIAVI Solutions Mobile Tech App.



#### **Features**

- · Configurable test capability
- · Intuitive user interface
- Software defined applications
- · Remote operation
- Android<sup>™</sup> and iOS<sup>®</sup> compatible
- Guided Test for Navigation Applications
- · Built-in GPS receiver
- International test configurations

#### **Benefits**

- · Purchase only the test options that you need
- Time saving ease of operation
- Easily updated with future applications
- Conveniently test in and around the aircraft from your mobile device
- · Recall saved test sequences for future use
- Provides accurate positional data for ADS-B testing
- · Compliant with global regulatory requirements

#### **Test Usage**

- ATCRBS and Mode S Transponders
- · ADS-B In and ADS-B out
- 978/1090MHz ADS-B Traffic
- GICB
- ILS LOC, GS, and MB
- DME/VOR, TACAN
- Communications AM, FM, SSB, and SELCAL32 ARINC 714A Tone Frequencies
- VSWR and Distance to Fault
- TCAS, UAT and ELT optional

# The Future of Flight Line Avionic System Testing

Building on nearly 50 years of providing superior avionics test sets, the AVX-10K is a compact, durable tester capable of providing a wide range of quick airborne system auto-tests and in-depth troubleshooting using software specific applications.

Using over-the-air, direct and coupled connections the AVX-10K can provide testing for the following systems:


| Communications            | Navigation              | Surveillance                           |
|---------------------------|-------------------------|--|
| <ul><li>AM(VHF)</li></ul> | • ILS                   | Transponder Modes                      |
| • FM(UHF)                 | - LOC                   | A, C, S                                |
| • SSB(HF)                 | - GS                    | <ul> <li>ADS-B Out</li> </ul>          |
| • SELCAL                  | - MB                    | <ul> <li>ADS-B In (Traffic)</li> </ul> |
|                           | • VOR                   | - 1030 MHz (ADS-B                      |
|                           | • DME                   | ADS-R, TIS-B)                          |
|                           | <ul><li>TACAN</li></ul> | - UAT (ADS-B,                          |
| Other Test Tools          |                         | TIS-B, FIS-B)                          |
| • ELT                     |                         | <ul> <li>TCAS I/II and TAS</li> </ul>  |
| • VSWR                    |                         | testing                                |

ADS-B MonitoringGICB MonitoringUAT Monitoring

The added flexibility of software-based test configurations means the AVX-10K provides the right capabilities for every individual shop's testing needs.



UC-584 and TC-201A antenna couplers minimize false intruders when testing.



#### **AVX-10K Side Detail**

- 1. GPS Antenna
- 2. Dual Ethernet Ports
- 3. Dual USB Ports
- 4. Hand Strap Clips

· Distance to Fault




#### **AVX-10K Front Detail**

- 5. Power Button
- 6. Speaker
- 7. Back Button
- 8. Home Button
- 9. Quick Tray Button
- 10. Cursor Control Keys
- 11. Function Keys

- 12. Full Color Touch Screen Display
- 13. Status Indicator Lights
- 14. GPS Antenna
- 15. Antenna (ANT) Port
- 16. Direct (RF/IO) Port
- 17. SWR Port

# Buy Only the Test Capabilities You Need. Add More When You Want.

#### **Transponder**



**Transponder Auto** — This test function provides a selection for configured test options including Generic ATCRBS, Generic Mode S, FAR Part 43, and many more.

**GICB** – Testing the GICB capabilities can be performed in Simple Mode (known registers) or Advanced Mode (full register set).

**ADS-B Auto** — Available Test Types for this option include AC 20-165 and CS-ACNS. Testing supports both Airborne and Surface configurations.

ADS-B Monitor — GPS Position can be manually entered or can be determined with the built-in GPS Receiver. Monitoring supports both Airborne and Surface configurations.

**UAT Monitor** — Allows monitoring of received UAT messaging and will decode and display each received Aircraft Address and Payload Type Code.

# **TCAS/Target Generation**



**TCAS** — This option lets you set up an intruder and run a scenario to ensure TCAS functionality. Intruder types includes either Mode S or ATCRBS.

**UAT Gen** — Provides access to setup targets and run ADS-B, FIS-B and TIS-B testing for the UAT frequency.

**Target Gen** — This feature allows the user to set up and stimulate up to five static targets. Target types can be 1090 MHz ADS-B, ADS-R or TIS-B. Each target will be associated with the Aircraft Under Test's Latitude, Longitude, Heading and Position which are all configurable.

#### **Navigation**



**ILS** — Provides simultaneous Localizer (with swept DDM), Glideslope and Marker Beacon Signals.

**VOR** — Generates signals over the VOR Band (108.00 to 117.95 MHz) with 30 Hz reference phase and 9960 Hz (sub-carrier frequency modulated with 30 Hz variable phase) amplitude modulated at 30% per tone. VOR bearing selection is provided in preset steps of 30° or variable steps of 0.1°.

DME – Single DME test screen provides control over
DME Frequency/Channel, Range, Rate, RF level,
Reply, Squitter, Ident and Echo. UUT frequency,
ERP, PRF P1/P2 width and Spacing are also displayed.

**TACAN** — Combines Range and Bearing control along with Range Rate and Bearing Rate including Air-to-air modes. Displays measured values on received signal.

#### Radio Test (COMMS)



COMM AM — Provides signal generation over the Range of 10.00 to 400.00 MHz in 1 kHz increments and monitoring of transmitter power and modulation depth over the same range. A calibrated 1020 Hz tone, amplitude modulated at 30%, is also provided. Frequency control is provided in 8.33 kHz / 25 kHz channel steps or in 1 kHz variable steps. Audio output is available.

**COMM FM** — Provides signal generation over the Range of 10.00 to 400.00 MHz in 1 kHz increments and monitoring of transmitter power and modulation deviation over the same range. A 1000 Hz tone, frequency modulated at 5 kHz, is also provided. Frequency control is provided in 12.5 kHz/25 kHz channel steps or in 1 kHz variable steps. Audio output is available.

**COMM SSB** — Provides signal generation and monitoring of transmitter power and modulation depth over the range of 10.00 to 30.00 MHz. A 1000 Hz tone is also provided. Audio output is available.

**SELCAL** – Provides selectable consecutive amplitude modulated tone pulse pairs, which may be sent continuously or as a burst.

#### **ELT**



**121.5/243 BCN Modes** – Provides monitoring for 121.5/243 MHz swept tone short range Beacons and displays transmitter frequency, power and start/stop tone frequencies. Audio output is available.

**406 BEACON Mode** — Provides monitoring for 406 MHz COPAS/SARSAT Emergency Locator Transmitter (ELT), Emergency Position Indicating Radio Beacons (EPIRB and Personal Locator) PLB Beacons. The Beacon utilizes BPSK data to transmit position information derived from a long-range navigation system or GPS receiver. The Protocol management and data field decode is automatically handled by the AVX-10K.

#### **Test Tools**



**VSWR/DTF** — This test tool is provided to assist in troubleshooting RF level issues. Test mode for both VSWR and Distance To Fault (DTF) testing can be set to VSWR or Return Loss.

**Guided Test** – Leverage the instructions from work cards to create a guided test. This process ensures consistent and repeatable test steps for mistake free work.

**Cable Loss** — This feature helps identify problems, as the loss identified on a cable may not be correct causing erroneous readings in test set ups and also to identify issues with wiring that can contribute to poor system performance.

Templates — allows the user to save all set-up parameters for the entire test set and recall for a later use. This is useful should you have common repeatable set-up parameters across multiple test applications for a specific aircraft platform. Next time you test that platform, simply choose the desired template and all saved set-up parameters will be recalled, saving time.

#### **Mobile Application for Remote Operation**

The VIAVI Solutions Mobile Tech App, is a handy tool for remotely controlling the AVX-10K in and around the aircraft. A directory of applicable on-line information is also available to users on-the-fly to get answers right when they're needed.

- The Mobile Tech app enables remote operation via the smart device, which allows techs to operate the unit from a remote location, without going back and forth from the test set to the cockpit
- Convenient access to documentation and training material

# AVX.108 AVX

Use your favorite mobile device with the AVX-10K for easy remote access to the test set.


# StrataSync™ Cloud-Enabled Test-Data Management

StrataSync is a hosted, cloud-based software application that provides asset, configuration, and test-data management for a wide range of VIAVI Solutions instruments. StrataSync manages inventory, test results, and performance data anywhere with browser-based ease and improves technician and instrument efficiency.

StrataSync stores test data in a central location, enabling viewing and sharing of test-data results. Often, data is not centrally collected and its long-term value is underrated. The causes of system failures, and data from previous tests is not available or is not analyzed. With StrataSync, critical aircraft performance information can be stored in a secure location, enabling proactive problem-area identification. Data is also accessible via an API to simplify automated retrieval.

# **Asset Management**

StrataSync asset management provides a single, intuitive way to monitor and assure your AVX-10K has the latest firmware installed. An administrator can quickly identify out-of-date test sets and apply firmware updates automatically via StrataSync which are deployed to the test set by simply syncing to StrataSync via the internet. New software options can also be purchase at a later date and deployed via StrataSync. This dramatically reduces the amount of time spent in the work center identifying upgrade requirements, and then manually upgrading the test set.



The StrataSync online asset management and reporting tool ensure test sets are up-to-date with the latest firmware, test capabilities, and provides access to test report data.

With StrataSync, registration can identify which test units are assigned to each technician. StrataSync tracks each test-set sync with the server, making utilization and test practices visible.

#### **Ordering Information**

| (• = Standard Item, all other items optional) |  |                                 | Preconfigured Kits        |                                |                                |
|---|--|---------------------------------|---------------------------|--------------------------------|--------------------------------|
| Catalog Number                                | Item Description                         | AVX-10K-FLTS<br>(Test Set Only) | AVX-10K-NAV<br>(NAV/COMM) | AVX-10K-SVLC<br>(Surveillance) | AVX-10K-CNS<br>(COMM/NAV/SVLC) |
| AVX-10K                                       | AVX-10K Unit                             | •                               | •                         | •                              | •                              |
| AC10K-PWRADPTR                                | AC/DC Power Adapter                      | •                               | •                         | •                              | •                              |
| AC10K-HANDSTRAP                               | Hand Strap                               | •                               | •                         | •                              | •                              |
| AC10K-OPSMNL                                  | Manual, Operations                       | •                               | •                         | •                              | •                              |
| AC10K-QSGUIDE                                 | Manual, Quick Start                      | •                               | •                         | •                              | •                              |
| AC10K-TRANSITCASE                             | Carrying Case, Hard Transit              |                                 | •                         | •                              | •                              |
| AC10K-ADPTRKIT                                | Calibration Kit, VSWR/DTF                | •                               | •                         | •                              | •                              |
| AC10K-ANT-ILS                                 | Antenna, VOR/ILS                         |                                 | •                         |                                | •                              |
| AC10K-ANT-MB                                  | Antenna, Marker Beacon                   |                                 | •                         |                                | •                              |
| AC10K-CBL6FT                                  | Cable, Coax 6'                           |                                 | •                         | •                              | •                              |
| AC10K-FPANT                                   | Antenna, RF Flat Panel w/1′ Cbl (62401)  |                                 |                           | •                              | •                              |
| 62401   | Cable, Coax 1'                           | •                               | •                         |                                |                                |
| AC10K-UC-584                                  | Shield/Coupler, UC-584 w/25' Cbl (14131) |                                 |                           | •                              | •                              |
| Software Options                              | Select Test Capability                   |                                 |                           |                                |                                |
| AVX-10K-SXPDR                                 | Transponder Modes A,C,S                  |                                 |                           | •                              | •                              |
| AVX-10K-SADSB                                 | ADS-B-In/Out/GICB/Target Gen             |                                 |                           | •                              | •                              |
| AVX-10K-STCAS                                 | TCAS I/II                                |                                 |                           |                                |                                |
| AVX-10K-SDME                                  | DME                                      |                                 | •                         | •                              | •                              |
| AVX-10K-STACAN                                | TACAN                                    |                                 |                           |                                |                                |
| AVX-10K-SUAT                                  | UAT In/Out                               |                                 |                           |                                |                                |
| AVX-10K-SNAV                                  | Navigation (ILS/MB/VOR)                  |                                 | •                         |                                | •                              |
| AVX-10K-SELT                                  | ELT 121.5/243/406MHz                     |                                 |                           |                                |                                |
| AVX-10K-SCOM                                  | Radio Test AM/FM (Comms)                 |                                 | •                         |                                | •                              |

#### **Selectable Power Cords**

| AC10K-PWRCRD-US/CAN | AC Power Cord - US/Canada             |
|---------------------|---------------------------------------|
| AC10K-PWRCRD-EU     | AC Power Cord - Continental Europe    |
| AC10K-PWRCRD-AUSNZ  | AC Power Cord - Australia/New Zealand |
| AC10K-PWRCRD-INDIA  | AC Power Cord - India                 |
| AC10K-PWRCRD-UK/IRE | AC Power Cord - UK/Ireland            |
| AC10K-PWRCRD-SWITZ  | AC Power Cord - Switzerland           |

 ${\it AVX-10K-FLTS-Flight Line Test Set only configuration-allows customer to pick and choose what hardware and software options desired.}$ 

AVX-10K-NAV – Communication, Navigation package includes the NAV/COMM software options shown and all NAV/COMM required hardware. This package is comparable to the IFR4000.

 ${\rm AVX-10K-SVLC-Surveillance\ package\ includes\ Transponder,\ ADS-B\ and\ DME\ software\ options\ and\ all\ required\ hardware\ like\ the\ IFR6000.}$ 


AVX-10K-CNS - Communication, Navigation and Surveillance package includes all hardware to support all software options. TCAS, UAT and ELT are optional.

#### **Additional Accessories**

| AC10K-ANTBRKT | Required to use your current IFR6000<br>1030/1090 RF Antenna          |
|---------------|---|
| AC10K-CC      | Soft Side Carrying Case   |
| AC10K-BATTERY | Internal Battery, Lithium Ion 7.3V 13Ah                               |
| AC10K-CBL12FT | Cable, Coax 12'   |
| 141131        | Cable, Coax 25'   |
| 142839        | Cable, Coax 50'   |
| 140889        | TC-201A TCAS/XPDR Directional Antenna<br>Coupler (Min. 110" fuselage) |
| 22163082      | TC-201B TCAS/XPDR Directional Antenna<br>Coupler (Min. 92" fuselage)  |
| AC10K-UC-584S | Shield/Coupler, UC-584S w/25' Cable                                   |
| 90106         | UC-584S Coupler Placement Pole  |
|               |   |

# **AVX-10K Commercial Kits Comprising Items List**

| Item# | Qty | Part #         | Description                    | AVX-10K-NAV<br>22154862 | AVX-10K-SVLC<br>22154822 | AVX-10K-CNS<br>22154861 |
|-------|-----|----------------|--------------------------------|-------------------------|--------------------------|-------------------------|
| 1     | 1   | 22137163       | AVX-10K Base Unit              | •                       | •                        | •                       |
| 2     | 1   | 22146602       | AC/DC Power Adapter            | •                       | •                        | •                       |
| 3     | 1   | 22153600       | Antenna - ILS                  | •                       |                          | •                       |
| 4     | 1   | 22153599       | Antenna 75 Mhz MB              | •                       |                          | •                       |
| 5     | 1   | 22141787       | Antenna, RF Flat Panel         |                         | •                        | •                       |
| 6     | 1   | 87431          | Shield/Coupler, UC-584         |                         | •                        | •                       |
| 7     | Opt | 22183050       | Attenuator                     |                         |                          |                         |
| 8     | Opt | 22183051       | Headset Adapter (Note 1)       |                         |                          |                         |
| 9     | 1   | AC10K-ADPTRKIT | Adapter Kit (See Figure 1)     | •                       | •                        | •                       |
| 10    | 1   | 62401          | Cable, Coax 1'                 | •                       | •                        | •                       |
| 11    | 1   | 22152432       | Cable, Coax 6'                 | •                       | •                        | •                       |
| 12    | 1   | 141131         | Cable, Coax 25'                |                         | •                        | •                       |
| 13    | Opt | 22022754       | Power Cord - US (Note 2)       |                         |                          |                         |
| 14    | Opt | 22022744       | Power Cord - European (Note 2) |                         |                          |                         |
| 15    | 1   | 22141759       | Operations Manual              | •                       | •                        | •                       |
| 16    | 1   | 22135253       | Quick Start Guide              | •                       | •                        | •                       |
| 17    | 1   | 22142165       | Handstrap                      | •                       | •                        | •                       |
| 18    | 1   | 142094         | Shield/Coupler, UC-584S        |                         |                          | •                       |



# AC10K-ADPTRKIT (22183132) Comprising Items List

| Item# | Qty | Part #   | Description   | AVX-10K-NAV-M<br>22182233 | AVX-10K-SVLC-M<br>22182230 | AVX-10K-MIL<br>22182232 |
|-------|-----|----------|---|---------------------------|----------------------------|-------------------------|
| 1     | 1   | 24140    | CAP, TNC, FEMALE SHORT                              | •                         | •                          | •                       |
| 2     | 1   | 24141    | Conn; Conn Acc; LOAD 50 Ohm;<br>TNC/F; DC - 6.0 GHz | •                         | •                          | •                       |
| 3     | 1   | 138598   | Adapter, TNC-F to TNC-F                             | •                         | •                          | •                       |
| 4     | 1   | 22183053 | Adapter, TNC-M to BNC-M                             | •                         | •                          | •                       |
| 5     | 1   | 23758    | Adapter, TNC-M to BNC-F                             | •                         | •                          | •                       |
| 6     | Opt | 22181865 | Adapter, N-F to TNC-F                               |                           |                            |                         |
| 7     | Opt | 23773    | Adapter, N-F to N-F                                 |                           |                            |                         |
| 8     | Opt | 92553    | Adapter, N-F to TNC-M                               |                           |                            |                         |
| 9     | Opt | 38589    | Adapter, N-M to TNC-F                               |                           |                            |                         |
| 10    | Opt | 22183052 | Hook, Cplr Placement                                |                           |                            |                         |
| 11    | Opt | 22183055 | Cap, TNC for Coupler Hook                           |                           |                            |                         |

Included Item Optional Item




Figure 1: Adapter Kit

# **Physical Characteristics**

| Test Set          | 12" H x 5.3" W x 3.75" D (30.48 cm x 13.5 cm x 9.5 cm)   |
|-------------------|--|
| Transit Case Size | 24.5" H x 19.3" W x 22.2" D (62.23 cm x 49.2 cm x 31 cm) |
| Weight            | 6.5 lbs. (2.94 kg) test set only                         |
|                   | 32 lbs. (14.51 kg) shipping weight                       |
| Battery           | 4 hrs continuous, > 8 hrs typical                        |
| Power             | 100 - 250 VAC, 1.5 A max, 47-63 hz                       |

#### Environmental

| Operating Temp | -20° to 55°C (-4° to 131° F)   |
|----------------|--------------------------------|
| Storage Temp   | -30° to 71°C (-22° to 159.8°F) |

# **General Specification**

# **Care Support Extended Warranty**

| AVX-10K-SILVER-5 | 5 Yr Total HW Warranty + Certified Calibrations - SILVER-5 | 60 Month |
|------------------|--|----------|
| AVX-10K-SILVER-3 | 3 Yr Total HW Warranty + Certified Calibrations - SILVER-3 | 36 Month |
| AVX-10K-BRONZE-2 | 1 Yr Extended HW Warranty only - BRONZE-2                  | 24 Month |

# Certified Calibration Care Plan Add-ons (Requires corresponding Silver Care/MaxCare Plan)

| CERT-CAL-DATA-3 | Certified Calibration Data - Pre and Post Cal Data Report for Care Plans - First 3 Years |
|-----------------|--|
| CERT-CAL-DATA-5 | Certified Calibration Data - Pre and Post Cal Data Report                                |

#### **Training**

| AVX-10K-TT | How to test with the AVX-10K - On-Site Instructor-Led Training, 1 day |  |
|------------|---|--|
|------------|---|--|

# **Test Compatibility**

| Transponder            | Modes A, C, S  |
|------------------------|--|
|                        | ADS-B 1090 MHz In/Out/GICB   |
|                        | UAT 978 MHz In/Out   |
| TCAS/Target Generation | ADS-B In (Traffic - Target Gen) 1030 MHz (ADS-B, ADS-R, TIS-B) 978 MHz UAT (ADS-B, TIS-B, FIS-B) |
| Navigation             | VOR, ILS (LOC/GS/MB), DME, TACAN   |
| ELT                    | 121.5, 243, 406 MHz Beacons  |
| Radio Test (COMMS)     | HF, VHF, UHF, SSB, AM/FM, SELCAL   |
| Test Tools             | Distance-To-Fault (DTF), VSWR, Cable Loss  |
|                        |  |

#### **Certificates and Certifications**

| AVX-10K Calibration Certificate (ISO 9001) (Included)     |
|---|
| AVX-10K Calibration Certificate with Test Data (ISO 9001) |
| MIL-PRF-28800F Class 2                                    |
| MIL-STD-810F  |
| UL  |
| EN  |
| CE  |



Rugged case provides storage for all accessories necessary for testing multiple systems.



Ergonomic integrated kick stand makes running tests and reviewing results simple.



Flat panel antenna, whip antenna, or antenna couplers provide a variety of methods to connect to the system under test.



Download the free VIAVI Mobile Tech app from the App Store® or Google Play store and remotely control the AVX-10K, access technical documentation, and training videos.



StrataSync is a free hosted, cloud-based solution that provides asset, configuration, and test data management for VIAVI instruments and ensures all instruments have the latest software installed.

Google Play and the Google Play logo are trademarks of Google LLC. App Store® and App Store Logo are registered trademarks of Apple Inc.



#### viavisolutions.com

Contact Us +1800 835 2352 | AvComm.Sales@viavisolutions.com To reach the VIAVI office nearest you, visit viavisolutions.com/contact

© 2025 VIAVI Solutions Inc.