

## Quick Card

# T-BERD<sup>®</sup>/MTS 5800 Network Tester Updating Software via USB

This quick card outlines how to upgrade the SmartClass 4800 or T-BERD/MTS 5800 to the latest software revision using a USB Flash Drive.



### Equipment Requirements:

- Laptop or Personal Computer with Internet Access
- 4GB to 16GB USB Flash Drive





Figure 1: Equipment Requirements


### Format USB Flash Drive:

1. Press the Power button  to turn on the test set.
2. Insert the USB Flash Drive into a USB port on the side of the T-BERD/MTS test set.
3. Tap the **System** icon  in the **Status Bar** at the top of the display to show the **System menu**.



4. Tap the **USB** Icon  to show the USB menu.

5. Tap  to format the USB Flash Drive.

6. Tap  and remove the USB Flash Drive from the USB port of the test set.

7. Insert the formatted USB flash drive into your Laptop or Personal Computer.




Figure 2: T-BERD/MTS-5800 System Menu




Figure 3: T-BERD/MTS 5800 USB Menu

**Download archive and extract to USB Flash Drive:**

1. On Laptop or Personal Computer, open the Internet browser and navigate to the software update portal for your test set:
  - SmartClass 4800: <http://4800.updatemyunit.net/>
  - T-BERD/MTS 5800: <http://5800.updatemyunit.net/>
  - T-BERD/MTS 5800v2: <http://5800v2.updatemyunit.net/>
  - T-BERD/MTS 5800-100G: <http://5800-100g.updatemyunit.net/>







Figure 4: Updatemyunit.net Software Update Portal

2. Click on a Flag icon to download and run platform software from the nearest server:
  -  European Server
  -  North America Server
  -  Singapore Server.
3. Enter or browse to the path of the USB Stick and press the OK button to extract update files to the USB Flash Drive.





Figure 5: Extracting the Platform Software



4. Eject the USB Flash Drive from the Laptop or Personal Computer.

## Upgrade Test Set:

1. Insert the USB Flash Drive into a USB port on the side of the T-BERD/MTS test set.
2. Plug the T-BERD/MTS test set into AC power. You cannot update the software while running on battery.

3. Tap the **System** icon  in the **Status Bar** at the top of the display to show the **System menu**.



4. Tap the Upgrade Icon  to show the Upgrade menu.
5. Select USB for the upgrade method.
6. Tap  and follow screen prompts to complete the software upgrade.




Figure 6: T-BERD/MTS 5800 System Menu




Figure 7: T-BERD/MTS 5800 USB Upgrade Menu