

Quick Card

OneExpert CATV/DSL/DSP Smart Access Anywhere™

This quick card describes how to use **VIAVI Smart Access Anywhere (SAA)** software to remotely operate the ONX family of instruments.


Equipment Requirements:

- PC running Windows operating system with internet access and the Smart Access Anywhere software application. **SAA Mobile App (iOS, Android) not supported on ONX at this time.**
- ONX 580/620/630/220 equipped with:
 - Firmware v9.0.17 or greater (ONX580)
 - Firmware v3.16 or greater (ONX620/630)
 - Firmware v2.5.5 (ONX220)
 - Secure Access Anywhere License (Temporary or permanent)
 - Wired or wireless internet access




How to Determine if Meter Has SAA License:

- Navigate to **Network→System Settings→Software Options**, look for **Smart Access Anywhere** option
 - If this is not **Enabled** contact your supervisor or [VIAVI Representative](#)



Download and Install VIAVI Smart Access Anywhere software:


1. On user PC open an Internet browser and navigate to VIAVI Smart Access Anywhere software portal: <http://smartaccess.updatemyunit.net/>.
2. Click on link under **Download latest update of Smart Access Anywhere Software for Windows** to download the latest Smart Access Anywhere software release:



3. Open the downloaded .ZIP archive and extract the executable Smart Access Anywhere installation image.
4. Double click on the installation image and follow the on-screen instructions to install the Smart Access Anywhere application.


Establish Instrument Internet Connection:

1. Navigate to the **System** → **Network** screen
2. Choose **Ethernet** or **WiFi** tab as appropriate
3. Use of a technician's mobile phone as WiFi hotspot is common use case
4. Confirm that network connection is successful




Initiate Smart Access Anywhere Session from ONX Meter

1. Navigate to **System Settings**→**Remote Operation**→**Smart Access Anywhere**, ensure **Enable Smart Access Anywhere** is checked
2. Click on **Connect to SAA Server**
3. Note **Smart Access Anywhere Code** for future use




Establish Smart Access Anywhere Connection:


1. Launch the VIAMI Smart Access Anywhere application and enter the Access Code in the text box labeled **Access Code** and click **Connect**.



2. Once connection is established click over to the **Remote Screen** tab



3. When prompted enter the VNC password as observed on ONX screen



4. At this point you have full remote visibility and control over ONX instrument

